

Connect

Developing with Connect

Getting Started

[Overview](#)

[Connect Quick-Start Guide \(PDF\)](#)

Fundamentals

[Overview](#)

[Connect Fundamentals \(PDF\)](#)

[Using Silicon Labs Connect v3.x with IEEE 802.15.4 \(PDF\)](#)

[Wireless Networking Fundamentals \(PDF\)](#)

Connect Developer's Guide

[Overview](#)

Developing and Debugging

[Overview](#)

[Architecture of the Silicon Labs Connect Stack v3.x \(PDF\)](#)

[Customizing Applications with Silicon Labs Connect v3.x \(PDF\)](#)

[Network Co-Processor Applications with Silicon Labs Connect v3.x \(PDF\)](#)

[Using Real Time Operating Systems with Silicon Labs Connect v3.x \(PDF\)](#)

[Energy Saving with Silicon Labs Connect v3.x \(PDF\)](#)

[Building Low Power Networks with the Silicon Labs Connect Stack v3.x \(PDF\)](#)

[EFR32 Radio Configurator Guide for Simplicity Studio 5 \(PDF\)](#)

[PHY Limitations and Timing Optimization](#)

Bootloading

[Overview](#)

[Bootloader Fundamentals \(PDF\)](#)

[Bootloading and OTA with Silicon Labs Connect v3.x \(PDF\)](#)

[Using the Gecko Bootloader with Silicon Labs Connect \(PDF\)](#)

[Gecko Bootloader User's Guide \(PDF\)](#)

[Series 2 Secure Boot with RTSL \(PDF\)](#)

[Transitioning to the Updated Gecko Bootloader in GSDK 4.0 and Higher \(PDF\)](#)

Multiprotocol

[Overview](#)

[Multiprotocol Fundamentals \(PDF\)](#)

[Dynamic Multiprotocol User's Guide \(PDF\)](#)

Non-Volatile Data Storage

[Overview](#)

[Non-Volatile Data Storage Fundamentals \(PDF\)](#)

[Using NVM3 Data Storage \(PDF\)](#)

[Bringing Up Custom Devices for the EFR32MG and EFR32FG Families \(PDF\)](#)

[Using Tokens for Non-Volatile Data Storage \(PDF\)](#)

Security

[Overview](#)

[IoT Endpoint Security Fundamentals \(PDF\)](#)

[Series 2 Secure Debug \(PDF\)](#)

[Production Programming of Series 2 Devices \(PDF\)](#)

[Anti-Tamper Protection Configuration and Use \(PDF\)](#)

[Authenticating Silicon Labs Devices using Device Certificates \(PDF\)](#)

[Secure Key Storage \(PDF\)](#)

[Programming Series 2 Devices Using the DCI and SWD \(PDF\)](#)

[Integrating Crypto Functionality with PSA Crypto vs. Mbed TLS \(PDF\)](#)

Connect API Reference Guide

Connect Stack API Reference

Connect Stack Version

`EMBER_MAJOR_VERSION`

`EMBER_MINOR_VERSION`

`EMBER_PATCH_VERSION`

`EMBER_SPECIAL_VERSION`

`EMBER_BUILD_NUMBER`

`EMBER_FULL_VERSION`

`EMBER_VERSION_TYPE`

`SOFTWARE_VERSION`

Connect Data Types

EmberNetworkParameters

`panId`

`radioTxPower`

`radioChannel`

EmberIncomingMessage

`options`

`source`

`endpoint`

`rssI`

`length`

`payload`

`timestamp`

`lqi`

EmberOutgoingMessage

`options`

`destination`

`endpoint`

`tag`

`length`

`payload`

`ackRssi`

- timestamp
- EmberMacAddress
 - longAddress
 - shortAddress
 - addr
 - mode
- EmberMacFrame
 - srcAddress
 - dstAddress
 - srcPanId
 - dstPanId
 - srcPanIdSpecified
 - dstPanIdSpecified
- EmberIncomingMacMessage
 - options
 - macFrame
 - rsi
 - lqi
 - frameCounter
 - length
 - payload
 - timestamp
- EmberOutgoingMacMessage
 - options
 - macFrame
 - tag
 - frameCounter
 - length
 - payload
 - ackRssi
 - timestamp
- EmberKeyData
 - contents
- EventActions
 - queue
 - handler
 - marker
 - name
- Event_s
 - actions
 - next
 - timeToExecute
- EventQueue_s
 - isrEvents

- events
- EmberEventControl
 - status
 - taskid
 - timeToExecute
- EmberEventData_S
 - control
 - handler
- EmberTaskControl
 - nextEventTime
 - events
 - busy
- EmberNodeType
- EmberNetworkStatus
- EmberChildFlags
- EmberMessageOptions
- EmberMacAddressMode
- EmberEventUnits
- @2
- EmberCounterType
- EmberPhyType
- EmberCalType
- EmberTxStreamParameters
- EmberEUI64
- EmberNodeld
- EmberPanId
- EmberMessageLength
- EmberTaskId
- Event
- EventQueue
- EmberEventData
- EmberBuffer
- emberKeyContents
- EXTENDED_PAN_ID_SIZE
- EUI64_SIZE
- EMBER_ENCRYPTION_KEY_SIZE
- EMBER_NULL_NODE_ID
- EMBER_BROADCAST_ADDRESS
- EMBER_USE_LONG_ADDRESS
- EMBER_COORDINATOR_ADDRESS
- EMBER_CAL_INVALID_VALUE
- Stack Information
 - Stack Counters
 - emberGetCounter

emberStackStatusHandler
emberStackIsrHandler
emberStackIdleHandler
emberRadioNeedsCalibratingHandler
emberChildJoinHandler
emberStackPowerDown
emberStackPowerUp
emberNetworkState
emberStackIsUp
emberSetSecurityKey
emberGetSecurityKey
emberSetRadioChannelExtended
emberSetRadioChannel
emberGetRadioChannel
emberGetDefaultChannel
emberPhyConfigInit
emberCalibrateCurrentChannelExtended
emberCalibrateCurrentChannel
emberApplyIrCalibration
emberTempCalibration
emberGetCalType
emberSetRadioPower
emberGetRadioPower
emberSetRadioPowerMode
emberSetMacParams
emberMacGetParentAddress
emberStackIdleTimeMs
emberGetInt32uMillisecondTick
emberCurrentStackTasks
emberOkToNap
emberOkToHibernate
emberGetEui64
emberIsLocalEui64
emberGetNodeId
emberGetPanId
emberGetNodeType
emberGetParentId
emberGetVersionInfo
EMBER_HIGH_PRIORITY_TASKS
EMBER_INVALID_CHANNEL

Network Management

Frequency Hopping

emberFrequencyHoppingStartClientCompleteHandler
emberFrequencyHoppingSetChannelMask

emberFrequencyHoppingStartServer
emberFrequencyHoppingStartClient
emberFrequencyHoppingStop

Parent Support

emberChildJoinHandler
emberPurgeIndirectMessages
emberSetIndirectQueueTimeout
emberFormNetwork
emberGetChildFlags
emberGetChildInfo
emberRemoveChild

emberIncomingBeaconHandler
emberActiveScanCompleteHandler
emberEnergyScanCompleteHandler
emberInit
emberTick
emberNetworkInit
emberStartActiveScan
emberSetActiveScanDuration
emberGetActiveScanDuration
emberStartEnergyScan
emberSetApplicationBeaconPayload
emberJoinNetworkExtended
emberJoinNetwork
emberPermitJoining
emberJoinCommissioned
emberSetSelectiveJoinPayload
emberClearSelectiveJoinPayload
emberSetAuxiliaryAddressFilteringEntry
emberGetAuxiliaryAddressFilteringEntry
emberResetNetworkState
emberMacFormNetwork
emberMacSetPanCoordinator
emberNetworkLeave
emberMacAddShortToLongAddressMapping
emberMacClearShortToLongAddressMappings
emberOfdmSetMcs
emberOfdmGetMcs
EMBER_MAC_MAX_APP_BEACON_PAYLOAD_LENGTH
EMBER_MAC_STACK_BEACON_PAYLOAD
EMBER_MAC_STACK_BEACON_PAYLOAD_LENGTH
EMBER_MAC_MAX_BEACON_FIELDS_LENGTH
EMBER_CHILD_TABLE_AGING_DISABLED
EMBER_CHILD_TABLE_MAX_TIMEOUT_S

EMBER_MAX_SELECTIVE_JOIN_PAYLOAD_LENGTH
EMBER_MAX_AUXILIARY_ADDRESS_FILTERING_TABLE_LENGTH

Radio Stream

emberStartTxStream
emberStopTxStream

Configuration

EMBER_HEAP_SIZE
EMBER_CHILD_TABLE_SIZE
EMBER_CHILD_TABLE_TOKEN_SIZE
EMBER_CHILD_TIMEOUT_SEC
EMBER_INDIRECT_QUEUE_SIZE
EMBER_MAC_OUTGOING_QUEUE_SIZE
EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS
EMBER_NWK_RANGE_EXTENDER_UPDATE_PERIOD_SEC
EMBER_MAC_ACK_TIMEOUT_MS
EMBER_RADIO_CCA_THRESHOLD
EMBER_FREQUENCY_HOPPING_SEED
EMBER_FREQUENCY_HOPPING_START_CHANNEL
EMBER_FREQUENCY_HOPPING_END_CHANNEL
EMBER_FREQUENCY_HOPPING_CHANNEL_DURATION_MS
EMBER_FREQUENCY_HOPPING_CHANNEL_GUARD_DURATION_MS
EMBER_FREQUENCY_HOPPING_SERVER_FREQ_INFO_BROADCAST_PERIOD_S
EMBER_FREQUENCY_HOPPING_SLEEPY_CLIENT_RESYNC_PERIOD_S
EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_TIMEOUT_S
EMBER_FREQUENCY_HOPPING_SERVER_ADVERTISING_ITERATION_COUNT
EMBER_COORDINATOR_FIRST_SHORT_ID_TO_BE_ASSIGNED
EMBER_SECURITY_SHORT_TO_LONG_MAPPING_TABLE_SIZE
EMBER_CSP_CALLBACK_MESSAGE_BUFFER_SIZE

Status Codes

EmberStatus

Stack Tokens

tokTypeStackKey
networkKey
tokTypeStackNodeData
panId
radioTxPower
radioFreqChannel
nodeType
nodeId
parentId

tokTypeStackChildTableEntry

longId
shortId
flags

tokTypeStackNvdataVersion
tokTypeStackNonceCounter
tokTypeStackKeyID
tokTypeStackLastAllocatedId
tokTypeStackBootCounter
tokTypeParentLongId
CURRENT_STACK_TOKEN_VERSION

Event Scheduling

sli_event_control_set_active
emEventControlSetDelayMS
emEventControlGetRemainingMS
emberRunEvents
emberRunTask
emberMsToNextEvent
emberMsToNextEventExtended
emberMsToNextStackEvent
emberTaskInit
emberMarkTaskIdle
emTaskEnableIdling
emMarkTaskActive
elapsedTimeInt8u
elapsedTimeInt16u
elapsedTimeInt32u
MAX_INT8U_VALUE
HALF_MAX_INT8U_VALUE
timeGTorEqualInt8u
MAX_INT16U_VALUE
HALF_MAX_INT16U_VALUE
timeGTorEqualInt16u
MAX_INT32U_VALUE
HALF_MAX_INT32U_VALUE
timeGTorEqualInt32u
MILLISECOND_TICKS_PER_SECOND
MILLISECOND_TICKS_PER_DECISECOND
MILLISECOND_TICKS_PER_QUARTERSECOND
MILLISECOND_TICKS_PER_MINUTE
MILLISECOND_TICKS_PER_HOUR
MILLISECOND_TICKS_PER_DAY
EMBER_TASK_COUNT
emberEventControlSetInactive
emberEventControlGetActive
emberEventControlSetActive
EMBER_MAX_EVENT_CONTROL_DELAY_MS
emberEventControlSetDelayMS

EMBER_MAX_EVENT_CONTROL_DELAY_QS
emberEventControlSetDelayQS
EMBER_MAX_EVENT_CONTROL_DELAY_MINUTES
emberEventControlSetDelayMinutes
emberEventControlGetRemainingMS
emberTaskEnableIdling
emberMarkTaskActive
__EVENT_H__

Memory Buffer

emberAllocateBuffer
emberMarkBuffer
emberGetBufferPointer
emberGetBufferLength
emberGetAvailableBufferMemory
EMBER_NULL_BUFFER

Messaging

emberMessageSentHandler
emberMacMessageSentHandler
emberIncomingMessageHandler
emberIncomingMacMessageHandler
emberMessageSend
emberMacMessageSend
emberPollForData
emberSetPollDestinationAddress
emberGetMaximumPayloadLength
emberUsingLongMessages
emberNcpSetLongMessagesUse
emberPurgeIndirectMessages
emberSetIndirectQueueTimeout
EMBER_MAX_UNSECURED_APPLICATION_PAYLOAD_LENGTH
EMBER_MAX_SECURED_APPLICATION_PAYLOAD_LENGTH
EMBER_MAX_ENDPOINT

Connect Application Framework API Reference

Application Framework Common

emberAfInitCallback
emberAfTickCallback
emberAfStackStatusCallback
emberAfIncomingMessageCallback
emberAfIncomingMacMessageCallback
emberAfMessageSentCallback
emberAfMacMessageSentCallback
emberAfChildJoinCallback
emberAfActiveScanCompleteCallback
emberAfEnergyScanCompleteCallback

- emberAfMarkApplicationBuffersCallback
- emberAfIncomingBeaconCallback
- emberAfFrequencyHoppingStartClientCompleteCallback
- emberAfRadioNeedsCalibratingCallback
- emberAfStackIdleCallback
- emberAfCommonOkToEnterLowPowerCallback
- emberAfGetResetCause
- emberAfAllocateEvent
- Command Interpreter Plugin
- Debug Print Plugin
- Mailbox Client Plugin
 - emberAfPluginMailboxClientMessageSubmitCallback
 - emberAfPluginMailboxClientMessageDeliveredCallback
 - emberAfPluginMailboxClientCheckInboxCallback
 - emberAfPluginMailboxClientMessageSubmit
 - emberAfPluginMailboxClientCheckInbox
- Mailbox Server Plugin
 - emberAfPluginMailboxServerMessageDeliveredCallback
 - emberAfPluginMailboxServerAddMessage
- Mailbox Common
 - EmberAfMailboxStatus
- Ota Unicast Bootloader Client Plugin
 - emberAfPluginOtaUnicastBootloaderClientNewIncomingImageCallback
 - emberAfPluginOtaUnicastBootloaderClientIncomingImageSegmentCallback
 - emberAfPluginOtaUnicastBootloaderClientImageDownloadCompleteCallback
 - emberAfPluginOtaUnicastBootloaderClientIncomingRequestBootloadCallback
 - emberAfPluginOtaUnicastBootloaderClientAbortImageDownload
- Ota Unicast Bootloader Server Plugin
 - emberAfPluginOtaUnicastBootloaderServerGetImageSegmentCallback
 - emberAfPluginOtaUnicastBootloaderServerImageDistributionCompleteCallback
 - emberAfPluginOtaUnicastBootloaderServerRequestTargetBootloadCompleteCallback
 - emberAfPluginOtaUnicastBootloaderServerInitiateImageDistribution
 - emberAfPluginUnicastBootloaderServerInitiateRequestTargetBootload
 - emberAfPluginOtaUnicastBootloaderServerAbortCurrentProcess
 - EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS
 - EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS
 - EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS
- Ota Unicast Bootloader Common
 - EmberAfOtaUnicastBootloaderStatus
- Ota Broadcast Bootloader Client Plugin
 - emberAfPluginOtaBootloaderClientNewIncomingImageCallback
 - emberAfPluginOtaBootloaderClientIncomingImageSegmentCallback
 - emberAfPluginOtaBootloaderClientImageDownloadCompleteCallback
 - emberAfPluginOtaBootloaderClientIncomingRequestStatusCallback

[emberAfPluginOtaBootloaderClientIncomingRequestBootloadCallback](#)

[emberAfPluginOtaBootloaderClientAbortImageDownload](#)

Ota Broadcast Bootloader Server Plugin

[emberAfPluginOtaBootloaderServerGetImageSegmentCallback](#)

[emberAfPluginOtaBootloaderServerImageDistributionCompleteCallback](#)

[emberAfPluginBootloaderServerRequestTargetsStatusCompleteCallback](#)

[emberAfPluginOtaBootloaderServerRequestTargetsBootloadCompleteCallback](#)

[emberAfPluginOtaBootloaderServerInitiateImageDistribution](#)

[emberAfPluginBootloaderServerInitiateRequestTargetsStatus](#)

[emberAfPluginBootloaderServerInitiateRequestTargetsBootload](#)

[emberAfPluginBootloaderServerGetTargetStatus](#)

[emberAfPluginOtaBootloaderServerAbortCurrentProcess](#)

[EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS](#)

[EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS](#)

[EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS](#)

[EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_BROADCAST_ROUNDS](#)

Ota Broadcast Bootloader Common

[EmberAfOtaBootloaderStatus](#)

[EmberAfOtaBootloaderTargetStatus](#)

[EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_INVALID_APPLICATION_TARGET_STATUS](#)

Poll Plugin

[emberAfPluginPollSetShortPollInterval](#)

[emberAfPluginPollSetLongPollInterval](#)

[emberAfPluginPollEnableShortPolling](#)

WSTK Sensors Plugin

Hardware Abstraction Layer (HAL) API Reference

Hardware Abstraction Layer (HAL)

Common Microcontroller Functions

[RTCCRamData](#)

[outgoingNwkFrameCounter](#)

[incomingParentNwkFrameCounter](#)

[outgoingLinkKeyFrameCounter](#)

[incomingLinkKeyFrameCounter](#)

[SleepModes](#)

[WakeEvents](#)

[WakeMask](#)

[halCommonVreg1v8EnableCount](#)

[halStackProcessBootCount](#)

[halGetResetInfo](#)

[halGetResetString](#)

[halInit](#)

[halReboot](#)

[halPowerUp](#)

[halPowerDown](#)

- halResume
- halSuspend
- halInternalEnableWatchDog
- halInternalDisableWatchDog
- halInternalWatchDogEnabled
- halSleep
- halSleepPreserveInts
- halCommonDelayMicroseconds
- halCommonDisableVreg1v8
- halCommonEnableVreg1v8
- halBeforeEM4
- halAfterEM4
- halGetEm2xxResetInfo
- MICRO_DISABLE_WATCH_DOG_KEY
- GPIO_MASK_SIZE
- GPIO_MASK
- WAKE_GPIO_MASK
- WAKE_GPIO_SIZE
- WAKE_MASK_INVALID
- WAKE_EVENT_SIZE
- DEBUG_TOGGLE

Token Access

Tokens

- halStackInitTokens
- halCommonGetToken
- halCommonGetMfgToken
- halCommonGetIndexedToken
- halCommonSetToken
- halCommonSetIndexedToken
- halCommonIncrementCounterToken

Simulated EEPROM

- halSimEepromCallback
- halSimEepromErasePage
- halSimEepromPagesRemainingToBeErased
- halSimEepromStatus

Sample APIs for Peripheral Access

Serial UART Communication

- halInternalUartInit
- halInternalPowerDownUart
- halInternalPowerUpUart
- halInternalStartUartTx
- halInternalStopUartTx
- halInternalForceWriteUartData
- halInternalForceReadUartByte

halInternalWaitUartTxComplete
halInternalRestartUart
halInternalUartFlowControlRxIsEnabled
halInternalUartXonRefreshDone
halInternalUartTxIsIdle
serialDropPacket
halInternalUartFlowControl
halInternalUartRxPump
halInternalUart1FlowControlRxIsEnabled
halInternalUart1XonRefreshDone
halInternalUart1TxIsIdle
halStackReceiveVuartMessage
EMBER_SERIAL_UNUSED
EMBER_SERIAL_FIFO
EMBER_SERIAL_LOWLEVEL
FIFO_ENQUEUE
FIFO_DEQUEUE
SerialBaudRate
SerialParity
halHostFlushBuffers
halHostEnqueueTx
halHostFlushTx
serialCopyFromRx
emLoadSerialTx
Button Control
BUTTON_PRESSED
BUTTON_RELEASED
halInternalInitButton
halButtonState
halButtonPinState
halButtonIsr
Buzzer Control
LED Control
HalBoardLed
halInternalInitLed
halToggleLed
halSetLed
halClearLed
halStackIndicateActivity
Flash Memory Control
halFlashEraselsActive
System Timer Control
halInternalStartSystemTimer
halCommonGetInt16uMillisecondTick

halCommonGetInt32uMillisecondTick
halCommonGetInt64uMillisecondTick
halCommonGetInt16uQuarterSecondTick
halSleepForQuarterSeconds
halSleepForMilliseconds
halCommonIdleForMilliseconds
halIdleForMilliseconds
Symbol Timer Control
HAL Configuration
Sample Breakout Board Configuration
IAR PLATFORM_HEADER Configuration
boolean
int8u
int8s
int16u
int16s
int32u
int32s
int64u
int64s
PointerType
HAL_HAS_INT64
_HAL_USE_COMMON_PGM_
halInternalAssertFailed
halInternalResetWatchDog
BIGENDIAN_CPU
NTOHS
NTOHL
NO_STRIPPING
EEPROM
__SOURCEFILE__
assert
halResetWatchdog
UNUSED
SIGNED_ENUM
STACK_FILL_VALUE
RAMFUNC
NO_OPERATION
SET_REG_FIELD
SET_CMSIS_REG
SET_CMSIS_REG_FIELD
simulatedTimePasses
simulatedTimePassesMs
simulatedSerialTimePasses

_HAL_USE_COMMON_DIVMOD_
VAR_AT_SEGMENT
STRINGIZE
ALIGNMENT
WEAK
NO_INIT
STATIC_ASSERT
abs
PLATCOMMONOKTOINCLUDE
MAIN_FUNCTION_PARAMETERS
MAIN_FUNCTION_ARGUMENTS
__NO_INIT__
__DEBUG_CHANNEL__
__INTVEC__
__CSTACK__
__RESETINFO__
__DATA_INIT__
__DATA__
__BSS__
__CONST__
__TEXT__
__TEXTRW_INIT__
__TEXTRW__
__AAT__
__BAT__
__BAT_INIT__
__FAT__
__RAT__
__SIMEE__
__PSSTORE__
__LONGTOKEN__
__EMHEAP__
__GUARD_REGION__
__DLIB_PERTHREAD_INIT__
__DLIB_PERTHREAD_INITIALIZED_DATA__
__DLIB_PERTHREAD_ZERO_DATA__
__INTERNAL_STORAGE__
__LOCKBITS_IN_MAINFLASH__
__UNRETAINED_RAM__
_NO_INIT_SEGMENT_BEGIN
_DEBUG_CHANNEL_SEGMENT_BEGIN
_INTVEC_SEGMENT_BEGIN
_CSTACK_SEGMENT_BEGIN
_RESETINFO_SEGMENT_BEGIN

_DATA_INIT_SEGMENT_BEGIN
_DATA_SEGMENT_BEGIN
_BSS_SEGMENT_BEGIN
_CONST_SEGMENT_BEGIN
_TEXT_SEGMENT_BEGIN
_TEXTRW_INIT_SEGMENT_BEGIN
_TEXTRW_SEGMENT_BEGIN
_AAT_SEGMENT_BEGIN
_BAT_SEGMENT_BEGIN
_BAT_INIT_SEGMENT_BEGIN
_FAT_SEGMENT_BEGIN
_RAT_SEGMENT_BEGIN
_SIMEE_SEGMENT_BEGIN
_PSSTORE_SEGMENT_BEGIN
_LONGTOKEN_SEGMENT_BEGIN
_EMHEAP_SEGMENT_BEGIN
_GUARD_REGION_SEGMENT_BEGIN
_DLIB_PERTHREAD_INIT_SEGMENT_BEGIN
_DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_BEGIN
_DLIB_PERTHREAD_ZERO_DATA_SEGMENT_BEGIN
_INTERNAL_STORAGE_SEGMENT_BEGIN
_LOCKBITS_IN_MAINFLASH_SEGMENT_BEGIN
_UNRETAINED_RAM_SEGMENT_BEGIN
_NO_INIT_SEGMENT_END
_DEBUG_CHANNEL_SEGMENT_END
_INTVEC_SEGMENT_END
_CSTACK_SEGMENT_END
_RESETINFO_SEGMENT_END
_DATA_INIT_SEGMENT_END
_DATA_SEGMENT_END
_BSS_SEGMENT_END
_CONST_SEGMENT_END
_TEXT_SEGMENT_END
_TEXTRW_INIT_SEGMENT_END
_TEXTRW_SEGMENT_END
_AAT_SEGMENT_END
_BAT_SEGMENT_END
_BAT_INIT_SEGMENT_END
_FAT_SEGMENT_END
_RAT_SEGMENT_END
_SIMEE_SEGMENT_END
_PSSTORE_SEGMENT_END
_LONGTOKEN_SEGMENT_END
_EMHEAP_SEGMENT_END

_GUARD_REGION_SEGMENT_END
_DLIB_PERTHREAD_INIT_SEGMENT_END
_DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_END
_DLIB_PERTHREAD_ZERO_DATA_SEGMENT_END
_INTERNAL_STORAGE_SEGMENT_END
_LOCKBITS_IN_MAINFLASH_SEGMENT_END
_UNRETAINED_RAM_SEGMENT_END
_NO_INIT_SEGMENT_SIZE
_DEBUG_CHANNEL_SEGMENT_SIZE
_INTVEC_SEGMENT_SIZE
_CSTACK_SEGMENT_SIZE
_RESETINFO_SEGMENT_SIZE
_DATA_INIT_SEGMENT_SIZE
_DATA_SEGMENT_SIZE
_BSS_SEGMENT_SIZE
_CONST_SEGMENT_SIZE
_TEXT_SEGMENT_SIZE
_TEXTRW_INIT_SEGMENT_SIZE
_TEXTRW_SEGMENT_SIZE
_AAT_SEGMENT_SIZE
_BAT_SEGMENT_SIZE
_BAT_INIT_SEGMENT_SIZE
_FAT_SEGMENT_SIZE
_RAT_SEGMENT_SIZE
_SIMEE_SEGMENT_SIZE
_PSSTORE_SEGMENT_SIZE
_LONGTOKEN_SEGMENT_SIZE
_EMHEAP_SEGMENT_SIZE
_GUARD_REGION_SEGMENT_SIZE
_DLIB_PERTHREAD_INIT_SEGMENT_SIZE
_DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_SIZE
_DLIB_PERTHREAD_ZERO_DATA_SEGMENT_SIZE
_INTERNAL_STORAGE_SEGMENT_SIZE
_LOCKBITS_IN_MAINFLASH_SEGMENT_SIZE
_UNRETAINED_RAM_SEGMENT_SIZE
_executeBarrierInstructions

Common PLATFORM_HEADER Configuration

TRUE
FALSE
NULL
BIT
BIT32
SETBIT
SETBITS

CLEARBIT
CLEARBITS
READBIT
READBITS
LOW_BYTE
HIGH_BYTE
HIGH_LOW_TO_INT
INT8U_TO_INT32U
BYTE_0
BYTE_1
BYTE_2
BYTE_3
BYTE_4
BYTE_5
BYTE_6
BYTE_7
COUNTOF
elapsedTimeInt8u
elapsedTimeInt16u
elapsedTimeInt32u
MAX_INT8U_VALUE
HALF_MAX_INT8U_VALUE
timeGTorEqualInt8u
MAX_INT16U_VALUE
HALF_MAX_INT16U_VALUE
timeGTorEqualInt16u
MAX_INT32U_VALUE
HALF_MAX_INT32U_VALUE
timeGTorEqualInt32u
UNUSED_VAR
DEBUG_LEVEL
STATIC_ASSERT
MEMSET
MEMCOPY
MEMMOVE
MEMPGMCOPY
MEMCOMPARE
MEMPGMCOMPARE
NVIC Configuration
Reset Cause Type Definitions
HAL Utilities
Crash and Watchdog Diagnostics
Cyclic Redundancy Code (CRC)
halCommonCrc16

[halCommonCrc32](#)

[INITIAL_CRC](#)

[CRC32_START](#)

[CRC32_END](#)

[Random Number Generation](#)

[halStackSeedRandom](#)

[halCommonGetRandom](#)

[Network to Host Byte Order Conversion](#)

[NTOHS](#)

[NTOHL](#)

[SwapEndiannessInt32u](#)

[HTONL](#)

[HTONS](#)

[Deprecated List](#)

[Connect](#)


[Training](#)

Developing with Connect

Developing Proprietary Connect Applications

Silicon Labs Connect is an IEEE 802.15.4 MAC-based wireless networking stack for a variety of proprietary applications optimized for low-power devices. This full-featured, easily customizable networking stack is designed for compliance with regulatory specifications across worldwide geographic regions and supports both Sub-GHz and 2.4 GHz frequency bands.

The Silicon Labs Connect stack supports many combinations of radio modulation, frequency and data rates. The stack provides support for end nodes, coordinators, and range extenders. It includes all wireless MAC (Medium Access Control) layer functions such as scanning and joining, setting up a point-to-point or star network, and managing device types such as sleepy end devices, routers, and coordinators. With all this functionality already implemented in the stack, users can focus on their end application development and not worry about the lower-level radio and network details.



The Connect stack is part of the Silicon Labs Flex SDK (Software Development Kit), installed through Simplicity Studio. Connect runs on top of RAIL (Radio Abstraction Interface Layer), also included with the Flex SDK. RAIL provides an intuitive, easily-customizable radio interface layer that is designed to support proprietary or standards-based wireless protocols.

The content on these pages is intended for those who want to experiment with or are already developing an application using the Silicon Labs Connect Stack.

For details about this release: Links to the Flex SDK release notes are available on the [silabs.com Gecko SDK page](#).

For Silicon Labs' Connect product information: See the [product pages on silabs.com](#).

For background about the Connect stack and other wireless networking topics: The [Fundamentals section](#) is a good place to start.

To get started with development: See the [Getting Started section](#) to get started working with example applications.

If you are already in development: See the [Developer's Guide](#) for details or go directly to the [API Reference](#).

Overview

Getting Started with Silicon Labs Connect Development

To get started with Silicon Labs Connect development, download the Simplicity Studio Development environment as described in the [Simplicity Studio 5 User's Guide](#).

This will also prompt you to install the Gecko SDK (GSDK). The GSDK combines Silicon Labs wireless software development kits (SDKs) such as the Flex SDK and Gecko Platform into a single, integrated package. The GSDK is your primary tool for developing in the Silicon Labs IoT Software ecosystem. All of Silicon Labs' stacks are written in-house to provide a seamless experience from silicon to tools, allowing you to unlock powerful features with ease, including:

- Abstraction of complex requirements like multiprotocol and pre-certification
- Industry-leading ability to support a large number of nodes
- Ultra-low power consumption
- Strong network reliability

Silicon Labs also helps future-proof your devices with over-the-air software and security updates, helping to minimize maintenance cost and improve your end user product experience!

The Flex SDK includes both the Connect library and examples and the RAIL (Radio Abstraction Interface Layer) Library and examples. Once you have downloaded Simplicity Studio and the GSDK, detailed instructions for using the Connect examples and configuration tools are provided in the [Proprietary Flex SDK Quick-Start Guide \(QSG168\)](#).

Note: The recommended method to get started with the GSDK is to first install Simplicity Studio 5, which will set up your development environment and walk you through the GSDK installation. Alternatively, GSDK and other required tools may be installed manually from the [GitHub GSDK site](#).

Overview

Connect Fundamentals

Silicon Labs has produced a series of documents on topics that provide useful background for Silicon Labs Connect developers.

- [Silicon Labs Connect Fundamentals \(PDF\)](#): Describes the features and functions of the Silicon Labs Connect stack, including its device types, network topologies, and its 'building block' development methodology using components.
- [Using Silicon Labs Connect v3.x with IEEE 802.15.4 \(PDF\)](#): Introduces the IEEE 802.15.4 standard on which Connect v3.x is based.
- [Wireless Networking Application Development Fundamentals \(PDF\)](#): For those new to wireless networking, introduces some fundamental concepts of wireless networking.

Overview

Connect Developers Guide

The Developer's Guide content is organized in the following groups:

- [Developing and Debugging](#): A description of development resources as well as detailed information on a variety of topics.
- [Bootloading](#): Information on using the Gecko Bootloader with Connect applications.
- [Multiprotocol](#): Background on implementing multiprotocol applications and information on different multiprotocol models.
- [Non-Volatile Data Storage](#): Background on managing device memory.
- [Security](#): Describes Silicon Labs security resources and how to manage Connect security.

Overview

Developing and Debugging Connect Applications

These pages provide details on developing and debugging applications using the Connect stack. Content includes:

- [Architecture of the Silicon Labs Connect Stack v3.x \(PDF\)](#): Describes the architecture of the Silicon Labs Connect stack v3.x and how it implements IEEE 802.15.4.
- [Customizing Applications with Silicon Labs Connect v3.x \(PDF\)](#): Describes how to use components, callbacks, and events on top of the Gecko Platform application framework to configure features and application behavior.
- [Network Co-Processor Applications with Silicon Labs Connect v3.x \(PDF\)](#): Describes how to run the Silicon Labs Connect stack in Network Co-Processor (NCP) mode, where the NCP runs on the EFR32 while the Host application and the Co-processor Communication daemon (CPCd) run on the Host device.
- [Using Real Time Operating Systems with Silicon Labs Connect v3.x \(PDF\)](#): Describes the process to implement a Connect-based application on top of one of the supported Real Time Operating Systems (RTOS).
- [Energy Saving with Silicon Labs Connect v3.x \(PDF\)](#): Describes the features available in Connect v3.x to reduce power consumption. Using those features is described in AN1252: Building Low Power Networks with the Silicon Labs Connect Stack v3.x.
- [Building Low Power Networks with the Silicon Labs Connect Stack v3.x \(PDF\)](#): Illustrates reducing power consumption in a Connect v3.x application using the sensor example.
- [EFR32 Radio Configurator Guide for Simplicity Studio 5 \(PDF\)](#): Documents the Radio Configurator tool, which can be used to create customizations at the PHY level.
- [PHY Limitations and Timing Optimization](#): Connect specific recommendations on radio config customizations.

Development Tools

Simplicity Studio and the Simplicity IDE: Simplicity Studio is the unified development environment for all Silicon Labs technologies, SoCs, and modules. It provides you with access to the target device-specific web and SDK resources, software and hardware configuration tools, and an integrated development environment (IDE) featuring industry-standard code editors, compilers, and debuggers. See [the silabs.com Simplicity Studio page](#) to download the tools and for more information.

Network Analyzer: Simplicity Studio® 5 (SSv5)'s Network Analyzer enables debugging of complex wireless systems. This tool captures a trace of wireless network activity that can be examined in detail live or at a later time. See the [Network Analyzer section](#) of the Simplicity Studio 5 User's Guide for more information.

Wireshark: Wireshark is the recommended network protocol analyzer for the use with Wi-SUN networks. Download instructions are provided for [Windows/Mac users](#) or [Linux users](#). Simplicity Studio® 5 supports [live interaction](#) between the application running on a Silicon Labs device and Wireshark.

Energy Profiler: Simplicity Studio® 5 (SSv5)'s Energy Profiler enables you to visualize the energy consumption of individual devices, multiple devices on one target system, or a network of interacting wireless devices to analyze and improve the power performance of these systems. Real-time information on current consumption is correlated with the program counter providing advanced energy software monitoring capabilities. It also provides a basic level of integration with the Network Analyzer network analysis tool. See the [Energy Profiler section](#) of the Simplicity Studio 5 User's Guide for more information.

Simplicity Commander: Simplicity Commander is a single, all-purpose tool to be used in a production environment. It is invoked using a simple Command Line Interface (CLI) that is also scriptable. Simplicity Commander enables customers to complete essential tasks such as configuring and building applications and bootloaders and flashing images to their devices. Simplicity Commander is available through Simplicity Studio or can be downloaded through [system-specific installers](#). The [Simplicity Commander User's Guide](#) provides more information.

Silicon Labs Configurator (SLC): SLC offers command-line access to application configuration and generation functions. [Software Project Generation and Configuration with SLC-CLI](#) provides instructions on downloading and using the SLC-CLI tool.

PHY Limitations and Timing Optimization

PHY Limitations and Timing Optimization

Supported profiles

Connect supports a wide range of radio configurations, including pre-configured and customized PHYs. The pre-configured PHYs are under the following profiles:

- Connect Profile
- Connect OFDM Profile
- Long Range Profile

Under these profiles, any customization is supported by Connect. Note, however, that using the radio configurator requires basic knowledge of digital modulations. It is possible to misconfigure modulation parameters to the level where communication might be impossible.

Base Profile

The Base profile allows the widest configuration options. However, Connect is only compatible with the IEEE 802.15.4 frame configuration. For the modulations available in the Base Profile, Connect only supports 1 Byte PHR frame configurations. To set this up, follow these settings:

- Check Header Enable
- Set Header Size to 1
- Set Frame Length Encoding to VARIABLE_LENGTH
- Set Frame Bit Endian to LSB_FIRST
- Check Length Includes CRC Bytes
- Set Minimum Length to 0
- Set Maximum Length to 127
- Set Variable Length Bit Size to 7
- Set Variable Frame Length Adjust to 0
- Set Variable Length Bit Endian to LSB_FIRST
- Set Variable Length Bit Location to 0

The frame setting also requires a 2 Byte long CRC, so make sure to select a 2 Byte long CRC Polynomial.

Although Connect can handle 2 Byte PHR and the PHR required for OFDM, those settings can only be activated by selecting a PHY from the Connect profiles.

OFDM Settings

The Connect OFDM PHYs are essentially same as Wi-SUN OFDM PHYs. However, without the limitation of the Wi-SUN spec, we allow changing the channel map and carrier frequency.

OFDM bitrate depends on bandwidth and MCS (modulation coding scheme). The bandwidth can be configured on the radio configurator, while MCS can be changed run-time, with the `emberOfdmSetMcs()` API. The default MCS is 0.

The available bitrates in kb/s, depending on bandwidth and MCS:

	0.2 MHz	0.4 MHz	0.8 MHz	1.2 MHz
MCS=0	12.5	25	50	100
MCS=1	25	50	100	200

	0.2 MHz	0.4 MHz	0.8 MHz	1.2 MHz
MCS=2	50	100	200	400
MCS=3	100	200	400	800
MCS=4	150	300	600	1200
MCS=5	200	400	800	1600
MCS=6	300	600	1200	2400

Multi-PHY Considerations

Connect has limited support for the Multi-PHY capabilities of EFR32. Channel-based Multi-PHY (i.e., configuration changes are applied by changing the channel) is fully supported. However, Connect always loads the first protocol in a protocol-based Multi-PHY configuration. For more details on this term, see [AN1253 \(PDF\)](#).

Optimizing Connect for a PHY

Although Connect is set up to be usable with a wide range of PHYs, there are certain features that depend on the PHY. These are usually configured conservatively, so it will probably work with most configurations, but not all. Furthermore, even if it works, it might be necessary to optimize these parameters for more effective operation.

CSMA/CA

The default configuration in Connect follows the recommendation from IEEE 802.15.4. All timing parameters are symbolrate dependent, while the threshold is -65dBm. All of the parameters can be changed via `emberSetMacParams()`. These parameters very rarely need modification. Perhaps, on a very low symbolrate, it is worth setting an overall timeout via `csmaTimeout`.

Turnaround Time and Acknowledgement Timeout

Turnaround time (delay between received packet and transmitted acknowledgement) in Connect is not configurable; it is always 12 symbol time.

Acknowledgement timeout by default is 25ms. This is much more than most PHY needs. Turnaround time + acknowledgement frame transmission time should be enough in theory. This can be tuned via `emberSetMacParams()`, with the `ackTimeout` argument.

Note though that in practice, optimizing the timeout doesn't improve efficiency much. The timeout only blocks the stack to transmit another packet while waiting on the acknowledgement.

Active Scan Duration

Active scan is used when a device joins a network. The joining device sends a beacon request, and waits a predefined duration for beacons of the joinable devices. This is the active scan duration, which is $960 \times 2^5 = 30720$ symbol time by default. This is however way too much for low bitrate; e.g. at 9.6kbps, this results in 3.2s.

This can be configured via `emberSetActiveScanDuration()`. The beacons are transmitted with a 50ms jitter after the beacon request frame (with additional delay caused by CSMA/CA).

Overview

Bootloading Embedded Applications

Bootloading allows you to update application firmware images on your devices. This section provides background information about bootloading using the Silicon Labs Gecko Bootloader.

- [Bootloader Fundamentals \(PDF\)](#): Bootloader Fundamentals - Introduces bootloading for Silicon Labs networking devices. Discusses the Gecko Bootloader as well as legacy Ember and Bluetooth bootloaders, and describes the file formats used by each.
- [Bootloading and OTA with Silicon Labs Connect v3.x \(PDF\)](#): Explains standalone (serial) and application (OTA) bootloader options available for use within Connect v3.x-based applications.
- [Using the Gecko Bootloader with Silicon Labs Connect \(PDF\)](#): Includes detailed information on using the Silicon Labs Gecko Bootloader with Connect. It supplements the general Gecko Bootloader implementation information provided in UG489: Silicon Labs Gecko Bootloader User's Guide for GSDK 4.0 and Higher.
- [Gecko Bootloader User's Guide for GSDK 4.0 and Higher \(PDF\)](#): Describes the high-level implementation of the Silicon Labs Gecko Bootloader for EFR32 SoCs and NCPs, and provides information on how to get started using the Gecko Bootloader with Silicon Labs wireless protocol stacks in GSDK 4.0 and higher.
- [Series 2 Secure Boot with RTSL \(PDF\)](#): Contains detailed information on configuring and using the Secure Boot with hardware Root of Trust and Secure Loader on Series 2 devices, including how to provision the signing key. This is a companion document to UG266: Silicon Labs Gecko Bootloader User's Guide.
- [Transitioning to the Updated Gecko Bootloader in GSDK 4.0 and Higher \(PDF\)](#): Gecko Bootloader v2.x, introduced in GSDK 4.0, contains a number of changes compared to Gecko Bootloader v1.x. This document describes the differences between the versions, including how to configure the new Gecko Bootloader in Simplicity Studio 5.

Overview

Multiprotocol

This section provides background information on multiprotocol applications.

- [Multiprotocol Fundamentals \(PDF\)](#): Describes the four multiprotocol modes, discusses considerations when selecting protocols for multiprotocol implementations, and reviews the Radio Scheduler, a required component of a dynamic multiprotocol solution.
- [Dynamic Multiprotocol User's Guide \(PDF\)](#): Describes how to implement a dynamic multiprotocol solution.

Overview

Non-Volatile Data Storage

This section offers an introduction to non-volatile data storage and describes how to use NVM3 data storage.

- [Non-Volatile Data Storage Fundamentals \(PDF\)](#): Introduces non-volatile data storage using flash and the three different storage implementations offered for Silicon Labs microcontrollers and SoCs: Simulated EEPROM, PS Store, and NVM3.
- [Using Third Generation Non-Volatile Memory \(NVM3\) Data Storage \(PDF\)](#): Explains how NVM3 can be used as non-volatile data storage in various protocol implementations.
- [Bringing Up Custom Devices for the EFR32MG and EFR32FG Families \(PDF\)](#): Describes how to initialize a piece of custom hardware (a 'device') based on the EFR32MG and EFR32FG families so that it interfaces correctly with a network stack. The same procedures can be used to restore devices whose settings have been corrupted or erased.
- [Using Tokens for Non-Volatile Data Storage \(PDF\)](#): Describes tokens and shows how to use them for non-volatile data storage in EmberZNet PRO and Silicon Labs Flex applications.

Overview

Security

Silicon Labs offers a range of security features depending on the part you are using and your application and production needs. This section provides background on security and how to use the available security features.

- [IoT Security Fundamentals \(PDF\)](#): Introduces the security concepts that must be considered when implementing an Internet of Things (IoT) system. Using the ioXt Alliance's eight security principles as a structure, it clearly delineates the solutions Silicon Labs provides to support endpoint security and what you must do outside of the Silicon Labs framework.
- [Series 2 Secure Debug \(PDF\)](#): Describes how to lock and unlock the debug access of EFR32 Gecko Series 2 devices. Many aspects of the debug access, including the secure debug unlock are described. The Debug Challenge Interface (DCI) and Secure Engine (SE) Mailbox Interface for locking and unlocking debug access are also included.
- [Production Programming of Series 2 Devices \(PDF\)](#): Provides details on programming, provisioning, and configuring Series 2 devices in production environments. Covers Secure Engine Subsystem of Series 2 devices, which runs easily upgradeable Secure Engine (SE) or Virtual Secure Engine (VSE) firmware.
- [Anti-Tamper Protection Configuration and Use \(PDF\)](#): Anti-Tamper Protection Configuration and Use - Shows how to program, provision, and configure the anti-tamper module on EFR32 Series 2 devices with Secure Vault.
- [Authenticating Silicon Labs Devices using Device Certificates \(PDF\)](#): How to authenticate an EFR32 Series 2 device with Secure Vault, using secure device certificates and signatures.
- [Secure Key Storage \(PDF\)](#): Explains how to securely "wrap" keys in EFR32 Series 2 devices with Secure Vault, so they can be stored in non-volatile storage.
- [Programming Series 2 Devices Using the Debug Challenge Interface \(DCI\) and Serial Wire Debug \(SWD\) \(PDF\)](#): Describes how to provision and configure Series 2 devices through the DCI and SWD.
- [Integrating Crypto Functionality Using PSA Crypto Compared to Mbed TLS \(PDF\)](#): Describes how to integrate crypto functionality into applications using PSA Crypto compared to Mbed TLS.

Connect

Connect

Silicon Labs Connect Stack API

Connect stack API is the primary Application Programming Interface (API) for applications running on Silicon Labs EFR32 Wireless Gecko SoCs to interact with the Silicon Labs Connect wireless stack.

Silicon Labs is developing products designed to meet the demands of customers moving to a connected world of devices in the home, often referred to as the IoT (Internet of Things). At a high level, the IoT goals for Silicon Labs are as follows:

- Connect all devices in the home with best-in-class mesh networking, either with Ember ZigBee PRO or other emerging standards.
- Leverage the company expertise in low-power, constrained devices.
- Enhance established low-power, mixed-signal chips.
- Provide low-cost bridging to existing Ethernet and Wi-Fi devices.
- Enable cloud services and connectivity to smartphones and tablets that promote ease of use and a common user experience for customers.

Connect Stack API Reference

Connect Stack API Reference

The primary API towards the Connect radio stack.

Modules

[Connect Stack Version](#)

[Connect Data Types](#)

[Stack Information](#)

[Network Management](#)

[Radio Stream](#)

[Configuration](#)

[Status Codes](#)

[Stack Tokens](#)

[Event Scheduling](#)

[Memory Buffer](#)

Connect Stack Version

Connect Stack Version

Macros to determine the stack version.

Note that the Connect Stack version might not match the version of Flex SDK.

See [config.h](#) for source code.

Macros

<code>#define</code>	<code>EMBER_MAJOR_VERSION</code>	<code>4</code>	The major version of the release. First digit of A.B.C.D.
<code>#define</code>	<code>EMBER_MINOR_VERSION</code>	<code>0</code>	The minor version of the release. Second digit of A.B.C.D.
<code>#define</code>	<code>EMBER_PATCH_VERSION</code>	<code>1</code>	The patch version of the release. Third digit of A.B.C.D.
<code>#define</code>	<code>EMBER_SPECIAL_VERSION</code>	<code>0</code>	Special version of the release. Fourth digit of A.B.C.D.
<code>#define</code>	<code>EMBER_BUILD_NUMBER</code>	<code>0</code>	Build number of the release. Should be stored on 2 bytes.
<code>#define</code>	<code>EMBER_FULL_VERSION</code>	<code>undefined</code>	Full version number stored on 2 bytes, with each of the four digits stored on 4 bits.
<code>#define</code>	<code>EMBER_VERSION_TYPE</code>	<code>EMBER_VERSION_TYPE_GA</code>	Version type of the release. <code>EMBER_VERSION_TYPE_GA</code> means generally available.
<code>#define</code>	<code>SOFTWARE_VERSION</code>	<code>EMBER_FULL_VERSION</code>	Full version number stored on 2 bytes, with each of the four digits stored on 4 bits.

Macro Definition Documentation

EMBER_MAJOR_VERSION

```
#define EMBER_MAJOR_VERSION
```

Value:

4

The major version of the release. First digit of A.B.C.D.

Definition at line `43` of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h`

EMBER_MINOR_VERSION

```
#define EMBER_MINOR_VERSION
```

Value:

0

The minor version of the release. Second digit of A.B.C.D.

Definition at line 48 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

EMBER_PATCH_VERSION

```
#define EMBER_PATCH_VERSION
```

Value:

1

The patch version of the release. Third digit of A.B.C.D.

Patch versions are fully backwards compatible as long as the major and minor version matches.

Definition at line 56 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

EMBER_SPECIAL_VERSION

```
#define EMBER_SPECIAL_VERSION
```

Value:

0

Special version of the release. Fourth digit of A.B.C.D.

Definition at line 61 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

EMBER_BUILD_NUMBER

```
#define EMBER_BUILD_NUMBER
```

Value:

0

Build number of the release. Should be stored on 2 bytes.

Definition at line 66 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

EMBER_FULL_VERSION

```
#define EMBER_FULL_VERSION
```

Value:

```
0 | ((uint16_t)EMBER_MAJOR_VERSION << 12) \
0 | ((uint16_t)EMBER_MINOR_VERSION << 8) \
0 | ((uint16_t)EMBER_PATCH_VERSION << 4) \
0 | ((uint16_t)EMBER_SPECIAL_VERSION)
```

Full version number stored on 2 bytes, with each of the four digits stored on 4 bits.

Definition at line 72 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

EMBER_VERSION_TYPE

```
#define EMBER_VERSION_TYPE
```

Value:

```
EMBER_VERSION_TYPE_GA
```

Version type of the release. EMBER_VERSION_TYPE_GA means generally available.

Definition at line 81 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

SOFTWARE_VERSION

```
#define SOFTWARE_VERSION
```

Value:

```
EMBER_FULL_VERSION
```

Full version number stored on 2 bytes, with each of the four digits stored on 4 bits.

Definition at line 86 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/config.h

Connect Data Types

Connect Data Types

Definitions of Connect data types used by various Connect API functions.

See [ember-types.h](#) for source code.

Modules

[EmberNetworkParameters](#)

[EmberIncomingMessage](#)

[EmberOutgoingMessage](#)

[EmberMacAddress](#)

[EmberMacFrame](#)

[EmberIncomingMacMessage](#)

[EmberOutgoingMacMessage](#)

[EmberKeyData](#)

[EventActions](#)

[Event_s](#)

[EventQueue_s](#)

[EmberEventControl](#)

[EmberEventData_s](#)

[EmberTaskControl](#)

Enumerations

```
enum EmberNodeType {  
    EMBER_UNKNOWN_DEVICE = 0  
    EMBER_STAR_COORDINATOR = 1  
    EMBER_STAR_RANGE_EXTENDER = 2  
    EMBER_STAR_END_DEVICE = 3  
    EMBER_STAR_SLEEPY_END_DEVICE = 4  
    EMBER_DIRECT_DEVICE = 5  
    EMBER_MAC_MODE_DEVICE = 6  
    EMBER_MAC_MODE_SLEEPY_DEVICE = 7  
}
```

Define the possible types of nodes and the roles that a node might play in a network.

```
enum EmberNetworkStatus {  
    EMBER_NO_NETWORK  
    EMBER_JOINING_NETWORK  
    EMBER_JOINED_NETWORK  
    EMBER_RADIO_TEST
```

```
}
```

Defines the possible join states for a node.

```
enum EmberChildFlags {  
    EMBER_CHILD_FLAGS_DEVICE_IS_RANGE_EXTENDER_BIT = 0x02  
    EMBER_CHILD_FLAGS_DEVICE_IS_SLEEPY_BIT = 0x04  
    EMBER_CHILD_FLAGS_HAVE_PENDING_DATA_BIT = 0x08  
    EMBER_CHILD_FLAGS_AES_SECURITY_CAPABLE_BIT = 0x10  
    EMBER_CHILD_FLAG_DEVICE_IS_EXTENDED_BIT = 0x20  
}  
Child flags.
```

```
enum EmberMessageOptions {  
    EMBER_OPTIONS_NONE = 0x00  
    EMBER_OPTIONS_SECURITY_ENABLED = 0x01  
    EMBER_OPTIONS_ACK_REQUESTED = 0x02  
    EMBER_OPTIONS_HIGH_PRIORITY = 0x04  
    EMBER_OPTIONS_INDIRECT = 0x08  
}  
Message options.
```

```
enum EmberMacAddressMode {  
    EMBER_MAC_ADDRESS_MODE_NONE = 0x00  
    EMBER_MAC_ADDRESS_MODE_SHORT = 0x02  
    EMBER_MAC_ADDRESS_MODE_LONG = 0x03  
}  
802.15.4 addressing mode.
```

```
enum EmberEventUnits {  
    EMBER_EVENT_INACTIVE = 0  
    EMBER_EVENT_MS_TIME  
    EMBER_EVENT_QS_TIME  
    EMBER_EVENT_MINUTE_TIME  
    EMBER_EVENT_ZERO_DELAY  
}  
Either marks an event as inactive or specifies the units for the event execution time.
```

```
enum @2 {  
    EMBER_OUTGOING_MESSAGES = 0x0001  
    EMBER_INCOMING_MESSAGES = 0x0002  
    EMBER_RADIO_IS_ON = 0x0004  
    EMBER_ASSOCIATING = 0x0008  
    EMBER_SCANNING = 0x0010  
}  
Define tasks that prevent the stack from sleeping.
```

```
enum EmberCounterType {
    EMBER_COUNTER_PHY_IN_PACKETS
    EMBER_COUNTER_PHY_OUT_PACKETS
    EMBER_COUNTER_MAC_IN_UNICAST
    EMBER_COUNTER_MAC_IN_BROADCAST
    EMBER_COUNTER_MAC_OUT_UNICAST_NO_ACK
    EMBER_COUNTER_MAC_OUT_UNICAST_ACK_SUCCESS
    EMBER_COUNTER_MAC_OUT_UNICAST_ACK_FAIL
    EMBER_COUNTER_MAC_OUT_UNICAST_CCA_FAIL
    EMBER_COUNTER_MAC_OUT_UNICAST_RETRY
    EMBER_COUNTER_MAC_OUT_BROADCAST
    EMBER_COUNTER_MAC_OUT_BROADCAST_CCA_FAIL
    EMBER_COUNTER_MAC_OUT_ENCRYPT_FAIL
    EMBER_COUNTER_MAC_DROP_IN_MEMORY
    EMBER_COUNTER_MAC_DROP_IN_FRAME_COUNTER
    EMBER_COUNTER_MAC_DROP_IN_DECRYPT
    EMBER_COUNTER_NWK_OUT_FORWARDING
    EMBER_COUNTER_NWK_IN_SUCCESS
    EMBER_COUNTER_NWK_DROP_IN_WRONG_SOURCE
    EMBER_COUNTER_NWK_DROP_IN_FORWARDING
    EMBER_COUNTER_UART_IN_DATA
    EMBER_COUNTER_UART_IN_MANAGEMENT
    EMBER_COUNTER_UART_IN_FAIL
    EMBER_COUNTER_UART_OUT_DATA
    EMBER_COUNTER_UART_OUT_MANAGEMENT
    EMBER_COUNTER_UART_OUT_FAIL
    EMBER_COUNTER_ROUTE_2_HOP_LOOP
    EMBER_COUNTER_BUFFER_ALLOCATION_FAIL
    EMBER_ASH_V3_ACK_SENT
    EMBER_ASH_V3_ACK_RECEIVED
    EMBER_ASH_V3_NACK_SENT
    EMBER_ASH_V3_NACK_RECEIVED
    EMBER_ASH_V3_RESEND
    EMBER_ASH_V3_BYTES_SENT
    EMBER_ASH_V3_TOTAL_BYTES_RECEIVED
    EMBER_ASH_V3_VALID_BYTES_RECEIVED
    EMBER_ASH_V3_PAYLOAD_BYTES_SENT
    EMBER_COUNTER_TYPE_COUNT
}

```

Define the event counters that can be requested from the application using `emberGetCounter()`

```
enum EmberPhyType {
    EMBER_RADIO_CONFIGURATOR
    EMBER_STANDARD_PHY_2_4GHZ
    EMBER_STANDARD_PHY_915MHZ
    EMBER_STANDARD_PHY_863MHZ
}

```

Define the PHY configuration of connect stack.

```
enum EmberCalType {
    EMBER_CAL_TEMP_VCO = 0x00000001
    EMBER_CAL_IRCAL = 0x00010000
    EMBER_CAL_ALL = 0x00010001
}

```

Define the type of calibration requested.

```
enum EmberTxStreamParameters {
    TX_STREAM_PN9
    TX_STREAM_CW
}

```

Radio Stream mode.

Typedefs

typedef uint8_t	EmberEUI64[EUI64_SIZE] EUI 64-bit ID (IEEE 802.15.4 long address).
typedef uint16_t	EmberNodeId IEEE 802.15.4 node ID. Also known as short address.
typedef uint16_t	EmberPanId IEEE 802.15.4 PAN ID.
typedef uint16_t	EmberMessageLength Message length in bytes.
typedef uint8_t	EmberTaskId An identifier for a task.
typedef struct Event_s	Event
typedef struct EventQueue_s	EventQueue An event queue is currently just a list of events ordered by execution time.
typedef const struct EmberEventData_ S	EmberEventData Complete events with a control and a handler procedure.
typedef uint16_t	EmberBuffer Buffers used by the memory buffer system.

Functions

uint8_t *	emberKeyContents(EmberKeyData *key) This macro allows the programmer to gain access to the key data bytes of the EmberKeyData structure.
-----------	---

Macros

#define	EXTENDED_PAN_ID_SIZE 8 Size of an extended PAN identifier in bytes (8).
#define	EUI64_SIZE 8 Size of EUI64 (an IEEE address) in bytes (8).
#define	EMBER_ENCRYPTION_KEY_SIZE 16 Size of an encryption key in bytes (16).
#define	EMBER_NULL_NODE_ID 0xFFFFu A distinguished network ID that will never be assigned to any node. Used to indicate the absence of a node ID.
#define	EMBER_BROADCAST_ADDRESS 0xFFFF Broadcast address.
#define	EMBER_USE_LONG_ADDRESS 0xFFFE Special short address indicating the node should use long addressing as source address.
#define	EMBER_COORDINATOR_ADDRESS 0x0000 The coordinator short address.
#define	EMBER_CAL_INVALID_VALUE (0xFFFFFFFF)

Enumeration Documentation

EmberNodeType

EmberNodeType

Define the possible types of nodes and the roles that a node might play in a network.

Enumerator

EMBER_UNKNOWN_DEVICE	
EMBER_STAR_COORDINATOR	
EMBER_STAR_RANGE_EXTENDER	
EMBER_STAR_END_DEVICE	
EMBER_STAR_SLEEPY_END_DEVICE	
EMBER_DIRECT_DEVICE	
EMBER_MAC_MODE_DEVICE	
EMBER_MAC_MODE_SLEEPY_DEVICE	

Definition at line 106 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberNetworkStatus

EmberNetworkStatus

Defines the possible join states for a node.

Enumerator

EMBER_NO_NETWORK	
EMBER_JOINING_NETWORK	
EMBER_JOINED_NETWORK	
EMBER_RADIO_TEST	

Definition at line 162 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberChildFlags

EmberChildFlags

Child flags.

Enumerator

EMBER_CHILD_FLAGS_DEVICE_IS_RANGE_EXTENDER_BIT	
EMBER_CHILD_FLAGS_DEVICE_IS_SLEEPY_BIT	
EMBER_CHILD_FLAGS_HAVE_PENDING_DATA_BIT	
EMBER_CHILD_FLAGS_AES_SECURITY_CAPABLE_BIT	
EMBER_CHILD_FLAG_DEVICE_IS_EXTENDED_BIT	

Definition at line 198 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberMessageOptions

EmberMessageOptions

Message options.

Enumerator

EMBER_OPTIONS_NONE	
EMBER_OPTIONS_SECURITY_ENABLED	
EMBER_OPTIONS_ACK_REQUESTED	
EMBER_OPTIONS_HIGH_PRIORITY	
EMBER_OPTIONS_INDIRECT	

Definition at line 225 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberMacAddressMode

EmberMacAddressMode

802.15.4 addressing mode.

Enumerator

EMBER_MAC_ADDRESS_MODE_NONE	
EMBER_MAC_ADDRESS_MODE_SHORT	
EMBER_MAC_ADDRESS_MODE_LONG	

Definition at line 338 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberEventUnits

EmberEventUnits

Either marks an event as inactive or specifies the units for the event execution time.

Enumerator

EMBER_EVENT_INACTIVE	
EMBER_EVENT_MS_TIME	
EMBER_EVENT_QS_TIME	
EMBER_EVENT_MINUTE_TIME	
EMBER_EVENT_ZERO_DELAY	

Definition at line 521 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

@2

@2

Define tasks that prevent the stack from sleeping.

Enumerator

EMBER_OUTGOING_MESSAGES	
EMBER_INCOMING_MESSAGES	
EMBER_RADIO_IS_ON	

```
EMBER_ASSOCIATING
EMBER_SCANNING
```

Definition at line 623 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberCounterType

```
EmberCounterType
```

Define the event counters that can be requested from the application using [emberGetCounter\(\)](#)

Enumerator

```
EMBER_COUNTER_PHY_IN_PACKETS
EMBER_COUNTER_PHY_OUT_PACKETS
EMBER_COUNTER_MAC_IN_UNICAST
EMBER_COUNTER_MAC_IN_BROADCAST
EMBER_COUNTER_MAC_OUT_UNICAST_NO_ACK
EMBER_COUNTER_MAC_OUT_UNICAST_ACK_SUCCESS
EMBER_COUNTER_MAC_OUT_UNICAST_ACK_FAIL
EMBER_COUNTER_MAC_OUT_UNICAST_CCA_FAIL
EMBER_COUNTER_MAC_OUT_UNICAST_RETRY
EMBER_COUNTER_MAC_OUT_BROADCAST
EMBER_COUNTER_MAC_OUT_BROADCAST_CCA_FAIL
EMBER_COUNTER_MAC_OUT_ENCRYPT_FAIL
EMBER_COUNTER_MAC_DROP_IN_MEMORY
EMBER_COUNTER_MAC_DROP_IN_FRAME_COUNTER
EMBER_COUNTER_MAC_DROP_IN_DECRYPT
EMBER_COUNTER_NWK_OUT_FORWARDING
EMBER_COUNTER_NWK_IN_SUCCESS
EMBER_COUNTER_NWK_DROP_IN_WRONG_SOURCE
EMBER_COUNTER_NWK_DROP_IN_FORWARDING
EMBER_COUNTER_UART_IN_DATA
EMBER_COUNTER_UART_IN_MANAGEMENT
EMBER_COUNTER_UART_IN_FAIL
EMBER_COUNTER_UART_OUT_DATA
EMBER_COUNTER_UART_OUT_MANAGEMENT
EMBER_COUNTER_UART_OUT_FAIL
EMBER_COUNTER_ROUTE_2_HOP_LOOP
EMBER_COUNTER_BUFFER_ALLOCATION_FAIL
EMBER_ASH_V3_ACK_SENT
EMBER_ASH_V3_ACK_RECEIVED
EMBER_ASH_V3_NACK_SENT
EMBER_ASH_V3_NACK_RECEIVED
EMBER_ASH_V3_RESEND
EMBER_ASH_V3_BYTES_SENT
EMBER_ASH_V3_TOTAL_BYTES_RECEIVED
EMBER_ASH_V3_VALID_BYTES_RECEIVED
EMBER_ASH_V3_PAYLOAD_BYTES_SENT
EMBER_COUNTER_TYPE_COUNT
```

Definition at line 646 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberPhyType

EmberPhyType

Define the PHY configuration of connect stack.

Enumerator

EMBER_RADIO_CONFIGURATOR	
EMBER_STANDARD_PHY_2_4GHZ	
EMBER_STANDARD_PHY_915MHZ	
EMBER_STANDARD_PHY_863MHZ	

Definition at line 765 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberCalType

EmberCalType

Define the type of calibration requested.

Enumerator

EMBER_CAL_TEMP_VCO	
EMBER_CAL_IRCAL	
EMBER_CAL_ALL	

Definition at line 788 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberTxStreamParameters

EmberTxStreamParameters

Radio Stream mode.

Enumerator

TX_STREAM_PN9	
TX_STREAM_CW	

Definition at line 874 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

Typedef Documentation

EmberEUI64

```
typedef uint8_t EmberEUI64[EUI64_SIZE] [EUI64_SIZE]
```

EUI 64-bit ID (IEEE 802.15.4 long address).

Definition at line 73 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberNodeId

```
typedef uint16_t EmberNodeId
```

IEEE 802.15.4 node ID. Also known as short address.

Definition at line 78 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberPanId

```
typedef uint16_t EmberPanId
```

IEEE 802.15.4 PAN ID.

Definition at line 83 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberMessageLength

```
typedef uint16_t EmberMessageLength
```

Message length in bytes.

Definition at line 219 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberTaskId

```
typedef uint8_t EmberTaskId
```

An identifier for a task.

Definition at line 540 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

Event

```
typedef struct Event_s Event
```

Definition at line 567 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EventQueue

```
typedef struct EventQueue_s EventQueue
```

An event queue is currently just a list of events ordered by execution time.

Definition at line 575 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberEventData

```
typedef const struct EmberEventData_S EmberEventData
```

Complete events with a control and a handler procedure.

An application typically creates an array of events along with their handlers. The main loop passes the array to [emberRunEvents\(\)](#) to call the handlers of any events whose time has arrived.

Definition at line 606 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberBuffer

```
typedef uint16_t EmberBuffer
```

Buffers used by the memory buffer system.

Definition at line 759 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

Function Documentation

emberKeyContents

```
uint8_t * emberKeyContents (EmberKeyData *key)
```

This macro allows the programmer to gain access to the key data bytes of the [EmberKeyData](#) structure.

Parameters

[in]	key	A Pointer to an EmberKeyData structure.
------	-----	---

Returns

- uint8_t* Returns a pointer to the first byte of the key data.

Definition at line 511 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

Macro Definition Documentation

EXTENDED_PAN_ID_SIZE

```
#define EXTENDED_PAN_ID_SIZE
```

Value:

```
8
```

Size of an extended PAN identifier in bytes (8).

Definition at line 58 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EUI64_SIZE

```
#define EUI64_SIZE
```

Value:

```
8
```

Size of EUI64 (an IEEE address) in bytes (8).

Definition at line 63 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_ENCRYPTION_KEY_SIZE

```
#define EMBER_ENCRYPTION_KEY_SIZE
```

Value:

```
16
```

Size of an encryption key in bytes (16).

Definition at line 68 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_NULL_NODE_ID

```
#define EMBER_NULL_NODE_ID
```

Value:

```
0xFFFFu
```

A distinguished network ID that will never be assigned to any node. Used to indicate the absence of a node ID.

Definition at line 89 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_BROADCAST_ADDRESS

```
#define EMBER_BROADCAST_ADDRESS
```

Value:

```
0xFFFF
```

Broadcast address.

Definition at line 92 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_USE_LONG_ADDRESS

```
#define EMBER_USE_LONG_ADDRESS
```

Value:

```
0xFFFE
```

Special short address indicating the node should use long addressing as source address.

Definition at line 96 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_COORDINATOR_ADDRESS

```
#define EMBER_COORDINATOR_ADDRESS
```

Value:

```
0x0000
```

The coordinator short address.

Definition at line 99 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EMBER_CAL_INVALID_VALUE

```
#define EMBER_CAL_INVALID_VALUE
```

Value:

```
(0xFFFFFFFF)
```

Definition at line 804 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberNetworkParameters

Hold network parameters.

For information about power settings and radio channels, see the technical specification for the RF communication module in your Developer Kit and the Radio Configurator Guide (AN971).

Public Attributes

uint16_t [panId](#)

int16_t [radioTxPower](#)

uint16_t [radioChannel](#)

Public Attribute Documentation

panId

```
uint16_t EmberNetworkParameters::panId
```

The network's PAN identifier.

Definition at line 187 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

radioTxPower

```
int16_t EmberNetworkParameters::radioTxPower
```

The transmit power setting, in deci-dBm.

Definition at line 189 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

radioChannel

```
uint16_t EmberNetworkParameters::radioChannel
```

The radio channel. Be sure to specify a channel supported by the radio.

Definition at line 191 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberIncomingMessage

An instance of this structure is passed to [emberIncomingMessageHandler\(\)](#). It describes the incoming message.

Public Attributes

EmberMessageOptions	options
EmberNodeId	source
uint8_t	endpoint
int8_t	rssi
EmberMessageLength	length
uint8_t *	payload
uint32_t	timestamp
uint8_t	lqi

Public Attribute Documentation

options

```
EmberMessageOptions EmberIncomingMessage::options
```

An [EmberMessageOptions](#) value indicating the options used for the incoming packet.

Definition at line 256 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

source

```
EmberNodeId EmberIncomingMessage::source
```

An [EmberNodeId](#) value indicating source node ID.

Definition at line 260 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

endpoint

```
uint8_t EmberIncomingMessage::endpoint
```

The endpoint the message is destined to.

Definition at line 264 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

```
int8_t EmberIncomingMessage::rssi
```

The RSSI in dBm the packet was received with.

Definition at line 268 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

length

```
EmberMessageLength EmberIncomingMessage::length
```

An [EmberMessageLength](#) value indicating the length in bytes of the incoming message.

Definition at line 273 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

payload

```
uint8_t* EmberIncomingMessage::payload
```

A pointer to the message payload.

Definition at line 277 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

timestamp

```
uint32_t EmberIncomingMessage::timestamp
```

The millisecond system time returned by [emberGetInt32uMillisecondTick\(\)](#) at the time the sync word was detected.

Definition at line 282 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

lqi

```
uint8_t EmberIncomingMessage::lqi
```

The LQI the packet was received with.

Definition at line 286 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberOutgoingMessage

An instance of this structure is passed to [emberMessageSentHandler\(\)](#). It describes the outgoing packet.

Public Attributes

EmberMessageOptions	options
EmberNodeId	destination
uint8_t	endpoint
uint8_t	tag
EmberMessageLength	length
uint8_t *	payload
int8_t	ackRssi
uint32_t	timestamp

Public Attribute Documentation

options

```
EmberMessageOptions EmberOutgoingMessage::options
```

An [EmberMessageOptions](#) value indicating the options used for transmitting the outgoing message.

Definition at line 298 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

destination

```
EmberNodeId EmberOutgoingMessage::destination
```

An [EmberNodeId](#) value indicating the destination short ID.

Definition at line 302 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

endpoint

```
uint8_t EmberOutgoingMessage::endpoint
```

The endpoint the message is destined to.

Definition at line 306 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

```
uint8_t EmberOutgoingMessage::tag
```

A tag value the application can use to match [emberMessageSend\(\)](#) calls to the corresponding [emberMessageSentHandler\(\)](#) calls.

Definition at line 311 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

length

```
EmberMessageLength EmberOutgoingMessage::length
```

An [EmberMessageLength](#) value indicating the length in bytes of the incoming message.

Definition at line 316 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

payload

```
uint8_t* EmberOutgoingMessage::payload
```

A pointer to the message payload.

Definition at line 320 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

ackRssi

```
int8_t EmberOutgoingMessage::ackRssi
```

The RSSI in dBm of the ACK corresponding to this message. This field is meaningful only if [EMBER_OPTIONS_ACK_REQUESTED](#) flag is set in the options field.

Definition at line 326 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

timestamp

```
uint32_t EmberOutgoingMessage::timestamp
```

The millisecond system time returned by `::sl_sleeptimer` at the time the sync word was transmitted.

Definition at line 331 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberMacAddress

A structure that stores an 802.15.4 address.

Public Attributes

uint8_t	longAddress	Long (EUI-64) address. Valid if <code>mode</code> is EMBER_MAC_ADDRESS_MODE_LONG .
uint16_t	shortAddress	Short address (node ID). Valid if <code>mode</code> is EMBER_MAC_ADDRESS_MODE_SHORT .
union EmberMacAddress s:@3	addr	
EmberMacAddress sMode	mode	

Public Attribute Documentation

longAddress

```
uint8_t EmberMacAddress::longAddress[EUI64_SIZE]
```

Long (EUI-64) address. Valid if `mode` is [EMBER_MAC_ADDRESS_MODE_LONG](#).

Definition at line 361 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

shortAddress

```
uint16_t EmberMacAddress::shortAddress
```

Short address (node ID). Valid if `mode` is [EMBER_MAC_ADDRESS_MODE_SHORT](#).

Definition at line 366 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

addr

```
union EmberMacAddress:@3 EmberMacAddress::addr
```

Definition at line 367 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

mode

```
EmberMacAddressMode EmberMacAddress::mode
```

Addressing mode

Definition at line 369 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h

EmberMacFrame

A structure that describes the addressing fields of a 802.15.4 frame.

Public Attributes

EmberMacAddress	srcAddress
s	
EmberMacAddress	dstAddress
s	
EmberPanId	srcPanId
EmberPanId	dstPanId
bool	srcPanIdSpecified
bool	dstPanIdSpecified

Public Attribute Documentation

srcAddress

```
EmberMacAddress EmberMacFrame::srcAddress
```

An [EmberMacAddress](#) structure indicating the source address of a MAC frame.

Definition at line 380 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

dstAddress

```
EmberMacAddress EmberMacFrame::dstAddress
```

An [EmberMacAddress](#) structure indicating the destination address of a MAC frame.

Definition at line 385 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

srcPanId

```
EmberPanId EmberMacFrame::srcPanId
```

An [EmberPanId](#) struct indicating the source PAN ID of a MAC frame. This field is meaningful only if `srcPanIdSpecified` is set to true.

Definition at line 390 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

dstPanId


```
EmberPanId EmberMacFrame::dstPanId
```

An [EmberPanId](#) struct indicating the destination PAN ID of a MAC frame. This field is meaningful only if `dstPanIdSpecified` is set to true.

Definition at line 395 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

srcPanIdSpecified

```
bool EmberMacFrame::srcPanIdSpecified
```

True if the `srcPanId` field is set, false otherwise.

Definition at line 399 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

dstPanIdSpecified

```
bool EmberMacFrame::dstPanIdSpecified
```

True if the `dstPanId` field is set, false otherwise.

Definition at line 403 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberIncomingMacMessage

An instance of this structure is passed to [emberIncomingMacMessageHandler\(\)](#). It describes the incoming MAC frame.

Public Attributes

EmberMessageOptions	options
EmberMacFrame	macFrame
int8_t	rssi
uint8_t	lqi
uint32_t	frameCounter
EmberMessageLength	length
uint8_t *	payload
uint32_t	timestamp

Public Attribute Documentation

options

```
EmberMessageOptions EmberIncomingMacMessage::options
```

An [EmberMessageOptions](#) value indicating the options used for the incoming packet.

Definition at line 415 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

macFrame

```
EmberMacFrame EmberIncomingMacMessage::macFrame
```

An [EmberMacFrame](#) structure indicating the source and destination addresses and source and destination PAN IDs.

Definition at line 420 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

rssi

```
int8_t EmberIncomingMacMessage::rssi
```

The RSSI in dBm the packet was received with.

Definition at line 424 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

```
uint8_t EmberIncomingMacMessage::lqi
```

The LQI the packet was received with.

Definition at line 428 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

frameCounter

```
uint32_t EmberIncomingMacMessage::frameCounter
```

The security MAC frame counter (if any).

Definition at line 432 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

length

```
EmberMessageLength EmberIncomingMacMessage::length
```

An [EmberMessageLength](#) value indicating the length in bytes of the MAC payload of the incoming message.

Definition at line 437 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

payload

```
uint8_t* EmberIncomingMacMessage::payload
```

A pointer to the message MAC payload.

Definition at line 441 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

timestamp

```
uint32_t EmberIncomingMacMessage::timestamp
```

The millisecond system time returned by `::sl_sleeptimer` at the time the sync word was detected.

Definition at line 446 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberOutgoingMacMessage

An instance of this structure is passed to [emberMacMessageSentHandler\(\)](#). It describes the outgoing MAC frame.

Public Attributes

EmberMessageOptions	options
EmberMacFrame	macFrame
uint8_t	tag
uint32_t	frameCounter
EmberMessageLength	length
uint8_t *	payload
int8_t	ackRssi
uint32_t	timestamp

Public Attribute Documentation

options

```
EmberMessageOptions EmberOutgoingMacMessage::options
```

An [EmberMessageOptions](#) value indicating the options used for transmitting the outgoing message.

Definition at line 458 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

macFrame

```
EmberMacFrame EmberOutgoingMacMessage::macFrame
```

An [EmberMacFrame](#) struct indicating the source and destination addresses and source and destination PAN IDs of the outgoing MAC frame.

Definition at line 463 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

tag

```
uint8_t EmberOutgoingMacMessage::tag
```

A tag value the application can use to match [emberMacMessageSend\(\)](#) calls to the corresponding [emberMacMessageSentHandler\(\)](#) calls.

Definition at line 468 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

frameCounter

```
uint32_t EmberOutgoingMacMessage::frameCounter
```

The security frame counter of the outgoing MAC frame (if any).

Definition at line 472 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

length

```
EmberMessageLength EmberOutgoingMacMessage::length
```

An [EmberMessageLength](#) value indicating the length in bytes of the incoming message.

Definition at line 477 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

payload

```
uint8_t* EmberOutgoingMacMessage::payload
```

A pointer to the message payload.

Definition at line 481 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

ackRssi

```
int8_t EmberOutgoingMacMessage::ackRssi
```

The RSSI in dBm of the ACK corresponding to this message. This field is meaningful only if [EMBER_OPTIONS_ACK_REQUESTED](#) flag is set in the options field.

Definition at line 487 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

timestamp

```
uint32_t EmberOutgoingMacMessage::timestamp
```

The millisecond system time returned by `::sl_sleeptimer` at the time the sync word was transmitted.

Definition at line 492 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberKeyData

This data structure contains the security key, most prominently used by [emberSetSecurityKey](#).

Public Attributes

uint8_t [contents](#)

Public Attribute Documentation

contents

```
uint8_t EmberKeyData::contents[EMBER_ENCRYPTION_KEY_SIZE]
```

This is the key byte data.

Definition at line 500 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EventActions

The static part of an event. Each event can be used with only one event queue.

Public Attributes

```
struct queue
EventQueue_s*

void(* handler

void(* marker

const char * name
```

Public Attribute Documentation

queue

```
struct EventQueue_s* EventActions::queue
```

Definition at line 554 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

handler

```
void(* EventActions::handler) (struct Event_s *)
```

Definition at line 555 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

marker

```
void(* EventActions::marker) (struct Event_s *)
```

Definition at line 556 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

name

```
const char* EventActions::name
```

Definition at line 557 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

Event_s

Public Attributes

```
EventActions * actions
struct Event_s * next
uint32_t timeToExecute
```

Public Attribute Documentation

actions

```
EventActions* Event_s::actions
```

Definition at line 561 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

next

```
struct Event_s* Event_s::next
```

Definition at line 565 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

timeToExecute

```
uint32_t Event_s::timeToExecute
```

Definition at line 566 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EventQueue_s

An event queue is currently just a list of events ordered by execution time.

Public Attributes

Event * isrEvents

Event * events

Public Attribute Documentation

isrEvents

```
Event* EventQueue_s::isrEvents
```

Definition at line 573 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

events

```
Event* EventQueue_s::events
```

Definition at line 574 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberEventControl

Control structure for events.

This structure should not be accessed directly. It holds the event status (one of the `EMBER_EVENT_` values) and the time left before the event fires.

Public Attributes

<code>EmberEventUnits</code>	<code>status</code>
<code>EmberTaskId</code>	<code>taskid</code>
<code>uint32_t</code>	<code>timeToExecute</code>

Public Attribute Documentation

status

```
EmberEventUnits EmberEventControl::status
```

The event's status, either inactive or the units for timeToExecute.

Definition at line 585 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

taskid

```
EmberTaskId EmberEventControl::taskid
```

The task ID this event belongs to.

Definition at line 587 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

timeToExecute

```
uint32_t EmberEventControl::timeToExecute
```

How long before the event fires. Units are always in milliseconds.

Definition at line 591 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberEventData_S

Complete events with a control and a handler procedure.

An application typically creates an array of events along with their handlers. The main loop passes the array to `emberRunEvents()` to call the handlers of any events whose time has arrived.

Public Attributes

`EmberEventControl *` `control`
`void(*)` `handler`

Public Attribute Documentation

control

```
EmberEventControl* EmberEventData_S::control
```

The control structure for the event.

Definition at line 603 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

handler

```
void(* EmberEventData_S::handler) (void)
```

The procedure to call when the event fires.

Definition at line 605 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

EmberTaskControl

Control structure for tasks.

This structure should not be accessed directly.

Public Attributes

```
uint32_t  nextEventTime
EmberEventData*  events
bool     busy
```

Public Attribute Documentation

nextEventTime

```
uint32_t EmberTaskControl::nextEventTime
```

The time when the next event associated with this task will fire

Definition at line 614 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

events

```
EmberEventData* EmberTaskControl::events
```

The list of events associated with this task

Definition at line 616 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

busy

```
bool EmberTaskControl::busy
```

A flag that indicates the task has something to do other than events

Definition at line 618 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/ember-types.h`

Stack Information

Stack Information

Connect API for accessing and modifying stack states and behaviors.

See [stack-info.h](#) for source code.

Modules

[Stack Counters](#)

Handlers

- void [emberStackStatusHandler](#)(EmberStatus status)
A callback invoked when the status of the stack changes.
- void [emberStackIsrHandler](#)(void)
This handler is invoked in ISR context when certain stack-related ISR routines fire.
- bool [emberStackIdleHandler](#)(uint32_t *idleTimeMs)
A callback to allow the application to manage idling the MCU.
- void [emberRadioNeedsCalibratingHandler](#)(void)
The radio calibration callback function.
- void [emberChildJoinHandler](#)(EmberNodeType nodeType, EmberNodeId nodeId)
Invoked at coordinator, range extender, or mac mode nodes when a new child has joined the device.

APIs

- void [emberStackPowerDown](#)(void)
Immediately turns the radio power completely off.
- void [emberStackPowerUp](#)(void)
Power up the radio. Typically called coming out of sleep.
- EmberNetworkStatus [emberNetworkState](#)(void)
Return the current join status.
- bool [emberStackIsUp](#)(void)
Indicate whether the stack is currently up.
- EmberStatus [emberSetSecurityKey](#)(EmberKeyData *key)
Write a key at the address of the formerly used security key. The key set by this function will not be used by the stack. The API is meant to be used to erase a key as it is now managed by PSA Crypto API.
- EmberStatus [emberGetSecurityKey](#)(EmberKeyData *key)
Get the legacy security key. This function does not return the value set with the PSA Crypto API.
- EmberStatus [emberSetRadioChannelExtended](#)(uint16_t channel, bool persistent)
Set the channel for sending and receiving messages on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.

EmberStatus	<p>emberSetRadioChannel(uint16_t channel)</p> <p>Set the channel for sending and receiving messages on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.</p>
uint16_t	<p>emberGetRadioChannel(void)</p> <p>Get the radio channel, to which a node is set, on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.</p>
uint16_t	<p>emberGetDefaultChannel(void)</p> <p>Get the first available channel in the current radio configuration.</p>
EmberStatus	<p>emberPhyConfigInit(EmberPhyType phyType)</p> <p>Indicate if the PHY configuration of the stack. Currently only supporting EMBER_RADIO_CONFIGURATOR and EMBER_STANDARD_PHY_2_4GHZ. It must be called before initializing the stack.</p>
EmberStatus	<p>emberCalibrateCurrentChannelExtended(uint32_t calValueIn, uint32_t *calValueOut)</p> <p>Perform image rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the emberRadioNeedsCalibratingHandler() callback function during emberTick(). This function should only be called from within the context of the emberRadioNeedsCalibratingHandler() callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.</p>
EmberStatus	<p>emberCalibrateCurrentChannel(void)</p> <p>Perform image rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the emberRadioNeedsCalibratingHandler() callback function during emberTick(). This function should only be called from within the context of the emberRadioNeedsCalibratingHandler() callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.</p>
EmberStatus	<p>emberApplyIrcalibration(uint32_t calValue)</p> <p>Apply Image Rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the emberRadioNeedsCalibratingHandler() callback function during emberTick(). This function should only be called from within the context of the emberRadioNeedsCalibratingHandler() callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.</p>
EmberStatus	<p>emberTempCalibration(void)</p> <p>Perform Temperature VCO calibration on the current channel. The stack will notify the application that it needs channel calibration via the emberRadioNeedsCalibratingHandler() callback function during emberTick(). This function should only be called from within the context of the emberRadioNeedsCalibratingHandler() callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.</p>
EmberCalType	<p>emberGetCalType(void)</p> <p>Fetch calibration type associated to the latest emberRadioNeedsCalibratingHandler() callback.</p>
EmberStatus	<p>emberSetRadioPower(int16_t power, bool persistent)</p> <p>Set the radio output power at which a node is to operate for the current network. The radio has a finite power resolution, so it will approximate the requested power with the closest possible value at or below the requested value.</p>
int16_t	<p>emberGetRadioPower(void)</p> <p>Get the radio output power of the current network at which a node is operating. This might be different to what you set using emberSetRadioPower because the radio has a finite power resolution, and emberSetRadioPower must approximate to the closest possible value at or below the requested value. This API however returns with the actual setting.</p>
EmberStatus	<p>emberSetRadioPowerMode(bool radioOn)</p> <p>Allow the application to turn the radio on/off. This API is intended for use with direct devices only.</p>
EmberStatus	<p>emberSetMacParams(int8_t ccaThreshold, uint8_t maxCcaAttempts, uint8_t minBackoffExp, uint8_t maxBackoffExp, uint16_t ccaBackoff, uint16_t ccaDuration, uint8_t maxRetries, uint32_t csmaTimeout, uint16_t ackTimeout)</p> <p>Set the MAC layer transmission parameters.</p>
EmberStatus	<p>emberMacGetParentAddress(EmberMacAddress *parentAddress)</p> <p>Retrieve the parent address. This API can be invoked only for nodes of EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE type.</p>

uint32_t	emberStackIdleTimeMs (uint16_t *currentStackTasks) Return the time in milliseconds the stack could idle for.
uint32_t	emberGetInt32uMillisecondTick (void) Return the current time in milliseconds.
uint16_t	emberCurrentStackTasks (void) Return a bitmask indicating the stack's current tasks.
bool	emberOkToNap (void) Indicate whether the stack is currently in a state with no high-priority tasks and may sleep.
bool	emberOkToHibernate (void) Indicate whether the stack currently has any pending tasks.
uint8_t *	emberGetEui64 (void) Return the EUI64 ID of the local node.
bool	emberIsLocalEui64 (EmberEUI64 eui64) Determine whether <code>eui64</code> is the local node's EUI64 ID. EUI64 is easily accessible in SoC mode, but in Host-NCP, the address is stored on the NCP. This API can be used on the Host to compare a value with the locally stored one.
EmberNodeId	emberGetNodeId (void) Return the 16-bit node ID of local node on the current network.
EmberPanId	emberGetPanId (void) Return the local node's PAN ID of the current network.
EmberNodeType	emberGetNodeType (void) Return an EmberNodeType value indicating the type of the node.
EmberNodeId	emberGetParentId (void) Return the parent's node ID.
EmberStatus	emberGetVersionInfo (uint16_t *gsdk_version, uint16_t *connect_stack_version, uint32_t *bootloader_version) Get the GSDK, Stack and bootloader versions all at once. The version format are not all the same. Please refer to the corresponding documentation to handle the information correctly.

Macros

#define	EMBER_HIGH_PRIORITY_TASKS (EMBER_OUTGOING_MESSAGES EMBER_INCOMING_MESSAGES EMBER_RADIO_IS_ON) A mask of the tasks that prevent a device from sleeping.
#define	EMBER_INVALID_CHANNEL 65535 Invalid channel number.

Handlers Documentation

emberStackStatusHandler

```
void emberStackStatusHandler (EmberStatus status)
```

A callback invoked when the status of the stack changes.

Parameters

[in]	status	Stack status. One of the following: <ul style="list-style-type: none"> • EMBER_NETWORK_UP • EMBER_NETWORK_DOWN • EMBER_NO_VALID_BEACONS • EMBER_JOIN_SCAN_FAILED • EMBER_JOIN_FAILED • EMBER_JOIN_DENIED • EMBER_JOIN_TIMEOUT • EMBER_MAC_SYNC_TIMEOUT
------	--------	--

The application is free to begin messaging once it receives the [EMBER_NETWORK_UP](#) status.

Definition at line 72 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberStackIsrHandler

```
void emberStackIsrHandler (void)
```

This handler is invoked in ISR context when certain stack-related ISR routines fire.

Parameters

N/A		
-----	--	--

Definition at line 77 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberStackIdleHandler

```
bool emberStackIdleHandler (uint32_t *idleTimeMs)
```

A callback to allow the application to manage idling the MCU.

Parameters

[inout]	idleTimeMs	A pointer to the time in millisecond the stack is allowed to idle. If the application decides to manage idling the MCU, it should update the passed value with the actual time the MCU was idled.
---------	------------	---

Returns

- true if the application is managing idling the MCU, false otherwise. If this function returns false, the stack will manage idling the MCU.

Definition at line 88 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberRadioNeedsCalibratingHandler

```
void emberRadioNeedsCalibratingHandler (void)
```

The radio calibration callback function.

Parameters

N/A		
-----	--	--

This handler is invoked by the stack upon receiving a "calibration needed" event from the radio to inform the application that it should perform calibration of the current channel as soon as possible using the [emberCalibrateCurrentChannel\(\)](#) API.

While calibration only takes tens of microseconds, the application can failsafe any critical processes or peripherals before calling `emberCalibrateCurrentChannel()`. The application must call `emberCalibrateCurrentChannel()` in response to this callback to maintain expected radio performance.

Definition at line 102 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberChildJoinHandler

```
void emberChildJoinHandler (EmberNodeType nodeType, EmberNodeId nodeId)
```

Invoked at coordinator, range extender, or mac mode nodes when a new child has joined the device.

Parameters

[in]	nodeType	The role of the joining device (<code>EMBER_STAR_RANGE_EXTENDER</code> , <code>EMBER_STAR_END_DEVICE</code> , <code>EMBER_STAR_SLEEPY_END_DEVICE</code> , <code>EMBER_MAC_MODE_DEVICE</code> or <code>EMBER_MAC_MODE_SLEEPY_DEVICE</code>).
[in]	nodeId	The node ID of the joining device.

Definition at line 601 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

APIs Documentation

emberStackPowerDown

```
void emberStackPowerDown (void)
```

Immediately turns the radio power completely off.

Parameters

N/A		
-----	--	--

After calling this function, do not call any other stack function except `emberStackPowerUp()` because all other stack functions require that the radio is powered to operate properly.

Definition at line 118 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberStackPowerUp

```
void emberStackPowerUp (void)
```

Power up the radio. Typically called coming out of sleep.

Parameters

N/A		
-----	--	--

For non-sleepy devices, also turns the radio on and leaves it in RX mode.

Definition at line 124 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberNetworkState

```
EmberNetworkStatus emberNetworkState (void)
```

Return the current join status.

Parameters

N/A

Returns a value indicating whether the node is joining, joined to, or leaving a network.

Returns

- An [EmberNetworkStatus](#) value indicating the current join status.

Definition at line 133 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberStackIsUp

```
bool emberStackIsUp (void)
```

Indicate whether the stack is currently up.

Parameters

N/A

Returns true if the stack is joined to a network and ready to send and receive messages. This reflects only the state of the local node and does not indicate whether or not other nodes are able to communicate with this node.

Returns

- **true** if the stack is up, **false** otherwise.

Definition at line 144 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetSecurityKey

```
EmberStatus emberSetSecurityKey (EmberKeyData *key)
```

Write a key at the address of the formerly used security key. The key set by this function will not be used by the stack. The API is meant to be used to erase a key as it is now managed by PSA Crypto API.

Parameters

[in] key An [EmberKeyData](#) value containing the security key to be set.

Returns

- An EmberStatus value of [EMBER_SUCCESS](#) if the key was successfully set. Otherwise, it returns an EmberStatus value of [EMBER_INVALID_CALL](#).

Definition at line 156 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetSecurityKey

```
EmberStatus emberGetSecurityKey (EmberKeyData *key)
```

Get the legacy security key. This function does not return the value set with the PSA Crypto API.

Parameters

[in]	key	An EmberKeyData where the legacy security key will be stored
------	-----	--

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the key was successfully read.

Definition at line 166 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetRadioChannelExtended

```
EmberStatus emberSetRadioChannelExtended (uint16_t channel, bool persistent)
```

Set the channel for sending and receiving messages on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.

Parameters

[in]	channel	A desired radio channel.
[in]	persistent	A flag to instruct the stack to save the channel setting in persistent or not. Each persistent call triggers a token write. Excessive usage might cause flash to wear-out.

Note

- Care should be taken when using this API. All devices on a network must use the same channel.

Returns

- An [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the stack accepted the channel change.
 - [EMBER_INVALID_CALL](#) if the node is currently performing frequency hopping.
 - [EMBER_PHY_INVALID_CHANNEL](#) if the passed channel is invalid.
 - [EMBER_MAC_BUSY](#) if the MAC is currently performing a high priority task.

Definition at line 222 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetRadioChannel

```
EmberStatus emberSetRadioChannel (uint16_t channel)
```

Set the channel for sending and receiving messages on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.

Parameters

[in]	channel	A desired radio channel.
------	---------	--------------------------

Note

- Care should be taken when using this API. All devices on a network must use the same channel. Each call triggers a token write. Excessive usage might cause flash to wear-out.

Returns

- An [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the stack accepted the channel change.
 - [EMBER_INVALID_CALL](#) if the node is currently performing frequency hopping.
 - [EMBER_PHY_INVALID_CHANNEL](#) if the passed channel is invalid.
 - [EMBER_MAC_BUSY](#) if the MAC is currently performing a high priority task.

Definition at line 242 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberGetRadioChannel

```
uint16_t emberGetRadioChannel (void)
```

Get the radio channel, to which a node is set, on the current network. The available channels depend on the radio config you use. Channels can differ more than the frequency if it's a multi-PHY config.

Parameters

N/A		
-----	--	--

Returns

- The current radio channel.

Definition at line 250 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberGetDefaultChannel

```
uint16_t emberGetDefaultChannel (void)
```

Get the first available channel in the current radio configuration.

Parameters

N/A		
-----	--	--

Returns

- The first available channel in the radio configuration. 0xffff if error

Definition at line 257 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberPhyConfigInit

```
EmberStatus emberPhyConfigInit (EmberPhyType phyType)
```

Indicate if the PHY configuration of the stack. Currently only supporting [EMBER_RADIO_CONFIGURATOR](#) and [EMBER_STANDARD_PHY_2_4GHZ](#). It must be called before initializing the stack.

Parameters

N/A	phyType	
-----	---------	--

Returns

- [EMBER_BAD_ARGUMENT](#) if phyType is incorrect [EMBER_INVALID_CALL](#) if API is called after stack initialization [EMBER_SUCCESS](#) otherwise

Definition at line 267 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberCalibrateCurrentChannelExtended

```
EmberStatus emberCalibrateCurrentChannelExtended (uint32_t calValueIn, uint32_t *calValueOut)
```

Perform image rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the [emberRadioNeedsCalibratingHandler\(\)](#) callback function during [emberTick\(\)](#). This function should only be called from within the context of the [emberRadioNeedsCalibratingHandler\(\)](#) callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.

Parameters

[in]	calValueIn	the calibration value to use. Set to EMBER_CAL_INVALID_VALUE to perform automatic calibration.
[out]	calValueOut	a pointer to the calibration value that was used. This parameter is ignored when set to NULL.

Returns

- An [EmberStatus](#) value indicating the success or failure of the command.

Definition at line 286 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberCalibrateCurrentChannel

```
EmberStatus emberCalibrateCurrentChannel (void)
```

Perform image rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the [emberRadioNeedsCalibratingHandler\(\)](#) callback function during [emberTick\(\)](#). This function should only be called from within the context of the [emberRadioNeedsCalibratingHandler\(\)](#) callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.

Parameters

N/A

Definition at line 297 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberApplyIrCalibration

```
EmberStatus emberApplyIrCalibration (uint32_t calValue)
```

Apply Image Rejection calibration on the current channel. The stack will notify the application that it needs channel calibration via the [emberRadioNeedsCalibratingHandler\(\)](#) callback function during [emberTick\(\)](#). This function should only be called from within the context of the [emberRadioNeedsCalibratingHandler\(\)](#) callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.

Parameters

[in]	calValue	the calibration value to apply. Should not be set to EMBER_CAL_INVALID_VALUE.
------	----------	---

Returns

- An [EmberStatus](#) value indicating the success or failure of the command.

Definition at line 313 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberTempCalibration

```
EmberStatus emberTempCalibration (void)
```

Perform Temperature VCO calibration on the current channel. The stack will notify the application that it needs channel calibration via the [emberRadioNeedsCalibratingHandler\(\)](#) callback function during [emberTick\(\)](#). This function should

only be called from within the context of the [emberRadioNeedsCalibratingHandler\(\)](#) callback function. Note if this function is called when the radio is off, it will turn the radio on and leave it on.

Parameters

N/A

Returns

- An [EmberStatus](#) value indicating the success or failure of the command.

Definition at line 326 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetCalType

```
EmberCalType emberGetCalType (void)
```

Fetch calibration type associated to the latest [emberRadioNeedsCalibratingHandler\(\)](#) callback.

Parameters

N/A

Returns

- An [EmberCalType](#) value indicating which type of calibration should be performed.

Definition at line 334 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetRadioPower

```
EmberStatus emberSetRadioPower (int16_t power, bool persistent)
```

Set the radio output power at which a node is to operate for the current network. The radio has a finite power resolution, so it will approximate the requested power with the closest possible value at or below the requested value.

Parameters

[in]	power	Desired radio output power, in deci-dBm.
[in]	persistent	A flag to instruct the stack to save the power setting in persistent or not.

Note

- Care should be taken when using this API on a running network, because it directly impacts the established link qualities neighboring nodes have with the node on which it is called. This can lead to disruption of existing routes and erratic network behavior.

Returns

- An [EmberStatus](#) value indicating the success or failure of the command. Failure indicates that the requested power level is out of range.

Definition at line 353 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetRadioPower

```
int16_t emberGetRadioPower (void)
```

Get the radio output power of the current network at which a node is operating. This might be different to what you set using [emberSetRadioPower](#) because the radio has a finite power resolution, and [emberSetRadioPower](#) must approximate to the closest possible value at or below the requested value. This API however returns with the actual setting.

Parameters

N/A

Returns

- Current radio output power, in deci-dBm.

Definition at line 363 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetRadioPowerMode

```
EmberStatus emberSetRadioPowerMode (bool radioOn)
```

Allow the application to turn the radio on/off. This API is intended for use with direct devices only.

Parameters

[in]	radioOn	If this parameter is true , the radio is turned on, otherwise it's turned off.
------	---------	---

Returns

- An [EmberStatus](#) value indicating the success or failure of the command. Failure indicates that the node type is a type other than [EMBER_DIRECT_DEVICE](#).

Definition at line 375 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberSetMacParams

```
EmberStatus emberSetMacParams (int8_t ccaThreshold, uint8_t maxCcaAttempts, uint8_t minBackoffExp, uint8_t maxBackoffExp, uint16_t ccaBackoff, uint16_t ccaDuration, uint8_t maxRetries, uint32_t csmaTimeout, uint16_t ackTimeout)
```

Set the MAC layer transmission parameters.

Parameters

[in]	ccaThreshold	The CCA RSSI threshold, in dBm, above which the channel is considered 'busy'. This parameter is by default set to EMBER_RADIO_CCA_THRESHOLD .
[in]	maxCcaAttempts	The maximum number of clear channel assessment attempts that are performed prior to fail to transmit a packet with EMBER_PHY_TX_CCA_FAIL status. This parameter is set by default to 4. If this parameter is set to 0, the CCA assessment shall not be performed.
[in]	minBackoffExp	The backoff exponent used if the initial channel clear assessment fails. This parameter is set by default to 3. Note: this is meaningful only if the <code>checkCca</code> parameter is set to true .
[in]	maxBackoffExp	The backoff exponent used if the final channel clear assessment fails. This parameter is set by default to 5. Note: this is meaningful only if the <code>checkCca</code> parameter is set to true .
[in]	ccaBackoff	The backoff unit period in microsecond. It is multiplied by the random backoff exponential controlled by <code>minBackoffExp</code> and <code>maxBackoffExp</code> to determine the overall backoff period. This parameter is set by default to the PHY symbol time in microseconds multiplied by 20.
[in]	ccaDuration	The minimum desired CCA check duration in microseconds. This parameter is set by default to the PHY symbol time in microseconds multiplied by 8.

[in]	maxRetries	The number of transmission retries that is performed if no acknowledgment was received. This parameter is set by default to 3 (which means that a total of 4 transmission attempts will be performed).
[in]	csmaTimeout	An overall timeout in microsecond time base for the the CSMA operations. This value is set by default to 0 which means that no timeout is imposed.
[in]	ackTimeout	The ack timeout in microseconds after which the transmitting gives up waiting for an acknowledgment. This parameter is set by default to (<code>EMBER_MAC_ACK_TIMEOUT_MS * 1000</code>).

Note

- The CSMA/CA (CCA) values are directly used in RAIL's `RAIL_CsmaConfig_t` and further information can be found in the RAIL API documentation.

Returns

- An `EmberStatus` value indicating whether the MAC parameters were successfully set or the reason of failure.

Definition at line 432 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberMacGetParentAddress

```
EmberStatus emberMacGetParentAddress (EmberMacAddress *parentAddress)
```

Retrieve the parent address. This API can be invoked only for nodes of `EMBER_MAC_MODE_DEVICE` or `EMBER_MAC_MODE_SLEEPY_DEVICE` type.

Parameters

N/A	parentAddress	
-----	---------------	--

Returns

- An `EmberStatus` value of `EMBER_SUCCESS` if the parent address was successfully retrieved, otherwise an `EmberStatus` value indicating the reason of failure.

Definition at line 449 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberStackIdleTimeMs

```
uint32_t emberStackIdleTimeMs (uint16_t *currentStackTasks)
```

Return the time in milliseconds the stack could idle for.

Parameters

[in]	currentStackTasks	A pointer to an integer that is written with the active stack tasks at the time of the API call.
------	-------------------	--

Returns

- Allowed idle time in milliseconds.

Definition at line 458 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetInt32uMillisecondTick

```
uint32_t emberGetInt32uMillisecondTick (void)
```


Return the current time in milliseconds.

Parameters

N/A		
-----	--	--

Returns

- Current time in milliseconds.

Definition at line 464 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberCurrentStackTasks

```
uint16_t emberCurrentStackTasks (void)
```

Return a bitmask indicating the stack's current tasks.

Parameters

N/A		
-----	--	--

The mask [EMBER_HIGH_PRIORITY_TASKS](#) defines which tasks are high-priority. Devices should not sleep if any high-priority tasks are active. Active tasks that are not high-priority are waiting for messages to arrive from other devices. If there are active tasks, but no high-priority ones, the device may sleep but should periodically wake up and call [emberPollForData\(\)](#) to receive messages. Parents will hold messages for [EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS](#) milliseconds before discarding them.

Returns

- A bitmask of the stack's active tasks.

Definition at line 479 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberOkToNap

```
bool emberOkToNap (void)
```

Indicate whether the stack is currently in a state with no high-priority tasks and may sleep.

Parameters

N/A		
-----	--	--

Tasks may be expecting incoming messages, in which case the device should periodically wake up and call [emberPollForData\(\)](#) to receive messages. This function can only be called when the node type is [EMBER_STAR_SLEEPY_END_DEVICE](#).

Returns

- **true** if the application may sleep but the stack may be expecting incoming messages.

Definition at line 492 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

emberOkToHibernate

```
bool emberOkToHibernate (void)
```

Indicate whether the stack currently has any pending tasks.

Parameters

N/A

If no tasks are pending, `emberTick()` does not need to be called until next stack API function is called. This function can only be called when the node type is `EMBER_STAR_SLEEPY_END_DEVICE`.

Returns

- **true** if the application may sleep for as long as it wishes.

Definition at line 502 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetEui64

```
uint8_t * emberGetEui64 (void)
```

Return the EUI64 ID of the local node.

Parameters

N/A

Returns

- The 64-bit ID.

Definition at line 508 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberIsLocalEui64

```
bool emberIsLocalEui64 (EmberEUI64 eui64)
```

Determine whether `eui64` is the local node's EUI64 ID. EUI64 is easily accessible in SoC mode, but in Host-NCP, the address is stored on the NCP. This API can be used on the Host to compare a value with the locally stored one.

Parameters

[in]

`eui64`

An EUI64 ID.

Returns

- **true** if `eui64` is the local node's ID, otherwise **false**.

Definition at line 519 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetNodeid

```
EmberNodeId emberGetNodeId (void)
```

Return the 16-bit node ID of local node on the current network.

Parameters

N/A

Returns

- The 16-bit ID. Byte order is little endian.

Definition at line 525 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetPanId

```
EmberPanId emberGetPanId (void)
```

Return the local node's PAN ID of the current network.

Parameters

N/A		
-----	--	--

Returns

- The PAN ID.

Definition at line 531 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetNodeType

```
EmberNodeType emberGetNodeType (void)
```

Return an [EmberNodeType](#) value indicating the type of the node.

Parameters

N/A		
-----	--	--

Returns

- The node type.

Definition at line 537 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetParentId

```
EmberNodeId emberGetParentId (void)
```

Return the parent's node ID.

Parameters

N/A		
-----	--	--

Returns

- The parent's node ID.

Definition at line 543 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

emberGetVersionInfo

```
EmberStatus emberGetVersionInfo (uint16_t *gsdk_version, uint16_t *connect_stack_version, uint32_t *bootloader_version)
```

Get the GSDK, Stack and bootloader versions all at once. The version format are not all the same. Please refer to the corresponding documentation to handle the information correctly.

Parameters

N/A	gsdk_version	
N/A	connect_stack_version	
N/A	bootloader_version	

Returns

- EMBER_SUCCESS if successful

Definition at line 550 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

Macro Definition Documentation

EMBER_HIGH_PRIORITY_TASKS

```
#define EMBER_HIGH_PRIORITY_TASKS
```

Value:

```
(EMBER_OUTGOING_MESSAGES | EMBER_INCOMING_MESSAGES | EMBER_RADIO_IS_ON)
```

A mask of the tasks that prevent a device from sleeping.

Definition at line 44 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

EMBER_INVALID_CHANNEL

```
#define EMBER_INVALID_CHANNEL
```

Value:

```
65535
```

Invalid channel number.

Definition at line 51 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

Stack Counters

Stack Counters

Stack counters API.

Functions

[EmberStatus](#) `emberGetCounter(EmberCounterType counterType, uint32_t *count)`
Retrieve the stack counter corresponding to the passed counter type.

Function Documentation

`emberGetCounter`

```
EmberStatus emberGetCounter (EmberCounterType counterType, uint32_t *count)
```

Retrieve the stack counter corresponding to the passed counter type.

Parameters

[in]	counterType	An EmberCounterType value indicating the stack counter to be retrieved.
[out]	count	The counter of the requested <code>counterType</code> is returned here

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the stack counter was successfully retrieved. An [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the passed `counterType` is invalid. An [EmberStatus](#) value of [EMBER_LIBRARY_NOT_PRESENT](#) if the stack counter library is not present.

Definition at line 578 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h`

Network Management

Network Management

Connect API for finding, forming, joining, and leaving Connect networks.

See [network-management.h](#) for source code.

Modules

[Frequency Hopping](#)

[Parent Support](#)

Handlers

- void [emberIncomingBeaconHandler](#)(EmberPanId panId, EmberMacAddress *source, int8_t rssi, bool permitJoining, uint8_t beaconFieldsLength, uint8_t *beaconFields, uint8_t beaconPayloadLength, uint8_t *beaconPayload)
Invoked if a beacon is received during the scanning procedure if the handler was initiated by the application with the [emberStartActiveScan\(\)](#) stack APIs.
- void [emberActiveScanCompleteHandler](#)(void)
Invoked after the application calls the [emberStartActiveScan\(\)](#) stack API to inform the application that the scanning procedure is complete.
- void [emberEnergyScanCompleteHandler](#)(int8_t mean, int8_t min, int8_t max, uint16_t variance)
Invoked after the application calls the [emberStartEnergyScan\(\)](#) stack API to inform the application that the energy scan procedure is complete and to provide statistics.

Functions

- [EmberStatus](#) [emberInit](#)(void)
Initialize the radio and the Ember stack.
- void [emberTick](#)(void)
A periodic tick routine that should be called in the main loop in the application.
- [EmberStatus](#) [emberNetworkInit](#)(void)
Resume the network operation after a reboot.
- [EmberStatus](#) [emberStartActiveScan](#)(uint16_t channel)
Start an active scan. `EMBER_SUCCESS` signals that the scan successfully started. Upon receiving a beacon, the [emberIncomingBeaconHandler\(\)](#) stack handler is called. At the end of the scanning procedure, the [emberActiveScanCompleteHandler\(\)](#) stack handler is called. Note that, while a scan can be initiated when the node is currently joined to a network, the node will generally be unable to communicate with its PAN during the scan period. In particular, time-sensitive network operations might be affected because a scan operation will prevent any network operation for the duration of the scan.
- [EmberStatus](#) [emberSetActiveScanDuration](#)(uint16_t durationMs)
Set the time in milliseconds the node will spend listening for incoming beacons during an active scan. The default value is set based on the symbol time of the current PHY configuration according to the 802.15.4 specs.
- uint16_t [emberGetActiveScanDuration](#)(void)
Get the current active scan duration in milliseconds.

EmberStatus	<p>emberStartEnergyScan(uint16_t channel, uint8_t samples)</p> <p>Start an energy scan. EMBER_SUCCESS signals that the scan successfully started. At the end of the scanning procedure, the emberEnergyScanCompleteHandler() stack handler is called. Note that, while a scan can be initiated when the node is currently joined to a network, the node is generally unable to communicate with its PAN during the scan period. In particular, time-sensitive network operations might be affected because a scan operation will prevent any network operation for the duration of the scan.</p>
EmberStatus	<p>emberSetApplicationBeaconPayload(uint8_t payloadLength, uint8_t *payload)</p> <p>Allow the application to set the application portion of the beacon payload. It's by default set to the empty string.</p>
EmberStatus	<p>emberJoinNetworkExtended(EmberNodeType nodeType, EmberNodeId nodeId, EmberNetworkParameters *parameters)</p> <p>Cause the stack to associate with the network using the specified network parameters. It can take several seconds for the stack to associate with the local network. Do not send messages until a call to the emberStackStatusHandler() callback informs you that the stack is up. Notice that forming a network causes the node's security frame counter to be reset.</p>
EmberStatus	<p>emberJoinNetwork(EmberNodeType nodeType, EmberNetworkParameters *parameters)</p> <p>Cause the stack to associate with the network using the specified network parameters. The network ID is assigned by the network coordinator. It can take several seconds for the stack to associate with the local network. Do not send messages until a call to the emberStackStatusHandler() callback informs you that the stack is up. Notice that joining a network causes the node's security frame counter to be reset.</p>
EmberStatus	<p>emberPermitJoining(uint8_t duration)</p> <p>Tell the stack to allow other nodes to join the network with this node as their parent. Joining is initially disabled by default. This function may only be called after the node is part of a network and the stack is up.</p>
EmberStatus	<p>emberJoinCommissioned(EmberNodeType nodeType, EmberNodeId nodeId, EmberNetworkParameters *parameters)</p> <p>Cause the stack to go up with the passed network parameters without performing any over-the-air message exchange. Notice that commissioning a network causes the node's security frame counter to be reset.</p>
EmberStatus	<p>emberSetSelectiveJoinPayload(uint8_t payloadLength, uint8_t *payload)</p> <p>When invoked at a EMBER_STAR_COORDINATOR or a EMBER_STAR_RANGE_EXTENDER, it causes the stack to only accept subsequent joining nodes with matching joining payload. When invoked at a node that has not yet joined a network, it sets the joining payload that will be included in the joining process. Notice, the join payload is included in a non-standard 802.15.4 command, therefore this feature is not available for nodes operating as EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE.</p>
EmberStatus	<p>emberClearSelectiveJoinPayload(void)</p> <p>Clear the join payload previously set with the emberSetSelectiveJoinPayload() API. When invoked at an EMBER_STAR_COORDINATOR or an EMBER_STAR_RANGE_EXTENDER it causes the stack to accept joining nodes with any join payload pattern. When invoked at a node that has not yet joined a network, it clears the join payload. Subsequent joining attempts will not include any join payload in the over-the-air joining handshake.</p>
EmberStatus	<p>emberSetAuxiliaryAddressFilteringEntry(EmberNodeId nodeId, uint8_t entryIndex)</p> <p>Set an entry in the auxiliary address filtering table at a given address. Nodes of EMBER_DIRECT_DEVICE device type can receive incoming messages destined to any of the node IDs in the auxiliary address filtering table (while also receiving messages destined to actual node ID). If the passed node ID is EMBER_NULL_NODE_ID, the entry is cleared.</p>
EmberNodeId	<p>emberGetAuxiliaryAddressFilteringEntry(uint8_t entryIndex)</p> <p>Retrieve the content of the auxiliary address filtering table at a given address. See emberSetAuxiliaryAddressFilteringEntry() for details.</p>
void	<p>emberResetNetworkState(void)</p> <p>Forget the current network and reverts to a network status of EMBER_NO_NETWORK.</p>
EmberStatus	<p>emberMacFormNetwork(EmberNetworkParameters *parameters)</p> <p>Form a new network as an EMBER_MAC_MODE_DEVICE by becoming the coordinator. This API should be used to form a compliant 802.15.4 PAN and to inter-operate with other 802.15.4 devices. Notice that forming a network causes the node's security frame counter to be reset.</p>

EmberStatus	<code>emberMacSetPanCoordinator</code> (bool isCoordinator) Configure a <code>EMBER_MAC_MODE_DEVICE</code> node to be a PAN coordinator. Note, this only applies to nodes that have been commissioned as <code>EMBER_MAC_MODE_DEVICE</code> .
EmberStatus	<code>emberNetworkLeave</code> (void) Allow a star topology node that previously joined a network to leave the network. The node will notify the parent node and eventually leave the network. The application is notified that the leave procedure completed via the <code>emberStackStatusHandler()</code> handler.
EmberStatus	<code>emberMacAddShortToLongAddressMapping</code> (EmberNodeId shortId, EmberEUI64 longId) Populate the short-to-long address mapping table at the MAC layer. The table is meaningful only when running as <code>EMBER_MAC_MODE_DEVICE</code> or <code>EMBER_MAC_MODE_SLEEPY_DEVICE</code> . The standard 802.15.4 encryption and authentication process requires the security nonce to be populated with the source node long ID. A receiver must do the same to decrypt a secured incoming message. This short-to-long mapping table is used to decrypt a secured incoming packet from a node using short source addressing. If no entry is found in this table, the incoming message will be dropped. This table is also used to encrypt secured outgoing messages with short source addressing in case the node is sending out a secured message with a short source address other than its own.
EmberStatus	<code>emberMacClearShortToLongAddressMappings</code> (void) Clear the short-to-long address mapping table at the MAC layer.
EmberStatus	<code>emberOfdmSetMcs</code> (uint8_t mcs) Set the MCS in case of an OFDM PHY. MCS can range from 0 to 6.
EmberStatus	<code>emberOfdmGetMcs</code> (uint8_t *mcs) Get the MCS in case of an OFDM PHY.

Macros

<code>#define</code>	<code>EMBER_MAC_MAX_APP_BEACON_PAYLOAD_LENGTH</code> 16 The maximum length in bytes of the application beacon payload.
<code>#define</code>	<code>EMBER_MAC_STACK_BEACON_PAYLOAD</code> "silabs-connect"
<code>#define</code>	<code>EMBER_MAC_STACK_BEACON_PAYLOAD_LENGTH</code> 14 The length in bytes of the stack beacon payload.
<code>#define</code>	<code>EMBER_MAC_MAX_BEACON_FIELDS_LENGTH</code> 84 The maximum length in bytes of the beacon fields (superframe, GTS, pending address) as per 802.15.4 specs.
<code>#define</code>	<code>EMBER_CHILD_TABLE_AGING_DISABLED</code> 0x20C400 A special timeout value that disables aging of the child table.
<code>#define</code>	<code>EMBER_CHILD_TABLE_MAX_TIMEOUT_S</code> (EMBER_CHILD_TABLE_AGING_DISABLED - 1) The maximum timeout in seconds after which a stale entry may be removed from the child table.
<code>#define</code>	<code>EMBER_MAX_SELECTIVE_JOIN_PAYLOAD_LENGTH</code> 50 The maximum length in bytes of the join payload.
<code>#define</code>	<code>EMBER_MAX_AUXILIARY_ADDRESS_FILTERING_TABLE_LENGTH</code> 2 The maximum number of entries the auxiliary address filtering table can hold.

Handlers Documentation

`emberIncomingBeaconHandler`

```
void emberIncomingBeaconHandler (EmberPanId panId, EmberMacAddress *source, int8_t rssi, bool permitJoining, uint8_t beaconFieldsLength, uint8_t *beaconFields, uint8_t beaconPayloadLength, uint8_t *beaconPayload)
```


Invoked if a beacon is received during the scanning procedure if the handler was initiated by the application with the [emberStartActiveScan\(\)](#) stack APIs.

Parameters

[in]	panId	The source pan ID of the received beacon.
[in]	source	The source node address of the received beacon.
[in]	rssI	The RSSI the beacon was received with.
[in]	permitJoining	The permit joining flag in the received beacon.
[in]	beaconFieldsLength	The length in bytes of the beacon fields defined as per 802.15.4 specs (superframe, GTS fields and pending address fields) of the received beacon.
[in]	beaconFields	A pointer to the beacon fields defined as per 802.15.4 specs (superframe, GTS fields and pending address fields) of the received beacon.
[in]	beaconPayloadLength	The length in bytes of the application beacon payload of the received beacon.
[in]	beaconPayload	A pointer to the application beacon payload of the received beacon.

Definition at line 94 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberActiveScanCompleteHandler

```
void emberActiveScanCompleteHandler (void)
```

Invoked after the application calls the [emberStartActiveScan\(\)](#) stack API to inform the application that the scanning procedure is complete.

Parameters

N/A

Definition at line 106 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberEnergyScanCompleteHandler

```
void emberEnergyScanCompleteHandler (int8_t mean, int8_t min, int8_t max, uint16_t variance)
```

Invoked after the application calls the [emberStartEnergyScan\(\)](#) stack API to inform the application that the energy scan procedure is complete and to provide statistics.

Parameters

[in]	mean	The average energy detected in dBm.
[in]	min	The minimum energy detected in dBm.
[in]	max	The maximum energy detected in dBm.
[in]	variance	The variance of the energy detected in dBm.

Definition at line 117 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

Function Documentation

emberInit

```
EmberStatus emberInit (void)
```

Initialize the radio and the Ember stack.

Parameters

N/A

Device configuration functions must be called before `emberInit()` is called.

Note

- The application must check the return value of this function. If the initialization fails, normal messaging functions are not available. Some failure modes are not fatal, but the application must follow certain procedures to permit recovery. Ignoring the return code results in unpredictable radio and API behavior. (In particular, problems with association will occur.)

Returns

- An `EmberStatus` value indicating successful initialization or the reason for failure.

Definition at line 141 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberTick

```
void emberTick (void)
```

A periodic tick routine that should be called in the main loop in the application.

Parameters

N/A

Definition at line 146 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberNetworkInit

```
EmberStatus emberNetworkInit (void)
```

Resume the network operation after a reboot.

Parameters

N/A

This API must be called on boot prior to ANY network operations. It initializes the networking system and attempts to resume the previous network identity and configuration. If the node was not previously joined, this routine should still be called.

If the node was previously joined to a network, it will retain its original type (e.g., coordinator, router, end device, and so on.)

`EMBER_NOT_JOINED` is returned if the node is not part of a network.

Returns

- An `EmberStatus` value that indicates one of the following:
 - successful initialization,
 - `EMBER_NOT_JOINED` if the node is not part of a network, or
 - the reason for failure.

Definition at line 165 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberStartActiveScan

```
EmberStatus emberStartActiveScan (uint16_t channel)
```

Start an active scan. [EMBER_SUCCESS](#) signals that the scan successfully started. Upon receiving a beacon, the [emberIncomingBeaconHandler\(\)](#) stack handler is called. At the end of the scanning procedure, the [emberActiveScanCompleteHandler\(\)](#) stack handler is called. Note that, while a scan can be initiated when the node is currently joined to a network, the node will generally be unable to communicate with its PAN during the scan period. In particular, time-sensitive network operations might be affected because a scan operation will prevent any network operation for the duration of the scan.

Parameters

[in]	channel	The channel to scan.
------	---------	----------------------

Possible error responses and their meanings:

- [EMBER_INVALID_CALL](#), the node is currently frequency hopping.
- [EMBER_MAC_SCANNING](#), indicates an ongoing scan.
- [EMBER_PHY_INVALID_CHANNEL](#), the specified channel is not a valid channel on the current platform.

Definition at line 186 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberSetActiveScanDuration

```
EmberStatus emberSetActiveScanDuration (uint16_t durationMs)
```

Set the time in milliseconds the node will spend listening for incoming beacons during an active scan. The default value is set based on the symbol time of the current PHY configuration according to the 802.15.4 specs.

Parameters

[in]	durationMs	The active scan duration in milliseconds. A value of 0xFFFF restores the default value.
------	------------	---

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the active scan duration was successfully set, otherwise an [EmberStatus](#) value indicating the reason of failure.

Definition at line 199 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberGetActiveScanDuration

```
uint16_t emberGetActiveScanDuration (void)
```

Get the current active scan duration in milliseconds.

Parameters

N/A

Returns

- a 16-bit integer indicating the current duration in millisecond of the active scan.

Definition at line 206 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberStartEnergyScan

```
EmberStatus emberStartEnergyScan (uint16_t channel, uint8_t samples)
```

Start an energy scan. [EMBER_SUCCESS](#) signals that the scan successfully started. At the end of the scanning procedure, the [emberEnergyScanCompleteHandler\(\)](#) stack handler is called. Note that, while a scan can be initiated when the node is currently joined to a network, the node is generally unable to communicate with its PAN during the scan period. In particular, time-sensitive network operations might be affected because a scan operation will prevent any network operation for the duration of the scan.

Parameters

[in]	channel	The channel to scan.
[in]	samples	The number of energy samples to be produced. Each sample is performed averaging the detected energy over X symbols time, whereas X depends on the selected PHY configuration and set by default to 8. The symbol time duration also depends on the selected PHY configuration.

Possible error responses and their meanings:

- [EMBER_INVALID_CALL](#), the node is currently frequency hopping.
- [EMBER_BAD_ARGUMENT](#), the samples parameter is invalid.
- [EMBER_MAC_SCANNING](#), indicates an ongoing scan.
- [EMBER_PHY_INVALID_CHANNEL](#), the specified channel is not a valid channel on the current platform.
- [EMBER_NO_BUFFERS](#), the stack doesn't have enough memory at the moment to perform the requested scan.

Definition at line 233 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberSetApplicationBeaconPayload

```
EmberStatus emberSetApplicationBeaconPayload (uint8_t payloadLength, uint8_t *payload)
```

Allow the application to set the application portion of the beacon payload. It's by default set to the empty string.

Parameters

[in]	payloadLength	The length in bytes of the application beacon payload to be set. This value can not exceed EMBER_MAC_MAX_APP_BEACON_PAYLOAD_LENGTH .
[out]	payload	A pointer to the application beacon payload to be set.

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the application beacon payload was successfully set, otherwise an [EmberStatus](#) value indicating the reason of failure.

Definition at line 248 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberJoinNetworkExtended

```
EmberStatus emberJoinNetworkExtended (EmberNodeType nodeType, EmberNodeId nodeId, EmberNetworkParameters *parameters)
```

Cause the stack to associate with the network using the specified network parameters. It can take several seconds for the stack to associate with the local network. Do not send messages until a call to the [emberStackStatusHandler\(\)](#) callback informs you that the stack is up. Notice that forming a network causes the node's security frame counter to be reset.

Parameters

[in]	nodeType	Specification of the role that this node will have in the network. This role can be EMBER_STAR_RANGE_EXTENDER , EMBER_STAR_END_DEVICE , EMBER_STAR_SLEEPY_END_DEVICE , EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE . If the node is frequency hopping, the role can not be EMBER_STAR_RANGE_EXTENDER .
[in]	nodeId	An EmberNodeId value indicating the short ID the node intends to use for addressing purposes. If this value is EMBER_NULL_NODE_ID , the network coordinator will allocate a new short address. Addresses should be allocated by the coordinator unless there is a specific need to join a network with a specific ID. If a specific ID is used, uniqueness should be guaranteed across the entire network by the application, via some out of band means. Notice that nodes of EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE require this parameter to be set to EMBER_NULL_NODE_ID .
[in]	parameters	An EmberNetworkParameters value that specifies the network parameters of the network with which the node should associate.

Returns

- An [EmberStatus](#) value that indicates either:
 - that the association process began successfully or
 - the reason for failure.

Definition at line 295 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberJoinNetwork

```
EmberStatus emberJoinNetwork (EmberNodeType nodeType, EmberNetworkParameters *parameters)
```

Cause the stack to associate with the network using the specified network parameters. The network ID is assigned by the network coordinator. It can take several seconds for the stack to associate with the local network. Do not send messages until a call to the [emberStackStatusHandler\(\)](#) callback informs you that the stack is up. Notice that joining a network causes the node's security frame counter to be reset.

Parameters

[in]	nodeType	Specification of the role that this node will have in the network. This role can be EMBER_STAR_RANGE_EXTENDER , EMBER_STAR_END_DEVICE , EMBER_STAR_SLEEPY_END_DEVICE , EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE . If the node is frequency hopping, the role can not be EMBER_STAR_RANGE_EXTENDER .
[in]	parameters	An EmberNetworkParameters value that specifies the network parameters of the network with which the node should associate.

Returns

- An [EmberStatus](#) value that indicates either:
 - that the association process began successfully or
 - the reason for failure.

Definition at line 321 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberPermitJoining

```
EmberStatus emberPermitJoining (uint8_t duration)
```

Tell the stack to allow other nodes to join the network with this node as their parent. Joining is initially disabled by default. This function may only be called after the node is part of a network and the stack is up.

Parameters

[in]	duration	A value of 0x00 disables joining. A value of 0xFF enables joining indefinitely. Any other value enables joining for that number of seconds.
------	----------	---

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the permit joining was successfully set, otherwise an [EmberStatus](#) value indicating the reason of failure.

Definition at line 337 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberJoinCommissioned

```
EmberStatus emberJoinCommissioned (EmberNodeType nodeType, EmberNodeId nodeId, EmberNetworkParameters *parameters)
```

Cause the stack to go up with the passed network parameters without performing any over-the-air message exchange. Notice that commissioning a network causes the node's security frame counter to be reset.

Parameters

[in]	nodeType	Specifies the role that this node will have in the network. The only device types allowed in the commissioning API are EMBER_DIRECT_DEVICE , EMBER_MAC_MODE_DEVICE and EMBER_MAC_MODE_SLEEPY_DEVICE .
[in]	nodeId	An EmberNodeId value that specifies the short ID the node will have. The passed node ID must be a valid short address (any value other than EMBER_NULL_NODE_ID or EMBER_BROADCAST_ADDRESS). A value of EMBER_USE_LONG_ADDRESS is allowed only when commissioning the node as EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE and will cause the node to send MAC level control messages such as data polls or beacons using long source addressing.
[in]	parameters	An EmberNetworkParameters value that specifies the network parameters of the network the node should participate in.

Returns

- An [EmberStatus](#) value that indicates either:
 - that the node successfully commissioned the passed network parameters
 - the reason for failure.

Definition at line 364 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberSetSelectiveJoinPayload

```
EmberStatus emberSetSelectiveJoinPayload (uint8_t payloadLength, uint8_t *payload)
```

When invoked at a [EMBER_STAR_COORDINATOR](#) or a [EMBER_STAR_RANGE_EXTENDER](#), it causes the stack to only accept subsequent joining nodes with matching joining payload. When invoked at a node that has not yet joined a network, it sets the joining payload that will be included in the joining process. Notice, the join payload is included in a non-standard 802.15.4 command, therefore this feature is not available for nodes operating as [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#).

Parameters

[in]	payloadLength	The length in bytes of the passed joining payload. This can not exceed EMBER_MAX_SELECTIVE_JOIN_PAYLOAD_LENGTH .
[in]	payload	A pointer to the payload to be set.

Returns

- An [EmberStatus](#) value that indicates either:

- that the node successfully set the join payload.
- the reason for failure.

Definition at line 389 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberClearSelectiveJoinPayload

```
EmberStatus emberClearSelectiveJoinPayload (void)
```

Clear the join payload previously set with the [emberSetSelectiveJoinPayload\(\)](#) API. When invoked at an [EMBER_STAR_COORDINATOR](#) or an [EMBER_STAR_RANGE_EXTENDER](#) it causes the stack to accept joining nodes with any join payload pattern. When invoked at a node that has not yet joined a network, it clears the join payload. Subsequent joining attempts will not include any join payload in the over-the-air joining handshake.

Parameters

N/A

Returns

- An [EmberStatus](#) value that indicates either:
 - that the node successfully cleared the join payload.
 - the reason for failure.

Definition at line 404 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberSetAuxiliaryAddressFilteringEntry

```
EmberStatus emberSetAuxiliaryAddressFilteringEntry (EmberNodeId nodeId, uint8_t entryIndex)
```

Set an entry in the auxiliary address filtering table at a given address. Nodes of [EMBER_DIRECT_DEVICE](#) device type can receive incoming messages destined to any of the node IDs in the auxiliary address filtering table (while also receiving messages destined to actual node ID). If the passed node ID is [EMBER_NULL_NODE_ID](#), the entry is cleared.

Parameters

[in]	nodeId	An EmberNodeId value to be added to the auxiliary address filtering table at the passed entry index.
[in]	entryIndex	The index of the auxiliary address filtering table entry to be set.

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if auxiliary address filtering table entry was successfully set. An [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the passed entry index is invalid.

Definition at line 427 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberGetAuxiliaryAddressFilteringEntry

```
EmberNodeId emberGetAuxiliaryAddressFilteringEntry (uint8_t entryIndex)
```

Retrieve the content of the auxiliary address filtering table at a given address. See [emberSetAuxiliaryAddressFilteringEntry\(\)](#) for details.

Parameters

[in]	entryIndex	The index in the auxiliary address filtering table entry to be retrieved.
------	------------	---

Returns

- An [EmberNodeId](#) value of [EMBER_NULL_NODE_ID](#) if the passed entry index is invalid or if the passed entry index refers to an unused entry. Otherwise, it returns the content of the auxiliary address filtering table entry corresponding to the passed entry index.

Definition at line 442 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberResetNetworkState

```
void emberResetNetworkState (void)
```

Forget the current network and reverts to a network status of [EMBER_NO_NETWORK](#).

Parameters

N/A		
-----	--	--

Definition at line 447 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberMacFormNetwork

```
EmberStatus emberMacFormNetwork (EmberNetworkParameters *parameters)
```

Form a new network as an [EMBER_MAC_MODE_DEVICE](#) by becoming the coordinator. This API should be used to form a compliant 802.15.4 PAN and to inter-operate with other 802.15.4 devices. Notice that forming a network causes the node's security frame counter to be reset.

Parameters

[in]	parameters	An EmberNetworkParameters value that specifies the network parameters of the network to be formed.
------	------------	--

Returns

- An [EmberStatus](#) value that indicates either the successful formation of the new network or the reason that the network formation failed.

Definition at line 461 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberMacSetPanCoordinator

```
EmberStatus emberMacSetPanCoordinator (bool isCoordinator)
```

Configure a [EMBER_MAC_MODE_DEVICE](#) node to be a PAN coordinator. Note, this only applies to nodes that have been commissioned as [EMBER_MAC_MODE_DEVICE](#).

Parameters

[in]	isCoordinator	If set to true, the node will identify itself as the PAN coordinator.
------	---------------	---

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the coordinator flag was successfully set, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 474 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberNetworkLeave

```
EmberStatus emberNetworkLeave (void)
```

Allow a star topology node that previously joined a network to leave the network. The node will notify the parent node and eventually leave the network. The application is notified that the leave procedure completed via the [emberStackStatusHandler\(\)](#) handler.

Parameters

N/A

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the node successfully initiated the network leave procedure, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 548 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberMacAddShortToLongAddressMapping

```
EmberStatus emberMacAddShortToLongAddressMapping (EmberNodeId shortId, EmberEUI64 longId)
```

Populate the short-to-long address mapping table at the MAC layer. The table is meaningful only when running as [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#). The standard 802.15.4 encryption and authentication process requires the security nonce to be populated with the source node long ID. A receiver must do the same to decrypt a secured incoming message. This short-to-long mapping table is used to decrypt a secured incoming packet from a node using short source addressing. If no entry is found in this table, the incoming message will be dropped. This table is also used to encrypt secured outgoing messages with short source addressing in case the node is sending out a secured message with a short source address other than its own.

Parameters

[in]	shortId	The short address of the [short, long] entry to be added to the table.
[in]	longId	The long address of the [short, long] entry to be added to the table.

Note

- Because the table is stored in RAM, the application should ensure it gets correctly re-populated upon reboot.
- Adding a new entry will cause the removal of existing entries matching the passed short ID or long ID.

Returns

- an [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the mapping was successfully added to the table.
 - [EMBER_INVALID_CALL](#) if the node is not running as [EMBER_MAC_MODE_DEVICE](#) or as [EMBER_MAC_MODE_SLEEPY_DEVICE](#).
 - [EMBER_TABLE_FULL](#) if the table is currently full.
 - [EMBER_NO_BUFFERS](#) if the heap does not currently have enough space for the new entry. The size of the table is controlled by the [EMBER_SECURITY_SHORT_TO_LONG_MAPPING_TABLE_SIZE](#).

Definition at line 584 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberMacClearShortToLongAddressMappings

```
EmberStatus emberMacClearShortToLongAddressMappings (void)
```

Clear the short-to-long address mapping table at the MAC layer.

Parameters

N/A		
-----	--	--

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if table was cleared, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 593 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberOfdmSetMcs

```
EmberStatus emberOfdmSetMcs (uint8_t mcs)
```

Set the MCS in case of an OFDM PHY. MCS can range from 0 to 6.

Parameters

[in]	mcs	The MCS value to set.
------	-----	-----------------------

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the MCS is valid, an [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the current PHY is not OFDM or an [EmberStatus](#) value of [EMBER_BAD_ARGUMENT](#) if the MCS value is not valid.

Definition at line 605 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberOfdmGetMcs

```
EmberStatus emberOfdmGetMcs (uint8_t *mcs)
```

Get the MCS in case of an OFDM PHY.

Parameters

[out]	mcs	A pointer to the uint8_t that should hold the current MCS value.
-------	-----	--

Returns

- an [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the current PHY is not OFDM or an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the current PHY is OFDM.

Definition at line 617 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

Macro Definition Documentation

EMBER_MAC_MAX_APP_BEACON_PAYLOAD_LENGTH

```
#define EMBER_MAC_MAX_APP_BEACON_PAYLOAD_LENGTH
```

Value:

```
16
```

The maximum length in bytes of the application beacon payload.

Definition at line 44 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_MAC_STACK_BEACON_PAYLOAD

```
#define EMBER_MAC_STACK_BEACON_PAYLOAD
```

Value:

```
"silabs-connect"
```

Definition at line 45 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_MAC_STACK_BEACON_PAYLOAD_LENGTH

```
#define EMBER_MAC_STACK_BEACON_PAYLOAD_LENGTH
```

Value:

```
14
```

The length in bytes of the stack beacon payload.

Definition at line 48 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_MAC_MAX_BEACON_FIELDS_LENGTH

```
#define EMBER_MAC_MAX_BEACON_FIELDS_LENGTH
```

Value:

```
84
```

The maximum length in bytes of the beacon fields (superframe, GTS, pending address) as per 802.15.4 specs.

Definition at line 53 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_CHILD_TABLE_AGING_DISABLED

```
#define EMBER_CHILD_TABLE_AGING_DISABLED
```

Value:

```
0x20C400
```

A special timeout value that disables aging of the child table.

Definition at line 57 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_CHILD_TABLE_MAX_TIMEOUT_S

```
#define EMBER_CHILD_TABLE_MAX_TIMEOUT_S
```

Value:

```
(EMBER_CHILD_TABLE_AGING_DISABLED - 1)
```

The maximum timeout in seconds after which a stale entry may be removed from the child table.

Definition at line 62 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_MAX_SELECTIVE_JOIN_PAYLOAD_LENGTH

```
#define EMBER_MAX_SELECTIVE_JOIN_PAYLOAD_LENGTH
```

Value:

```
50
```

The maximum length in bytes of the join payload.

Definition at line 370 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

EMBER_MAX_AUXILIARY_ADDRESS_FILTERING_TABLE_LENGTH

```
#define EMBER_MAX_AUXILIARY_ADDRESS_FILTERING_TABLE_LENGTH
```

Value:

```
2
```

The maximum number of entries the auxiliary address filtering table can hold.

Definition at line 409 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

Frequency Hopping

Frequency Hopping

API and callbacks for frequency hopping configuration.

See [network-management.h](#) for source code.

Callbacks

`void` [emberFrequencyHoppingStartClientCompleteHandler\(EmberStatus status\)](#)
 This stack handler is invoked after the application calls the [emberFrequencyHoppingStartClient\(\)](#) stack API to inform the application that the synchronization process with the server is complete. See [emberFrequencyHoppingStartClient\(\)](#) for details.

Functions

`EmberStatus` [emberFrequencyHoppingSetChannelMask\(uint8_t channelMaskLength, uint8_t *channelMask\)](#)
 Set the channel mask for frequency hopping. This API can only be invoked when the node is not frequency hopping.

`EmberStatus` [emberFrequencyHoppingStartServer\(void\)](#)
 Start the device operating as a frequency hopping server. This API can only be invoked when the node is joined to a network. Notice that the server upon starting hopping shall perform an initial advertisement across the entire channel hopping sequence. This is done to resynchronize clients in case the server was started as result of a reboot.

`EmberStatus` [emberFrequencyHoppingStartClient\(EmberNodeId serverNodeId, EmberPanId serverPanId\)](#)
 Start operating as a frequency hopping client and synchronize with the specified server. This API can be invoked on nodes that are already joined to a network (with the exception of nodes started as `EMBER_MAC_MODE_DEVICE` or `EMBER_MAC_MODE_SLEEPY_DEVICE`) and nodes that are not joined to a network yet. If the node is already performing frequency hopping, this API returns `EMBER_INVALID_CALL`. If this API returns `EMBER_SUCCESS`, the [emberFrequencyHoppingStartClientCompleteHandler\(\)](#) is invoked asynchronously to inform the application whether the node successfully synchronized with the specified server or to inform the application of the reason of failure. After the client is synced to a server, it may seamlessly perform the resynchronization process if needed. Sleepy devices in particular periodically perform the resynchronization process. If the client fails a resynchronization process, it informs the application by invoking the [emberStackStatusHandler\(\)](#) handler with `EMBER_MAC_SYNC_TIMEOUT` status. When this occurs, the client will no longer be synced to the server. The application may elect to attempt a new synchronization process by invoking this API again.

`EmberStatus` [emberFrequencyHoppingStop\(void\)](#)
 Stop frequency hopping. This API can only be invoked when the node is frequency hopping. Applicable for both server and client.

Callbacks Documentation

emberFrequencyHoppingStartClientCompleteHandler

```
void emberFrequencyHoppingStartClientCompleteHandler (EmberStatus status)
```

This stack handler is invoked after the application calls the [emberFrequencyHoppingStartClient\(\)](#) stack API to inform the application that the synchronization process with the server is complete. See [emberFrequencyHoppingStartClient\(\)](#) for details.

Parameters

[in]	status	An EmberStatus value indicating whether the synchronization process with the server was completed successfully or the reason for failure.
------	--------	---

Definition at line 733 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

Function Documentation

emberFrequencyHoppingSetChannelMask

```
EmberStatus emberFrequencyHoppingSetChannelMask (uint8_t channelMaskLength, uint8_t *channelMask)
```

Set the channel mask for frequency hopping. This API can only be invoked when the node is not frequency hopping.

Parameters

[in]	channelMaskLength	Length of the bitmap in bytes
[in]	channelMask	A pointer to a bitmap representing allowed channels for frequency hopping.

Note

- The application is responsible for applying this setting to both the server and clients.

Note

- The bitmap size needs to be at least $(EMBER_FREQUENCY_HOPPING_END_CHANNEL + 8) \gg 3$ or an error is thrown.
- The bitmap needs to be set again after stopping frequency hopping.

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the node successfully set the bitmask. An [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the node is currently performing frequency hopping. An [EmberStatus](#) value of [EMBER_BAD_ARGUMENT](#) if the resulting channel list is empty, or if channelMaskLength is shorter than expected.

Definition at line 661 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberFrequencyHoppingStartServer

```
EmberStatus emberFrequencyHoppingStartServer (void)
```

Start the device operating as a frequency hopping server. This API can only be invoked when the node is joined to a network. Notice that the server upon starting hopping shall perform an initial advertisement across the entire channel hopping sequence. This is done to resynchronize clients in case the server was started as result of a reboot.

Parameters

N/A

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the node successfully initiated frequency hopping server operations. An [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the node is not currently joined to a network or if the node is already performing frequency hopping.

Definition at line 675 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberFrequencyHoppingStartClient

```
EmberStatus emberFrequencyHoppingStartClient (EmberNodeId serverNodeId, EmberPanId serverPanId)
```

Start operating as a frequency hopping client and synchronize with the specified server. This API can be invoked on nodes that are already joined to a network (with the exception of nodes started as [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#)) and nodes that are not joined to a network yet. If the node is already performing frequency hopping, this API returns [EMBER_INVALID_CALL](#). If this API returns [EMBER_SUCCESS](#), the [emberFrequencyHoppingStartClientCompleteHandler\(\)](#) is invoked asynchronously to inform the application whether the node successfully synchronized with the specified server or to inform the application of the reason of failure. After the client is synced to a server, it may seamlessly perform the resynchronization process if needed. Sleepy devices in particular periodically perform the resynchronization process. If the client fails a resynchronization process, it informs the application by invoking the [emberStackStatusHandler\(\)](#) handler with [EMBER_MAC_SYNC_TIMEOUT](#) status. When this occurs, the client will no longer be synced to the server. The application may elect to attempt a new synchronization process by invoking this API again.

Parameters

[in]	serverNodeId	An EmberNodeId value indicating the node ID of the server to synchronize with.
[in]	serverPanId	An EmberPanId value indicating the PAN ID of the server to synchronize with. Note that this parameter is meaningful only if the node is not currently joined to any network.

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) indicating that the node successfully initiated the synchronization process with the server, otherwise an [EmberStatus](#) value indicating the reason of failure.

Definition at line 708 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberFrequencyHoppingStop

```
EmberStatus emberFrequencyHoppingStop (void)
```

Stop frequency hopping. This API can only be invoked when the node is frequency hopping. Applicable for both server and client.

Parameters

N/A		
-----	--	--

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) indicating that the node successfully stopped frequency hopping. An [EmberStatus](#) value of [EMBER_INVALID_CALL](#) if the node is not currently frequency hopping.

Definition at line 718 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

Parent Support

Parent Support

Handlers

void [emberChildJoinHandler](#)(EmberNodeType nodeType, EmberNodeId nodeId)
 Invoked at coordinator, range extender, or mac mode nodes when a new child has joined the device.

Handlers

The Application Framework implements all handlers, directly calling their associated callbacks. By default, Connect projects declare such callbacks as stubs in flex-callbacks-stubs.c. Hence, to use an enabled Connect feature, applications should replace the stub with their own implementation of the associated callback (typically in flex-callbacks.c). See UG235.04 for more info.

[EmberStatus](#) [emberPurgeIndirectMessages](#)(void)
 Purge all indirect transmissions from the indirect message queue.

[EmberStatus](#) [emberSetIndirectQueueTimeout](#)(uint32_t timeoutMs)
 Set indirect queue timeout value. The indirect queue timeout is set by default to [EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS](#).

Functions

[EmberStatus](#) [emberFormNetwork](#)(EmberNetworkParameters *parameters)
 Form a new network by becoming the coordinator. This API requires the parent-support library to be present.

[EmberStatus](#) [emberGetChildFlags](#)(EmberMacAddress *address, EmberChildFlags *flags)
 Return an [EmberChildFlags](#) bitmask indicating the child flags of the child corresponding to the passed MAC address.

[EmberStatus](#) [emberGetChildInfo](#)(EmberMacAddress *address, EmberMacAddress *addressResp, EmberChildFlags *flags)
 Return info on the child corresponding to the passed MAC address.

[EmberStatus](#) [emberRemoveChild](#)(EmberMacAddress *address)
 Remove the node corresponding to the passed MAC address from the child table.

Handlers Documentation

emberChildJoinHandler

```
void emberChildJoinHandler (EmberNodeType nodeType, EmberNodeId nodeId)
```

Invoked at coordinator, range extender, or mac mode nodes when a new child has joined the device.

Parameters

[in]	nodeType	The role of the joining device (EMBER_STAR_RANGE_EXTENDER , EMBER_STAR_END_DEVICE , EMBER_STAR_SLEEPY_END_DEVICE , EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE).
[in]	nodeId	The node ID of the joining device.

Definition at line 601 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/stack-info.h

Handlers Documentation

emberPurgeIndirectMessages

```
EmberStatus emberPurgeIndirectMessages (void)
```

Purge all indirect transmissions from the indirect message queue.

Parameters

N/A

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if all indirect messages were purged, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 299 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberSetIndirectQueueTimeout

```
EmberStatus emberSetIndirectQueueTimeout (uint32_t timeoutMs)
```

Set indirect queue timeout value. The indirect queue timeout is set by default to [EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS](#).

Parameters

N/A	timeoutMs	The timeout in milliseconds to be set.
-----	-----------	--

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the passed timeout was successfully set, or a value of [EMBER_BAD_ARGUMENT](#) if the passed value is invalid.

Definition at line 313 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

Function Documentation

emberFormNetwork

```
EmberStatus emberFormNetwork (EmberNetworkParameters *parameters)
```

Form a new network by becoming the coordinator. This API requires the parent-support library to be present.

Parameters

[in]	parameters	An EmberNetworkParameters value that specifies the network parameters of the network to be formed.
------	------------	--

Returns

- An [EmberStatus](#) value that indicates either the successful formation of the new network or an [EmberStatus](#) value indicating the reason of failure.

Definition at line 263 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h

emberGetChildFlags

```
EmberStatus emberGetChildFlags (EmberMacAddress *address, EmberChildFlags *flags)
```

Return an [EmberChildFlags](#) bitmask indicating the child flags of the child corresponding to the passed MAC address.

Parameters

[in]	address	A pointer to an EmberMacAddress that specifies the MAC address of the child.
[out]	flags	A pointer to an EmberChildFlags containing the child flags of the child corresponding to the passed MAC address.

Note

- Deprecated, use `emberGetChildInfo` instead

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the child was found in the child table, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 493 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberGetChildInfo

```
EmberStatus emberGetChildInfo (EmberMacAddress *address, EmberMacAddress *addressResp, EmberChildFlags *flags)
```

Return info on the child corresponding to the passed MAC address.

Parameters

[in]	address	A pointer to an EmberMacAddress that specifies the MAC address of the child (short or long).
[out]	addressResp	A pointer to an EmberMacAddress that returns the other address (respectively long or short).
[out]	flags	A pointer to an EmberChildFlags containing the child flags of the child corresponding to the passed MAC address.

Note

- For star coordinators, if the input address is short, the corresponding child will also be searched in the list of devices connected through range extender. Long address and additional flags for these devices are not available to the coordinator.

Note

- Both out parameters are optional. If set to NULL, the API will at least indicate if the child was found in the network.

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the child was found in the child table, [EMBER_CHILD_NOT_FOUND](#) if it was not, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 521 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

emberRemoveChild

```
EmberStatus emberRemoveChild (EmberMacAddress *address)
```

Remove the node corresponding to the passed MAC address from the child table.

Parameters

[in]	address	A pointer to an EmberMacAddress that specifies the MAC address of the child to be removed.
------	---------	--

Returns

- An [EmberStatus](#) value of [EMBER_SUCCESS](#) if the node was successfully removed from the child table, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 537 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/network-management.h`

Radio Stream

Radio Stream

Radio stream API.

License

Copyright 2018 Silicon Laboratories Inc. www.silabs.com

SPDX-License-Identifier: Zlib

The licensor of this software is Silicon Laboratories Inc.

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Connect API managing radio stream for RF testing purpose

See [radio-stream.h](#) for source code.

Functions

EmberStatus `emberStartTxStream`(EmberTxStreamParameters parameters, uint16_t channel)
Start a continuous TX stream to test RF.

EmberStatus `emberStopTxStream`(void)
Stop an RF stream in progress.

Function Documentation

emberStartTxStream

EmberStatus emberStartTxStream (EmberTxStreamParameters parameters, uint16_t channel)

Start a continuous TX stream to test RF.

Parameters

[in]	parameters	Stream mode. See EmberTxStreamParameters .
[in]	channel	RF channel.

Returns

- EMBER_INVALID_CALL if the stack can not process the request EMBER_BAD_ARGUMENT if the parameters are wrong EMBER_SUCCESS if the stream can be started

Definition at line 50 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/radio-stream.h

emberStopTxStream

EmberStatus emberStopTxStream (void)

Stop an RF stream in progress.

Parameters

N/A

Returns

- EMBER_INVALID_CALL if no stream is in progress EMBER_SUCCESS otherwise

Definition at line 58 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/radio-stream.h

Configuration

Configuration

User-configurable stack configuration macros and defaults.

Connect stack provides various interfaces to apply configuration:

- APIs to change configuration run-time
- Manufacturing tokens to change configuration during device flashing
- Macros to change configuration at compile-time

The compile time configuration macros and their default values are listed here.

The default values are always chosen to make it usable for most applications, but in some cases, you might need to change it. The recommended way is to either define the macro you need to change in the compilation command (e.g. gcc -D) or you by manipulating the configuration options in the configurator GUI.

See [ember-configuration-defaults.h](#) for source code.

Macros

#define	EMBER_HEAP_SIZE 2000	The size in bytes of the Ember heap. See Memory Buffer for more details.
#define	EMBER_CHILD_TABLE_SIZE 0	The maximum number of children supported by the device. Can be configured from 0 to 64. 11B of token space is allocated for each child in the table.
#define	EMBER_CHILD_TABLE_TOKEN_SIZE EMBER_CHILD_TABLE_SIZE	
#define	EMBER_CHILD_TIMEOUT_SEC 3600	Every child should exchange regularly some sort of traffic with the parent. Eventually, if traffic is not exchanged for a prolonged period of time, the parent may remove the child from the child table. In particular the parent shall remove the oldest stale child whenever the child table is full and there is the need of making room for a new child. Range extenders periodically exchange network-level commands with the coordinator. End devices and sleepy end devices can use emberPollForData() as keep alive mechanism, or use the Poll Plugin plugin. The maximum allowed timeout value is EMBER_CHILD_TABLE_MAX_TIMEOUT_S . Setting the timeout value to EMBER_CHILD_TABLE_AGING_DISABLED disables aging of the child table.
#define	EMBER_INDIRECT_QUEUE_SIZE 0	Indirect queue is used on a parent to store a message intended for a sleepy end device, this configures the size of that queue. Configure it to 0 if parent support plugin is not used.
#define	EMBER_MAC_OUTGOING_QUEUE_SIZE 0	MAC Outgoing packet queue is to store messages until the radio is available to send it (In most cases, the radio is unavailable because it's already transmitting). The configures the size of that queue.
#define	EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS 8000	The maximum amount of time (in milliseconds) that the MAC will hold a message for indirect transmission to a child. The maximum value is 30 seconds (30000 milliseconds).
#define	EMBER_NWK_RANGE_EXTENDER_UPDATE_PERIOD_SEC 60	The period in seconds a range extender sends an update command to the coordinator containing the list of its children.

#define	EMBER_MAC_ACK_TIMEOUT_MS 25	The ACK timeout in milliseconds. This parameter should be fine-tuned to reduce energy consumption for sleepy devices and depends on the data rate of the PHY configuration used. The maximum allowed value is 65.
#define	EMBER_RADIO_CCA_THRESHOLD -65	The CCA threshold used at the MAC layer for CSMA/CA, in dBm.
#define	EMBER_FREQUENCY_HOPPING_SEED 0	The frequency hopping channel sequence generation seed. Can be configured between 0 and 65535. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_START_CHANNEL 0	The lowest channel on the frequency hopping list. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_END_CHANNEL 24	The highest channel on the frequency hopping list. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_CHANNEL_DURATION_MS 400	The time in milliseconds to stay on each channel for frequency hopping. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_CHANNEL_GUARD_DURATION_MS 20	The time in milliseconds to guard each channel while frequency hopping. No MAC activity is allowed when entering or exiting the slot. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_SERVER_FREQ_INFO_BROADCAST_PERIOD_S 15	The duration in seconds after which the server should broadcast its frequency hopping information to allow clients to realign. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_SLEEPY_CLIENT_RESYNC_PERIOD_S 60	The duration in seconds after which a sleepy client should resync with the server if the last resync happened more than this duration ago. See the Frequency Hopping chapter of UG235.03 for more details.
#define	EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_TIMEOUT_S (100)	The maximum duration in seconds a non sleepy client would keep hopping without receiving frequency hopping information from the server, after which the synchronization with the server is deemed lost. A special value of EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_DISABLE_TIMEOUT disables this timeout.
#define	EMBER_FREQUENCY_HOPPING_SERVER_ADVERTISING_ITERATION_COUNT (3)	When a node is started a frequency hopping server, it will first advertise on all channels to resynchronize all existing clients in case the server was started as result of a reboot. This parameter defines the number of iterations over the entire hopping sequence.
#define	EMBER_COORDINATOR_FIRST_SHORT_ID_TO_BE_ASSIGNED 1	An EMBER_STAR_COORDINATOR assigns short IDs to other nodes in the star network sequentially starting from this short ID. This option provides a simple effective way to reserve an pool of short addresses for commissioning.
#define	EMBER_SECURITY_SHORT_TO_LONG_MAPPING_TABLE_SIZE 10	The size of the short-to-long address mapping table. See emberMacAddShortToLongAddressMapping for more details.
#define	EMBER_CSP_CALLBACK_MESSAGE_BUFFER_SIZE 127	The size of the the receiving buffer in CSP Callbacks.

Macro Definition Documentation

EMBER_HEAP_SIZE

```
#define EMBER_HEAP_SIZE
```

Value:

```
2000
```

The size in bytes of the Ember heap. See [Memory Buffer](#) for more details.

Warnings

- This should be configured from the Parent Support plugin options.

Definition at line 90 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_CHILD_TABLE_SIZE

```
#define EMBER_CHILD_TABLE_SIZE
```

Value:

```
0
```

The maximum number of children supported by the device. Can be configured from 0 to 64. 11B of token space is allocated for each child in the table.

Note

- It's recommended to set it to 64 for [EMBER_STAR_COORDINATOR](#), 32 for [EMBER_STAR_RANGE_EXTENDER](#) and 0 for anything else.

Warnings

- This should be configured from the Parent Support plugin options.

Definition at line 102 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_CHILD_TABLE_TOKEN_SIZE

```
#define EMBER_CHILD_TABLE_TOKEN_SIZE
```

Value:

```
EMBER_CHILD_TABLE_SIZE
```

Definition at line 105 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_CHILD_TIMEOUT_SEC

```
#define EMBER_CHILD_TIMEOUT_SEC
```

Value:

```
3600
```

Every child should exchange regularly some sort of traffic with the parent. Eventually, if traffic is not exchanged for a prolonged period of time, the parent may remove the child from the child table. In particular the parent shall remove the oldest stale child whenever the child table is full and there is the need of making room for a new child. Range extenders periodically exchange network-level commands with the coordinator. End devices and sleepy end devices can use [emberPollForData\(\)](#) as keep alive mechanism, or use the [Poll Plugin](#) plugin. The maximum allowed timeout value is

`EMBER_CHILD_TABLE_MAX_TIMEOUT_S`. Setting the timeout value to `EMBER_CHILD_TABLE_AGING_DISABLED` disables aging of the child table.

Warnings

- This should be configured from the Parent Support plugin options.

Definition at line 123 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_INDIRECT_QUEUE_SIZE

```
#define EMBER_INDIRECT_QUEUE_SIZE
```

Value:

```
0
```

Indirect queue is used on a parent to store a message intended for a sleepy end device, this configures the size of that queue. Configure it to 0 if parent support plugin is not used.

Warnings

- This should be configured from the Parent Support plugin options.

Definition at line 139 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_MAC_OUTGOING_QUEUE_SIZE

```
#define EMBER_MAC_OUTGOING_QUEUE_SIZE
```

Value:

```
0
```

MAC Outgoing packet queue is to store messages until the radio is available to send it (In most cases, the radio is unavailable because it's already transmitting). The configures the size of that queue.

Warnings

- This should be configured from the MAC Packet Queue plugin options.

Definition at line 149 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS

```
#define EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS
```

Value:

```
8000
```

The maximum amount of time (in milliseconds) that the MAC will hold a message for indirect transmission to a child. The maximum value is 30 seconds (30000 milliseconds).

Warnings

- This should be configured from the Parent Support plugin options.

Definition at line 159 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_NWK_RANGE_EXTENDER_UPDATE_PERIOD_SEC

```
#define EMBER_NWK_RANGE_EXTENDER_UPDATE_PERIOD_SEC
```

Value:

```
60
```

The period in seconds a range extender sends an update command to the coordinator containing the list of its children.

- This option is only used on [EMBER_STAR_RANGE_EXTENDER](#) device.

Definition at line 168 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_MAC_ACK_TIMEOUT_MS

```
#define EMBER_MAC_ACK_TIMEOUT_MS
```

Value:

```
25
```

The ACK timeout in milliseconds. This parameter should be fine-tuned to reduce energy consumption for sleepy devices and depends on the data rate of the PHY configuration used. The maximum allowed value is 65.

Definition at line 177 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_RADIO_CCA_THRESHOLD

```
#define EMBER_RADIO_CCA_THRESHOLD
```

Value:

```
-65
```

The CCA threshold used at the MAC layer for CSMA/CA, in dBm.

Warnings

- This should be configured from the Connect Stack plugin options.

Definition at line 185 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_SEED

```
#define EMBER_FREQUENCY_HOPPING_SEED
```

Value:

```
0
```

The frequency hopping channel sequence generation seed. Can be configured between 0 and 65535. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 194 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_START_CHANNEL

```
#define EMBER_FREQUENCY_HOPPING_START_CHANNEL
```

Value:

```
0
```

The lowest channel on the frequency hopping list. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 202 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_END_CHANNEL

```
#define EMBER_FREQUENCY_HOPPING_END_CHANNEL
```

Value:

```
24
```

The highest channel on the frequency hopping list. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 210 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_CHANNEL_DURATION_MS

```
#define EMBER_FREQUENCY_HOPPING_CHANNEL_DURATION_MS
```

Value:

```
400
```

The time in milliseconds to stay on each channel for frequency hopping. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 218 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_CHANNEL_GUARD_DURATION_MS

```
#define EMBER_FREQUENCY_HOPPING_CHANNEL_GUARD_DURATION_MS
```

Value:

```
20
```

The time in milliseconds to guard each channel while frequency hopping. No MAC activity is allowed when entering or exiting the slot. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 227 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_SERVER_FREQ_INFO_BROADCAST_PERIOD_S

```
#define EMBER_FREQUENCY_HOPPING_SERVER_FREQ_INFO_BROADCAST_PERIOD_S
```

Value:

```
15
```

The duration in seconds after which the server should broadcast its frequency hopping information to allow clients to realign. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 236 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_SLEEPY_CLIENT_RESYNC_PERIOD_S

```
#define EMBER_FREQUENCY_HOPPING_SLEEPY_CLIENT_RESYNC_PERIOD_S
```

Value:

```
60
```

The duration in seconds after which a sleepy client should resync with the server if the last resync happened more than this duration ago. See the Frequency Hopping chapter of UG235.03 for more details.

Definition at line 245 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_TIMEOUT_S

```
#define EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_TIMEOUT_S
```

Value:

```
(100)
```

The maximum duration in seconds a non sleepy client would keep hopping without receiving frequency hopping information from the server, after which the synchronization with the server is deemed lost. A special value of [EMBER_FREQUENCY_HOPPING_ALWAYS_ON_CLIENT_SYNC_DISABLE_TIMEOUT](#) disables this timeout.

Definition at line 256 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h`

EMBER_FREQUENCY_HOPPING_SERVER_ADVERTISING_ITERATION_COUNT

```
#define EMBER_FREQUENCY_HOPPING_SERVER_ADVERTISING_ITERATION_COUNT
```

Value:

```
(3)
```

When a node is started a frequency hopping server, it will first advertise on all channels to resynchronize all existing clients in case the server was started as result of a reboot. This parameter defines the number of iterations over the entire hopping sequence.

Definition at line 266 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h

EMBER_COORDINATOR_FIRST_SHORT_ID_TO_BE_ASSIGNED

```
#define EMBER_COORDINATOR_FIRST_SHORT_ID_TO_BE_ASSIGNED
```

Value:

```
1
```

An [EMBER_STAR_COORDINATOR](#) assigns short IDs to other nodes in the star network sequentially starting from this short ID. This option provides a simple effective way to reserve a pool of short addresses for commissioning.

Definition at line 276 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h

EMBER_SECURITY_SHORT_TO_LONG_MAPPING_TABLE_SIZE

```
#define EMBER_SECURITY_SHORT_TO_LONG_MAPPING_TABLE_SIZE
```

Value:

```
10
```

The size of the short-to-long address mapping table. See [emberMacAddShortToLongAddressMapping](#) for more details.

- This table is only used for [EMBER_MAC_MODE_DEVICE](#) and [EMBER_MAC_MODE_SLEEPY_DEVICE](#), but the memory will be allocated on all device types.

Definition at line 287 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h

EMBER_CSP_CALLBACK_MESSAGE_BUFFER_SIZE

```
#define EMBER_CSP_CALLBACK_MESSAGE_BUFFER_SIZE
```

Value:

```
127
```

The size of the the receiving buffer in CSP Callbacks.

- This must be set high enough depending on the PHY to prevent buffer overflow. In SUN PHYs (OFDM and FSK), the max message length is 2048. Considering the impact of this parameter on the stack size, this needs to be fine tuned according the need of the application

Definition at line 298 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/ember-configuration-defaults.h

Status Codes

Status Codes

Return-code definitions for Connect stack API functions.

Many Connect API functions return an [EmberStatus](#) value to indicate the success or failure of the call.

Return codes are one byte long.

This page documents the possible status codes and their meanings.

See [error-def.h](#) for source code.

See also [error.h](#) for information on how the values for the return codes are built up from these definitions. The file [error-def.h](#) is separated from [error.h](#) because utilities will use this file to parse the return codes.

Note

- Do not include [error-def.h](#) directly. It is included by [error.h](#) inside an enum typedef, which is in turn included by [ember.h](#).

Enumerations

```

enum EmberStatus {
    EMBER_SUCCESS = 0x00
    EMBER_ERR_FATAL = 0x01
    EMBER_BAD_ARGUMENT = 0x02
    EMBER_EEPROM_MFG_STACK_VERSION_MISMATCH = 0x04
    EMBER_INVALID_CALL = 0x70
    EMBER_EEPROM_MFG_VERSION_MISMATCH = 0x06
    EMBER_EEPROM_STACK_VERSION_MISMATCH = 0x07
    EMBER_NO_BUFFERS = 0x18
    EMBER_SERIAL_INVALID_BAUD_RATE = 0x20
    EMBER_SERIAL_INVALID_PORT = 0x21
    EMBER_SERIAL_TX_OVERFLOW = 0x22
    EMBER_SERIAL_RX_OVERFLOW = 0x23
    EMBER_SERIAL_RX_FRAME_ERROR = 0x24
    EMBER_SERIAL_RX_PARITY_ERROR = 0x25
    EMBER_SERIAL_RX_EMPTY = 0x26
    EMBER_SERIAL_RX_OVERRUN_ERROR = 0x27
    EMBER_MAC_NO_DATA = 0x31
    EMBER_MAC_SYNC_TIMEOUT = 0x33
    EMBER_MAC_SYNC_WRONG_SEED = 0x34
    EMBER_MAC_SECURITY_FAILED = 0x35
    EMBER_MAC_UNKNOWN_DESTINATION = 0x37
    EMBER_MAC_SECURITY_NOT_SUPPORTED = 0x38
    EMBER_MAC_TRANSMIT_QUEUE_FULL = 0x39
    EMBER_MAC_ACK_HEADER_TYPE = 0x3B
    EMBER_MAC_SCANNING = 0x3D
    EMBER_MAC_BUSY = 0x3E
    EMBER_MAC_NO_ACK_RECEIVED = 0x40
    EMBER_MAC_INDIRECT_TIMEOUT = 0x41
    EMBER_MAC_INDIRECT_MESSAGE_PURGED = 0x42
    EMBER_SIM_EEPROM_ERASE_PAGE_GREEN = 0x43
    EMBER_SIM_EEPROM_ERASE_PAGE_RED = 0x44
    EMBER_SIM_EEPROM_FULL = 0x45
    EMBER_SIM_EEPROM_INIT_2_FAILED = 0x49
    EMBER_SIM_EEPROM_INIT_3_FAILED = 0x4A
    EMBER_SIM_EEPROM_REPAIRING = 0x4D
    EMBER_ERR_FLASH_WRITE_INHIBITED = 0x46
    EMBER_ERR_FLASH_VERIFY_FAILED = 0x47
    EMBER_ERR_FLASH_PROG_FAIL = 0x4B
    EMBER_MESSAGE_TOO_LONG = 0x74
    EMBER_ADC_CONVERSION_DONE = 0x80
    EMBER_ADC_CONVERSION_BUSY = 0x81
    EMBER_ADC_CONVERSION_DEFERRED = 0x82
    EMBER_ADC_NO_CONVERSION_PENDING = 0x84
    EMBER_SLEEP_INTERRUPTED = 0x85
    EMBER_PHY_TX_INCOMPLETE = 0x89
    EMBER_PHY_INVALID_CHANNEL = 0x8A
    EMBER_PHY_INVALID_POWER = 0x8B
    EMBER_PHY_TX_BUSY = 0x8C
    EMBER_PHY_TX_CCA_FAIL = 0x8D
    EMBER_PHY_CALIBRATING = 0x8E
    EMBER_PHY_ACK_RECEIVED = 0x8F
    EMBER_NETWORK_UP = 0x90
    EMBER_NETWORK_DOWN = 0x91
    EMBER_JOIN_SCAN_FAILED = 0x92
    EMBER_JOIN_FAILED = 0x94
    EMBER_JOIN_DENIED = 0x95
    EMBER_JOIN_TIMEOUT = 0x96
    EMBER_NO_VALID_BEACONS = 0xAB
    EMBER_SECURITY_DATA_INVALID = 0xBD
    EMBER_NOT_JOINED = 0x93
    EMBER_TABLE_FULL = 0xB4
    EMBER_LIBRARY_NOT_PRESENT = 0xB5
    EMBER_CHILD_NOT_FOUND = 0xB6
    EMBER_NVM3_ERR_OPENED_WITH_OTHER_PARAMETERS = 0xC1
    EMBER_NVM3_ERR_ALIGNMENT_INVALID = 0xC2
    EMBER_NVM3_ERR_SIZE_TOO_SMALL = 0xC3
    EMBER_NVM3_ERR_PAGE_SIZE_NOT_SUPPORTED = 0xC4
    EMBER_NVM3_ERR_TOKEN_INIT = 0xC5
    EMBER_NVM3_ERR_UPGRADE = 0xC6

```

```

EMBER_NVM3_ERR_UNKNOWN = 0xC7
EMBER_NCP_UNKNOWN_COMMAND_ID
= 0xD0
EMBER_APPLICATION_ERROR_0 = 0xF0
EMBER_APPLICATION_ERROR_1 = 0xF1
EMBER_APPLICATION_ERROR_2 = 0xF2
EMBER_APPLICATION_ERROR_3 = 0xF3
EMBER_APPLICATION_ERROR_4 = 0xF4
EMBER_APPLICATION_ERROR_5 = 0xF5
EMBER_APPLICATION_ERROR_6 = 0xF6
EMBER_APPLICATION_ERROR_7 = 0xF7
EMBER_APPLICATION_ERROR_8 = 0xF8
EMBER_APPLICATION_ERROR_9 = 0xF9
EMBER_APPLICATION_ERROR_10 =
0xFA
EMBER_APPLICATION_ERROR_11 =
0xFB
EMBER_APPLICATION_ERROR_12 =
0xFC
EMBER_APPLICATION_ERROR_13 =
0xFD
EMBER_APPLICATION_ERROR_14 =
0xFE
EMBER_APPLICATION_ERROR_15 =
0xFF
}

```

Enumeration Documentation

EmberStatus

EmberStatus

Enumerator

	Enumerator
EMBER_SUCCESS	The generic "no error" message.
EMBER_ERR_FATAL	The generic "fatal error" message.
EMBER_BAD_ARGUMENT	An invalid value was passed as an argument to a function.
EMBER_EEPROM_MFG_STACK_VERSION_MISMATCH	The manufacturing and stack token format in non-volatile memory is different than what the stack expects (returned at initialization).
EMBER_INVALID_CALL	The API call is not allowed given the current state of the stack.
EMBER_EEPROM_MFG_VERSION_MISMATCH	The manufacturing token format in non-volatile memory is different than what the stack expects (returned at initialization).
EMBER_EEPROM_STACK_VERSION_MISMATCH	The stack token format in non-volatile memory is different than what the stack expects (returned at initialization).
EMBER_NO_BUFFERS	There are no more buffers (either in the stack heap or the queue used by the associated module, such as indirect queue).
EMBER_SERIAL_INVALID_BAUD_RATE	Specified an invalid baud rate.
EMBER_SERIAL_INVALID_PORT	Specified an invalid serial port.
EMBER_SERIAL_TX_OVERFLOW	Tried to send too much data.
EMBER_SERIAL_RX_OVERFLOW	There was not enough space to store a received character and some characters were dropped.
EMBER_SERIAL_RX_FRAME_ERROR	Detected a UART framing error.
EMBER_SERIAL_RX_PARITY_ERROR	Detected a UART parity error.
EMBER_SERIAL_RX_EMPTY	There is no received data to process.

EMBER_SERIAL_RX_OVERRUN_ERROR	The receive interrupt was not handled in time and some characters were dropped.
EMBER_MAC_NO_DATA	No pending data exists for device doing a data poll.
EMBER_MAC_SYNC_TIMEOUT	The frequency hopping client failed the frequency hopping synchronization procedure. It timed out trying to reach the frequency hopping server.
EMBER_MAC_SYNC_WRONG_SEED	The frequency hopping client failed the frequency hopping synchronization procedure. The server is currently using a different seed.
EMBER_MAC_SECURITY_FAILED	MAC security operation failed.
EMBER_MAC_UNKNOWN_DESTINATION	Transmission failed: the destination node does not appear in the neighbor or child tables.
EMBER_MAC_SECURITY_NOT_SUPPORTED	Transmission failed: the local node does not support security or a secured transmission has been requested to a child that does not support security.
EMBER_MAC_TRANSMIT_QUEUE_FULL	The MAC transmit queue is full.
EMBER_MAC_ACK_HEADER_TYPE	MAC ACK header received.
EMBER_MAC_SCANNING	The MAC can't complete this task because it is scanning.
EMBER_MAC_BUSY	The requested operation cannot be completed because MAC is currently busy performing a high-priority task.
EMBER_MAC_NO_ACK_RECEIVED	Expected to receive an ACK following the transmission, but the MAC level ACK was never received.
EMBER_MAC_INDIRECT_TIMEOUT	Indirect data message timed out before polled.
EMBER_MAC_INDIRECT_MESSAGE_PURGED	Transmission failed: the indirect message was purged because the destination child has been removed or updated, or because emberPurgeIndirectMessages() was called.
EMBER_SIM_EEPROM_ERASE_PAGE_GREEN	The Simulated EEPROM is telling the application that there is at least one flash page to be erased. The GREEN status means the current page has not filled above the ::ERASE_CRITICAL_THRESHOLD.
EMBER_SIM_EEPROM_ERASE_PAGE_RED	The Simulated EEPROM is telling the application that there is at least one flash page to be erased. The RED status means the current page has filled above the ::ERASE_CRITICAL_THRESHOLD.
EMBER_SIM_EEPROM_FULL	The Simulated EEPROM has run out of room to write any new data and the data trying to be set has been lost. This error code is the result of ignoring the EMBER_SIM_EEPROM_ERASE_PAGE_RED error code.
EMBER_SIM_EEPROM_INIT_2_FAILED	Attempt 2 to initialize the Simulated EEPROM has failed.
EMBER_SIM_EEPROM_INIT_3_FAILED	Attempt 3 to initialize the Simulated EEPROM has failed.
EMBER_SIM_EEPROM_REPAIRING	The Simulated EEPROM is repairing itself.
EMBER_ERR_FLASH_WRITE_INHIBITED	A fatal error has occurred while trying to write data to the flash. The target memory attempting to be programmed is already programmed. The flash write routines were asked to flip a bit from a 0 to 1, which is physically impossible and the write was therefore inhibited. The data in the flash cannot be trusted after this error.
EMBER_ERR_FLASH_VERIFY_FAILED	A fatal error has occurred while trying to write data to the flash and the write verification has failed. The data in the flash cannot be trusted after this error, and it is possible this error is the result of exceeding the life cycles of the flash.
EMBER_ERR_FLASH_PROG_FAIL	A fatal error has occurred while trying to write data to the flash, possibly due to write protection or an invalid address. The data in the flash cannot be trusted after this error, and it is possible this error is the result of exceeding the life cycles of the flash.
EMBER_MESSAGE_TOO_LONG	The message to be transmitted is too big to fit into a single over-the-air packet.

EMBER_ADC_CONVERSION_DONE	Conversion is complete.
EMBER_ADC_CONVERSION_BUSY	Conversion cannot be done because a request is being processed.
EMBER_ADC_CONVERSION_DEFERRED	Conversion is deferred until the current request has been processed.
EMBER_ADC_NO_CONVERSION_PENDING	No results are pending.
EMBER_SLEEP_INTERRUPTED	Sleeping (for a duration) has been abnormally interrupted and exited prematurely.
EMBER_PHY_TX_INCOMPLETE	The transmit hardware did not finish transmitting a packet.
EMBER_PHY_INVALID_CHANNEL	An unsupported channel setting was specified.
EMBER_PHY_INVALID_POWER	An unsupported power setting was specified.
EMBER_PHY_TX_BUSY	The requested operation cannot be completed because the radio is currently busy, either transmitting a packet or performing calibration.
EMBER_PHY_TX_CCA_FAIL	The transmit attempt failed because all CCA attempts indicated that the channel was busy.
EMBER_PHY_CALIBRATING	The requested operation cannot be completed because the stack has triggered a radio calibration. Wait for about one second for it to complete.
EMBER_PHY_ACK_RECEIVED	The expected ACK was received after the last transmission.
EMBER_NETWORK_UP	The stack software has completed initialization required to be in a network and is ready to send and receive packets over the air.
EMBER_NETWORK_DOWN	The network is not operating.
EMBER_JOIN_SCAN_FAILED	The node failed to initiate the scanning process during the joining process.
EMBER_JOIN_FAILED	An attempt to join a network failed.
EMBER_JOIN_DENIED	An attempt to join a network was rejected.
EMBER_JOIN_TIMEOUT	The node timed out waiting for a response during the joining process.
EMBER_NO_VALID_BEACONS	An attempt to join or rejoin the network failed because no valid beacons was received by the joining node.
EMBER_SECURITY_DATA_INVALID	The security data provided was not valid, or an integrity check failed.
EMBER_NOT_JOINED	The node has not joined a network. Returned by emberNetworkInit() if there was no connection data saved in tokens.
EMBER_TABLE_FULL	There are no empty entries left in the table.
EMBER_LIBRARY_NOT_PRESENT	The requested function cannot be executed because the library (plugin) that contains the necessary functionality is not present.
EMBER_CHILD_NOT_FOUND	The requested NodeId has not been found in the child list or grandchildren list (start network only).
EMBER_NVM3_ERR_OPENED_WITH_OTHER_PARAMETERS	NVM3 is telling the application that the initialization was aborted as the NVM3 instance was already opened with other parameters.
EMBER_NVM3_ERR_ALIGNMENT_INVALID	NVM3 is telling the application that the initialization was aborted as the NVM3 instance is not aligned properly in memory.

EMBER_NVM3_ERR_SIZE_TOO_SMALL	NVM3 is telling the application that the initialization was aborted as the size of the NVM3 instance is too small.
EMBER_NVM3_ERR_PAGE_SIZE_NOT_SUPPORTED	NVM3 is telling the application that the initialization was aborted as the NVM3 page size is not supported.
EMBER_NVM3_ERR_TOKEN_INIT	NVM3 is telling the application that there was an error initializing some of the tokens.
EMBER_NVM3_ERR_UPGRADE	NVM3 is telling the application there has been an error when attempting to upgrade SimEE tokens.
EMBER_NVM3_ERR_UNKNOWN	NVM3 is telling the application that there has been an unknown error.
EMBER_NCP_UNKNOWN_COMMAND_ID	The NCP does not know the command ID that the host sent. This can correspond to a version mismatch, where an API is available on the host but not on the NCP.
EMBER_APPLICATION_ERROR_0	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_1	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_2	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_3	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_4	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_5	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_6	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_7	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_8	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_9	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_10	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_11	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_12	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_13	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_14	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.
EMBER_APPLICATION_ERROR_15	This error is reserved for customer application use. This will never be returned from any portion of the network stack or HAL.

Definition at line 58 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/error-def.h

Stack Tokens

Stack Tokens

Definitions for stack tokens.

Stack tokens are used by the stack to store information in non-volatile memory. A typical use case is to store the network information, so after an accidental reset it can be part of the network without going through the association process again.

Note

- For the application tokens, refer to [Token Access](#) and AN1154.

Warnings

- While stack tokens can be accessed through the [Token Access](#) API, they **must not be written directly**. Most stack tokens have APIs to read/write them. This documentation is intended for those who need more information on the internal details of the connect stack.

See [token-stack.h](#) for source code.

Modules

[tokTypeStackKey](#)

[tokTypeStackNodeData](#)

[tokTypeStackChildTableEntry](#)

Token types

The types used for each stack token.

typedef uint16_t	tokTypeStackNvdataVersion Type for TOKEN_STACK_NVDATA_VERSION. Keeps the version number of stack tokens.
typedef uint32_t	tokTypeStackNonceCounter Type for TOKEN_STACK_NONCE_COUNTER. Used to make sure that Nonce used for security is not repeated even after unexpected reboot.
typedef uint32_t	tokTypeStackKeyID Type for TOKEN_STACK_SECURITY_KEY_ID. Used to make sure that Nonce used for security is not repeated even after unexpected reboot.
typedef uint16_t	tokTypeStackLastAllocatedId Type for TOKEN_STACK_LAST_ASSIGNED_ID. Stores the last assigned Nodeld if the device is EMBER_STAR_COORDINATOR .
typedef uint32_t	tokTypeStackBootCounter Type for TOKEN_STACK_BOOT_COUNTER. Increments at boot (during emberInit()).
typedef EmberEUI64	tokTypeParentLongId Type for TOKEN_STACK_PARENT_LONG_ID. Stores the Long Id of the parent of this device. Only used for EMBER_MAC_MODE_DEVICE and EMBER_MAC_MODE_SLEEPY_DEVICE device types.

Macros

```
#define CURRENT_STACK_TOKEN_VERSION 0x03FC
```

The current version number of the stack tokens. MSB is the version. LSB is a complement.

Token types Documentation

tokTypeStackNvdataVersion

```
typedef uint16_t tokTypeStackNvdataVersion
```

Type for TOKEN_STACK_NVDATA_VERSION. Keeps the version number of stack tokens.

Definition at line 220 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeStackNonceCounter

```
typedef uint32_t tokTypeStackNonceCounter
```

Type for TOKEN_STACK_NONCE_COUNTER. Used to make sure that Nonce used for security is not repeated even after unexpected reboot.

Definition at line 226 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeStackKeyID

```
typedef uint32_t tokTypeStackKeyID
```

Type for TOKEN_STACK_SECURITY_KEY_ID. Used to make sure that Nonce used for security is not repeated even after unexpected reboot.

Definition at line 241 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeStackLastAllocatedId

```
typedef uint16_t tokTypeStackLastAllocatedId
```

Type for TOKEN_STACK_LAST_ASSIGNED_ID. Stores the last assigned NodeId if the device is [EMBER_STAR_COORDINATOR](#).

Definition at line 272 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeStackBootCounter

```
typedef uint32_t tokTypeStackBootCounter
```

Type for TOKEN_STACK_BOOT_COUNTER. Increments at boot (during [emberInit\(\)](#)).

Definition at line 278 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeParentLongId

```
typedef EmberEUI64 tokTypeParentLongId
```

Type for TOKEN_STACK_PARENT_LONG_ID. Stores the Long Id of the parent of this device. Only used for [EMBER_MAC_MODE_DEVICE](#) and [EMBER_MAC_MODE_SLEEPY_DEVICE](#) device types.

Definition at line 285 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

Macro Definition Documentation

CURRENT_STACK_TOKEN_VERSION

```
#define CURRENT_STACK_TOKEN_VERSION
```

Value:

```
0x03FC
```

The current version number of the stack tokens. MSB is the version. LSB is a complement.

See [hal/micro/token.h](#) for a more complete explanation.

Definition at line 206 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

tokTypeStackKey

Type for TOKEN_STACK_SECURITY_KEY. Keeps the security key for MAC layer security.

Public Attributes

uint8_t [networkKey](#)

Public Attribute Documentation

networkKey

```
uint8_t tokTypeStackKey::networkKey[16]
```

The key itself

Definition at line 234 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

tokTypeStackNodeData

Type for TOKEN_STACK_NODE_DATA. Generic information of the node is stored in this token.

Public Attributes

uint16_t	panId
int16_t	radioTxPower
uint16_t	radioFreqChannel
uint8_t	nodeType
uint16_t	nodeId
uint16_t	parentId

Public Attribute Documentation

panId

```
uint16_t tokTypeStackNodeData::panId
```

The PanId of the device

Definition at line 249 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

radioTxPower

```
int16_t tokTypeStackNodeData::radioTxPower
```

The TX power configured for the device in deci-dBm

Definition at line 250 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

radioFreqChannel

```
uint16_t tokTypeStackNodeData::radioFreqChannel
```

The radio channel configured for the device

Definition at line 251 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

nodeType

```
uint8_t tokTypeStackNodeData::nodeType
```

The [EmberNodeType](#) configured for the device

Definition at line 252 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

nodeId

```
uint16_t tokTypeStackNodeData::nodeId
```

The nodeId (short address) of the device

Definition at line 253 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

parentId

```
uint16_t tokTypeStackNodeData::parentId
```

The nodeId of the device's parent, if any

Definition at line 254 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h

tokTypeStackChildTableEntry

Type of an element of TOKEN_STACK_CHILD_TABLE (indexed token). Keeps children information of a device, which has parent support enabled.

Public Attributes

[EmberEUI64](#) [longId](#)

[EmberNodeId](#) [shortId](#)

[uint8_t](#) [flags](#)

Public Attribute Documentation

longId

```
EmberEUI64 tokTypeStackChildTableEntry::longId
```

The Long Id of the child

Definition at line 263 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

shortId

```
EmberNodeId tokTypeStackChildTableEntry::shortId
```

The NodeId of the child

Definition at line 264 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

flags

```
uint8_t tokTypeStackChildTableEntry::flags
```

Flags for the child required by the stack

Definition at line 265 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/config/token-stack.h`

Event Scheduling

Event Scheduling

Scheduling events for future execution.

See [Event Scheduling](#) for documentation. These macros implement an event abstraction that allows the application to schedule code to run after a specified time interval. An event consists of a procedure to be called at some point in the future and a control object that determines which procedure should be called. Events are also useful when an ISR needs to initiate an action that should run outside the ISR context.

See [event.h](#) for source code.

Note that, while not required, it is recommended that the event-handling procedure explicitly define the recurrence of the next event, either by rescheduling via some kind of `emberEventControlSetDelayXX()` call or by deactivating via a call to `emberEventControlSetInactive()`.

When the handler does not explicitly reschedule or cancel the event, the default behavior of the event control system is to keep the event immediately active as if the handler function had called `emberEventControlSetActive(someEvent)` or `emberEventControlSetDelayMS(someEvent, 0)`.

The base time units for events are ticks. A tick equals 1 ms on every platform supported by Connect. Note, however, that the accuracy of the base tick depends on the timer source, which by default is the LF RC oscillator on EFR32 platforms.

Furthermore, the scheduled delay is the minimum delay. If `emberRunEvents()` or `emberRunTask()` are not called frequently enough, the actual delay may be longer than the scheduled delay.

Additionally, the APIs for quarter second and minute delays (`emberEventControlSetDelayQS()` and `emberEventControlSetDelayMinutes()`) use "binary" units. One quarter second is 256 ticks and one minute is 65536 ticks. These APIs are therefore doesn't actually mean a quarter of second or a minute on platforms supported by Connect.

However, in the future, Connect support might become available on platforms where one tick is not exactly 1 ms. For example, on the EM357 SoC, 1 s is 1024 ticks, so each tick is $1000 / 1024 = \sim 0.98$ milliseconds. If you need platform independent accurate delays, use the macros `MILLISECOND_TICKS_PER_SECOND` and `MILLISECOND_TICKS_PER_MINUTE`. For example, calling `emberEventControlSetDelayMS(someEvent, 3 * MILLISECOND_TICKS_PER_MINUTE)` will delay for 3 minutes on any platform.

The following are brief usage examples.

```

EmberEventControl delayEvent;
EmberEventControl signalEvent;
EmberEventControl periodicEvent;

void delayEventHandler(void)
{
    // Disable this event until its next use.
    emberEventControlSetInactive(delayEvent);
}

void signalEventHandler(void)
{
    // Disable this event until its next use.
    emberEventControlSetInactive(signalEvent);

    // Sometimes an action has to occur 100 ms later.
    if (somethingIsExpected)
        emberEventControlSetDelayMS(delayEvent, 100);
}

void periodicEventHandler(void)
{
    emberEventControlSetDelayQS(periodicEvent, 4);
}

void somelsr(void)
{
    // Set the signal event to run at the first opportunity.
    emberEventControlSetActive(signalEvent);
}

// Put the controls and handlers in an array. They will be run in
// this order (this is usually generated)
EmberEventData events[] =
{
    { &delayEvent, delayEventHandler },
    { &signalEvent, signalEventHandler },
    { &periodicEvent, periodicEventHandler },
    { NULL, NULL } // terminator
};

void main(void)
{
    // Cause the periodic event to occur once a second.
    emberEventControlSetDelayQS(periodicEvent, 4);

    while (true) {
        emberRunEvents(events);
    }
}

```

Time Manipulation Macros

- void `sl_event_control_set_active`(EmberEventControl *event)
Set `EmberEventControl` to run at the next available opportunity.
- void `emberEventControlSetDelayMS`(EmberEventControl *event, uint32_t delay)
Set `EmberEventControl` to run some milliseconds in the future.
- uint32_t `emberEventControlGetRemainingMS`(EmberEventControl *event)
Check when the event is scheduled to run.

void	emberRunEvents (EmberEventData *events) Start an event handler if anything is scheduled when this function is called.
void	emberRunTask (EmberTaskId taskId) Start an event handler if there is anything scheduled at the moment this function is called.
uint32_t	emberMsToNextEvent (EmberEventData *events, uint32_t maxMs) Check when the next event is scheduled to run.
uint32_t	emberMsToNextEventExtended (EmberEventData *events, uint32_t maxMs, uint8_t *returnIndex) Check when the next event is scheduled to run.
uint32_t	emberMsToNextStackEvent (void) Check when the next stack event is scheduled to run.
EmberTaskId	emberTaskInit (EmberEventData *events) Initialize a task for managing events and processor idling state.
bool	emberMarkTaskIdle (EmberTaskId taskId) Try to idle the CPU, unless any events in any tasks are pending.
void	emTaskEnableIdling (bool allow) Enable or disable idling.
void	emMarkTaskActive (EmberTaskId taskId) Calling it indicates that a task has something to do, so it should prevent the CPU from idling until emberMarkTaskIdle is next called on this task.
#define	elapsedTimeInt8u (oldTime, newTime) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
#define	elapsedTimeInt16u (oldTime, newTime) Returns the elapsed time between two 16 bit values. Result may not be valid if the time samples differ by more than 32767.
#define	elapsedTimeInt32u (oldTime, newTime) Returns the elapsed time between two 32 bit values. Result may not be valid if the time samples differ by more than 2147483647.
#define	MAX_INT8U_VALUE (0xFF) Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.
#define	HALF_MAX_INT8U_VALUE (0x80) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
#define	timeGTorEqualInt8u (t1, t2) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
#define	MAX_INT16U_VALUE (0xFFFF) Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.
#define	HALF_MAX_INT16U_VALUE (0x8000) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
#define	timeGTorEqualInt16u (t1, t2) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
#define	MAX_INT32U_VALUE (0xFFFFFFFFUL) Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.
#define	HALF_MAX_INT32U_VALUE (0x80000000UL) Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

```
#define timeGTorEqualInt32u (t1, t2)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_SECOND 1000UL
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_DECISECOND (MILLISECOND_TICKS_PER_SECOND / 10)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_QUARTERSECOND (MILLISECOND_TICKS_PER_SECOND >> 2)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_MINUTE (60UL * MILLISECOND_TICKS_PER_SECOND)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_HOUR (60UL * MILLISECOND_TICKS_PER_MINUTE)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MILLISECOND_TICKS_PER_DAY (24UL * MILLISECOND_TICKS_PER_HOUR)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define EMBER_TASK_COUNT (3)
The number of event tasks that can be used to schedule and run events. Connect stack requires one, while another is used for Application Framework events.

#define emberEventControlSetInactive (control)
Set EmberEventControl as inactive (no pending event).

#define emberEventControlGetActive (control)
Check whether EmberEventControl is currently active. An event is considered active if it is set to run some time in the future (activated by emberEventControlSetActive\(\), emberEventControlSetDelayMS\(\) or any other emberEventControlSetDelay\* functions)

#define emberEventControlSetActive (control)
Set EmberEventControl to run at the next available opportunity.

#define EMBER_MAX_EVENT_CONTROL_DELAY_MS (HALF_MAX_INT32U_VALUE - 1)
The maximum delay that may be passed to emberEventControlSetDelayMS\(\).

#define emberEventControlSetDelayMS (control, delay)
Set EmberEventControl to run some milliseconds in the future.

#define EMBER_MAX_EVENT_CONTROL_DELAY_QS (EMBER_MAX_EVENT_CONTROL_DELAY_MS >> 8)
The maximum delay that may be passed to emberEventControlSetDelayQS\(\).

#define emberEventControlSetDelayQS (control, delay)
Set EmberEventControl to run some quarter seconds in the future.

#define EMBER_MAX_EVENT_CONTROL_DELAY_MINUTES (EMBER_MAX_EVENT_CONTROL_DELAY_MS >> 16)
The maximum delay that may be passed to emberEventControlSetDelayMinutes\(\).

#define emberEventControlSetDelayMinutes (control, delay)
Set EmberEventControl to run some minutes in the future.

#define emberEventControlGetRemainingMS (control)
Check when the event is scheduled to run.

#define emberTaskEnableIdling (allow)
Enable or disable idling.

#define emberMarkTaskActive (taskid)
Calling it indicates that a task has something to do, so it should prevent the CPU from idling until emberMarkTaskIdle is next called on this task.
```

Macros

```
#define __EVENT_H__ undefined
```

Time Manipulation Macros Documentation

sli_event_control_set_active

```
void sli_event_control_set_active (EmberEventControl *event)
```

Set [EmberEventControl](#) to run at the next available opportunity.

Parameters

[in]	event	Pointer to the control of the event to set active
------	-------	---

Warnings

- Applications should use [emberEventControlSetActive\(\)](#) instead.

Definition at line 299 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emEventControlSetDelayMS

```
void emEventControlSetDelayMS (EmberEventControl *event, uint32_t delay)
```

Set [EmberEventControl](#) to run some milliseconds in the future.

Parameters

[in]	event	Pointer to the control of the event to run.
[in]	delay	The delay in milliseconds. Must be less than EMBER_MAX_EVENT_CONTROL_DELAY_MS

Warnings

- Applications should use [emberEventControlSetDelayMS\(\)](#) instead.

Definition at line 325 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emEventControlGetRemainingMS

```
uint32_t emEventControlGetRemainingMS (EmberEventControl *event)
```

Check when the event is scheduled to run.

Parameters

[in]	event	Pointer to the control of the event in question.
------	-------	--

Returns

- Return the amount of milliseconds remaining before the event is scheduled to run. If the event is inactive, [MAX_INT32U_VALUE](#) is returned.

Warnings

- Applications should use [emberEventControlGetRemainingMS\(\)](#) instead.

Definition at line 378 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h

emberRunEvents

```
void emberRunEvents (EmberEventData *events)
```

Start an event handler if anything is scheduled when this function is called.

Parameters

[in]	events	Pointer to the array of events.
------	--------	---------------------------------

An application typically creates an array of events along with their handlers. This function should be called in the main loop to run those events. **Warnings**

- This is normally handled by [emberRunTask\(\)](#) in the main plugin.

Definition at line 392 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h

emberRunTask

```
void emberRunTask (EmberTaskId taskid)
```

Start an event handler if there is anything scheduled at the moment this function is called.

Parameters

N/A	taskid	
-----	--------	--

If an application has initialized a task via [emberTaskInit\(\)](#), to run the events associated with that task, it should call [emberRunTask\(\)](#) instead of [emberRunEvents\(\)](#).

Warnings

- This is normally handled by the main plugin.

Definition at line 405 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h

emberMsToNextEvent

```
uint32_t emberMsToNextEvent (EmberEventData *events, uint32_t maxMs)
```

Check when the next event is scheduled to run.

Parameters

[in]	events	An array of events to check.
[in]	maxMs	If no event is scheduled before maxMs, maxMs will be returned

Returns

- Returns the number of milliseconds before the next event is scheduled to expire, or `maxMs` if no event is scheduled to expire within that time.

Note

- If any events are modified within an interrupt, to guarantee the accuracy of this API, it must be called with interrupts disabled.

See Also

- [emberMsToNextEventExtended\(\)](#)

Definition at line 420 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberMsToNextEventExtended

```
uint32_t emberMsToNextEventExtended (EmberEventData *events, uint32_t maxMs, uint8_t *returnIndex)
```

Check when the next event is scheduled to run.

Parameters

[in]	events	An array of events to check.
[in]	maxMs	If no event is scheduled before maxMs, maxMs will be returned
[out]	returnIndex	If not NULL pointer was passed, the index of the next event will be returned here, or 0xFF if no event is scheduled before maxMs.

Returns

- Returns the number of milliseconds before the next event is scheduled to expire, or `maxMs` if no event is scheduled to expire within that time.

Note

- If any events are modified within an interrupt, to guarantee the accuracy of this API, it must be called with interrupts disabled.

See Also

- [emberMsToNextEvent\(\)](#)

Definition at line 438 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberMsToNextStackEvent

```
uint32_t emberMsToNextStackEvent (void)
```

Check when the next stack event is scheduled to run.

Parameters

N/A		
-----	--	--

Returns

- Returns the number of milliseconds before the next stack event is scheduled to run.

Definition at line 446 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberTaskInit

```
EmberTaskId emberTaskInit (EmberEventData *events)
```

Initialize a task for managing events and processor idling state.

Parameters

[in]	events	Pointer to the array of events to manage
------	--------	--

Returns

- Returns the [EmberTaskId](#) which represents the newly created task.

Note

- After the task is created [emberRunTask\(\)](#) should be called periodically.

Definition at line 456 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberMarkTaskIdle

```
bool emberMarkTaskIdle (EmberTaskId taskid)
```

Try to idle the CPU, unless any events in any tasks are pending.

Parameters

[in]	taskid	the task which should handle the idling.
------	--------	--

Returns

- Returns **true** if the processor was idled **false** if idling wasn't permitted because a task has something to do.

Note

- This API should always be called with interrupts disabled. It will forcibly re-enable interrupts before returning.

Definition at line 468 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emTaskEnableIdling

```
void emTaskEnableIdling (bool allow)
```

Enable or disable idling.

Parameters

[in]	allow	Setting it to true will enable, while setting it to false will disable idling.
------	-------	--

Warnings

- Applications should use [emberTaskEnableIdling\(\)](#) instead.

Definition at line 484 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emMarkTaskActive

```
void emMarkTaskActive (EmberTaskId taskid)
```

Calling it indicates that a task has something to do, so it should prevent the CPU from idling until [emberMarkTaskIdle](#) is next called on this task.

Parameters

[in]	taskid	The task to mark active.
------	--------	--------------------------

Warnings

- Applications should use `emberMarkTaskActive()` instead.

Definition at line 499 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

elapsedTimeInt8u

```
#define elapsedTimeInt8u
```

Value:

```
(oldTime, newTime)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 190 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

elapsedTimeInt16u

```
#define elapsedTimeInt16u
```

Value:

```
(oldTime, newTime)
```

Returns the elapsed time between two 16 bit values. Result may not be valid if the time samples differ by more than 32767.

Definition at line 197 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

elapsedTimeInt32u

```
#define elapsedTimeInt32u
```

Value:

```
(oldTime, newTime)
```

Returns the elapsed time between two 32 bit values. Result may not be valid if the time samples differ by more than 2147483647.

Definition at line 204 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MAX_INT8U_VALUE

```
#define MAX_INT8U_VALUE
```

Value:

```
(0xFF)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 211 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

HALF_MAX_INT8U_VALUE

```
#define HALF_MAX_INT8U_VALUE
```

Value:

```
(0x80)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 212 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

timeGTorEqualInt8u

```
#define timeGTorEqualInt8u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 213 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MAX_INT16U_VALUE

```
#define MAX_INT16U_VALUE
```

Value:

```
(0xFFFF)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 220 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

HALF_MAX_INT16U_VALUE

```
#define HALF_MAX_INT16U_VALUE
```

Value:

```
(0x8000)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 221 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

timeGTorEqualInt16u

```
#define timeGTorEqualInt16u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 222 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MAX_INT32U_VALUE

```
#define MAX_INT32U_VALUE
```

Value:

```
(0xFFFFFFFFUL)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 229 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

HALF_MAX_INT32U_VALUE

```
#define HALF_MAX_INT32U_VALUE
```

Value:

```
(0x80000000UL)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 230 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

timeGTorEqualInt32u

```
#define timeGTorEqualInt32u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 231 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_SECOND

```
#define MILLISECOND_TICKS_PER_SECOND
```

Value:

```
1000UL
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 234 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_DECISECOND

```
#define MILLISECOND_TICKS_PER_DECISECOND
```

Value:

```
(MILLISECOND_TICKS_PER_SECOND / 10)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 237 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_QUARTERSECOND

```
#define MILLISECOND_TICKS_PER_QUARTERSECOND
```

Value:

```
(MILLISECOND_TICKS_PER_SECOND >> 2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 241 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_MINUTE

```
#define MILLISECOND_TICKS_PER_MINUTE
```

Value:

```
(60UL * MILLISECOND_TICKS_PER_SECOND)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 245 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_HOUR

```
#define MILLISECOND_TICKS_PER_HOUR
```

Value:

```
(60UL * MILLISECOND_TICKS_PER_MINUTE)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 249 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

MILLISECOND_TICKS_PER_DAY

```
#define MILLISECOND_TICKS_PER_DAY
```

Value:

```
(24UL * MILLISECOND_TICKS_PER_HOUR)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 253 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

EMBER_TASK_COUNT

```
#define EMBER_TASK_COUNT
```

Value:

```
(3)
```

The number of event tasks that can be used to schedule and run events. Connect stack requires one, while another is used for Application Framework events.

Definition at line 261 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlSetInactive

```
#define emberEventControlSetInactive
```

Value:

```
(control)
```

Set [EmberEventControl](#) as inactive (no pending event).

Definition at line 268 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlGetActive

```
#define emberEventControlGetActive
```

Value:

```
(control)
```

Check whether [EmberEventControl](#) is currently active. An event is considered active if it is set to run some time in the future (activated by [emberEventControlSetActive\(\)](#), [emberEventControlSetDelayMS\(\)](#) or any other `emberEventControlSetDelay*` functions)

Returns

- Returns **true** if the event is active **false** otherwise

Definition at line 282 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlSetActive

```
#define emberEventControlSetActive
```

Value:

```
(control)
```

Set [EmberEventControl](#) to run at the next available opportunity.

Definition at line 291 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

EMBER_MAX_EVENT_CONTROL_DELAY_MS

```
#define EMBER_MAX_EVENT_CONTROL_DELAY_MS
```

Value:

```
(HALF_MAX_INT32U_VALUE - 1)
```

The maximum delay that may be passed to [emberEventControlSetDelayMS\(\)](#).

Definition at line 305 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlSetDelayMS

```
#define emberEventControlSetDelayMS
```

Value:

```
(control, delay)
```

Set [EmberEventControl](#) to run some milliseconds in the future.

Definition at line 314 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

EMBER_MAX_EVENT_CONTROL_DELAY_QS

```
#define EMBER_MAX_EVENT_CONTROL_DELAY_QS
```

Value:

```
(EMBER_MAX_EVENT_CONTROL_DELAY_MS >> 8)
```

The maximum delay that may be passed to [emberEventControlSetDelayQS\(\)](#).

Definition at line 330 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlSetDelayQS

```
#define emberEventControlSetDelayQS
```

Value:


```
(control, delay)
```

Set [EmberEventControl](#) to run some quarter seconds in the future.

Warnings

- Applications should use [emberEventControlSetDelayQS\(\)](#) instead.

Definition at line 341 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

EMBER_MAX_EVENT_CONTROL_DELAY_MINUTES

```
#define EMBER_MAX_EVENT_CONTROL_DELAY_MINUTES
```

Value:

```
(EMBER_MAX_EVENT_CONTROL_DELAY_MS >> 16)
```

The maximum delay that may be passed to [emberEventControlSetDelayMinutes\(\)](#).

Definition at line 347 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlSetDelayMinutes

```
#define emberEventControlSetDelayMinutes
```

Value:

```
(control, delay)
```

Set [EmberEventControl](#) to run some minutes in the future.

Definition at line 356 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberEventControlGetRemainingMS

```
#define emberEventControlGetRemainingMS
```

Value:

```
(control)
```

Check when the event is scheduled to run.

Returns

- Returns the amount of milliseconds remaining before the event is scheduled to run. If the event is inactive, [MAX_INT32U_VALUE](#) is returned.

Definition at line 366 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberTaskEnableIdling

```
#define emberTaskEnableIdling
```

Value:

(allow)

Enable or disable idling.

Definition at line 477 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

emberMarkTaskActive

```
#define emberMarkTaskActive
```

Value:

(taskid)

Calling it indicates that a task has something to do, so it should prevent the CPU from idling until [emberMarkTaskIdle](#) is next called on this task.

Definition at line 492 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

Macro Definition Documentation

__EVENT_H__

```
#define __EVENT_H__
```

Definition at line 179 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/event.h`

Memory Buffer

Memory Buffer

Ember Connect API dynamically allocates and frees memory.

Generally, dynamic memory allocation in embedded code is not recommended. However, in some cases, the drawbacks of avoiding them is even bigger. Using C standard library dynamic memory is still not recommended due because it could cause fragmented memory.

For these reasons, Connect allocates some (configurable in the stack common plugin) memory as HEAP at compile-time. Memory allocation from this heap is possible through the API below.

See [memory-buffer.h](#) for source code.

APIs

This handler is invoked by the memory buffers system garbage collector and allows the application to properly mark the application-defined EmberBuffer variables with emberMarkBuffer(). Implement associated callback emberAfMarkApplicationBuffersCallback() to use. See [Handlers](#) for additional information.

EmberBuffer	emberAllocateBuffer (uint16_t dataSizeInBytes) Dynamically allocates memory.
void	emberMarkBuffer (EmberBuffer *buffer) Prevent the garbage collector from reclaiming the memory associated with the passed EmberBuffer . The application should call this API within the ::emberMarkApplicationBuffersHandler() stack handler for each EmberBuffer object.
uint8_t *	emberGetBufferPointer (EmberBuffer buffer) Return a pointer to the memory segment corresponding to the passed EmberBuffer buffer. Notice that the garbage collector can move memory segments to defragment the available memory. As result, the application should always use this API to obtain an updated pointer prior to accessing the memory.
uint16_t	emberGetBufferLength (EmberBuffer buffer) Return the length in bytes of the passed EmberBuffer buffer.
uint16_t	emberGetAvailableBufferMemory (void) Return the available memory at the buffer manager in bytes.

Macros

#define	EMBER_NULL_BUFFER 0x0000u A special EmberBuffer ID indicating that no memory is currently allocated.
---------	---

APIs Documentation

emberAllocateBuffer

```
EmberBuffer emberAllocateBuffer (uint16_t dataSizeInBytes)
```

Dynamically allocates memory.

Parameters

[in]	dataSizeInBytes	The size in bytes of the memory to be allocated.
------	-----------------	--

Returns

- An [EmberBuffer](#) value of `EMBER_NULL_BUFFER` if the memory management system could not allocate the requested memory, or any other [EmberBuffer](#) value indicating that the requested memory was successfully allocated. The allocated memory can easily be freed by assigning an [EmberBuffer](#) variable to `EMBER_NULL_BUFFER`. The memory will be freed by the garbage collector during the next [emberTick\(\)](#) call.

Definition at line 92 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h`

emberMarkBuffer

```
void emberMarkBuffer (EmberBuffer *buffer)
```

Prevent the garbage collector from reclaiming the memory associated with the passed [EmberBuffer](#). The application should call this API within the `::emberMarkApplicationBuffersHandler()` stack handler for each [EmberBuffer](#) object.

Parameters

[in]	buffer	A pointer to the EmberBuffer buffer to be marked.
------	--------	---

Definition at line 101 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h`

emberGetBufferPointer

```
uint8_t * emberGetBufferPointer (EmberBuffer buffer)
```

Return a pointer to the memory segment corresponding to the passed [EmberBuffer](#) buffer. Notice that the garbage collector can move memory segments to defragment the available memory. As result, the application should always use this API to obtain an updated pointer prior to accessing the memory.

Parameters

[in]	buffer	A pointer to the EmberBuffer buffer for which the corresponding memory pointer should be returned.
------	--------	--

Returns

- A NULL pointer if the passed [EmberBuffer](#) value is `EMBER_NULL_BUFFER`. Otherwise, a pointer to the corresponding memory segment.

Definition at line 116 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h`

emberGetBufferLength

```
uint16_t emberGetBufferLength (EmberBuffer buffer)
```

Return the length in bytes of the passed [EmberBuffer](#) buffer.

Parameters

[in]	buffer	A pointer to the EmberBuffer buffer for which the corresponding length in bytes should be returned.
------	--------	---

Returns

- The length in bytes of a memory segment corresponding to the passed [EmberBuffer](#) buffer.

Definition at line 127 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h

emberGetAvailableBufferMemory

```
uint16_t emberGetAvailableBufferMemory (void)
```

Return the available memory at the buffer manager in bytes.

Parameters

N/A		
-----	--	--

Returns

- The number of available bytes.

Definition at line 134 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h

Macro Definition Documentation

EMBER_NULL_BUFFER

```
#define EMBER_NULL_BUFFER
```

Value:

```
0x0000u
```

A special [EmberBuffer](#) ID indicating that no memory is currently allocated.

Definition at line 50 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/memory-buffer.h

Messaging

Messaging

Connect APIs and handlers for sending and receiving messages.

t_stack

Note that MAC mode and Extended star/direct mode use different APIs for messaging.

See [message.h](#) for source code.

Handlers

The Application Framework implements all handlers, directly calling their associated callbacks. By default, Connect projects declare such callbacks as stubs in flex-callbacks-stubs.c. Hence, to use an enabled Connect feature, applications should replace the stub with their own implementation of the associated callback (typically in flex-callbacks.c). See UG235.04 for more info.

void	emberMessageSentHandler (EmberStatus status, EmberOutgoingMessage *message) This handler is invoked when the stack has completed sending a message.
void	emberMacMessageSentHandler (EmberStatus status, EmberOutgoingMacMessage *message) This handler is invoked when a node of EMBER_MAC_MODE_DEVICE type or EMBER_MAC_MODE_SLEEPY_DEVICE type has completed sending a MAC frame.
void	emberIncomingMessageHandler (EmberIncomingMessage *message) This handler is invoked when a packet has been received from a node type other than EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE .
void	emberIncomingMacMessageHandler (EmberIncomingMacMessage *message) This handler is invoked when a node of EMBER_MAC_MODE_DEVICE type or EMBER_MAC_MODE_SLEEPY_DEVICE has received a MAC frame.
EmberStatus	emberMessageSend (EmberNodeId destination, uint8_t endpoint, uint8_t messageTag, EmberMessageLength messageLength, uint8_t *message, EmberMessageOptions options) Send a message to the passed destination short ID.
EmberStatus	emberMacMessageSend (EmberMacFrame *macFrame, uint8_t messageTag, EmberMessageLength messageLength, uint8_t *message, EmberMessageOptions options) Create a MAC level frame and sends it to the passed destination. This API can only be used for nodes of EMBER_MAC_MODE_DEVICE node type or EMBER_MAC_MODE_SLEEPY_DEVICE node type.
EmberStatus	emberPollForData (void) Send a data request command to the parent node. Note that if the node short ID is a value of EMBER_USE_LONG_ADDRESS , the node shall use its long ID as source address.
EmberStatus	emberSetPollDestinationAddress (EmberMacAddress *destination) Set data polls destination address for nodes of EMBER_MAC_MODE_DEVICE node type or EMBER_MAC_MODE_SLEEPY_DEVICE node type.
uint16_t	emberGetMaximumPayloadLength (EmberMacAddressMode srcAddressMode, EmberMacAddressMode dstAddressMode, bool interpan, bool secured) Return the maximum payload according to the passed source and destination addressing modes, the passed secured flag, and the current configuration of the node.

- bool [emberUsingLongMessages](#)(void)
Indicates if the stack is currently using long messages or not.
- EmberStatus** [emberNcpSetLongMessagesUse](#)(bool useLongMessages)
Set the current message length that the stack uses.
- EmberStatus** [emberPurgeIndirectMessages](#)(void)
Purge all indirect transmissions from the indirect message queue.
- EmberStatus** [emberSetIndirectQueueTimeout](#)(uint32_t timeoutMs)
Set indirect queue timeout value. The indirect queue timeout is set by default to [EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS](#).

Macros

- #define [EMBER_MAX_UNSECURED_APPLICATION_PAYLOAD_LENGTH](#) 111
- #define [EMBER_MAX_SECURED_APPLICATION_PAYLOAD_LENGTH](#) 102
- #define [EMBER_MAX_ENDPOINT](#) 0xF
The maximum allowed endpoint value.

Handlers Documentation

emberMessageSentHandler

```
void emberMessageSentHandler (EmberStatus status, EmberOutgoingMessage *message)
```

This handler is invoked when the stack has completed sending a message.

Parameters

[in]	status	<p>An EmberStatus value of:</p> <ul style="list-style-type: none"> EMBER_SUCCESS if an ACK was received from the destination or no ACK was requested. EMBER_MAC_NO_ACK_RECEIVED if an ACK was requested and no ACK was received. EMBER_MAC_INDIRECT_TIMEOUT if the destination is a sleepy node and the packet timed-out before the sleepy node sent a data request. EMBER_MAC_INDIRECT_MESSAGE_PURGED if the destination is a sleepy node and it was removed from the child table while the packet was stored in the indirect queue. EMBER_PHY_TX_CCA_FAIL if the node failed all the clear channel assessment attempts. EMBER_PHY_TX_INCOMPLETE if the transmission was not completed correctly.
[in]	message	An EmberOutgoingMessage describing the outgoing packet.

Warnings

- Implement associated callback [emberAfMessageSentCallback\(\)](#) to use. See [Handlers](#) for additional information.

Definition at line 95 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberMacMessageSentHandler

```
void emberMacMessageSentHandler (EmberStatus status, EmberOutgoingMacMessage *message)
```

This handler is invoked when a node of [EMBER_MAC_MODE_DEVICE](#) type or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) type has completed sending a MAC frame.

Parameters

[in]	status	An EmberStatus value of: <ul style="list-style-type: none"> • EMBER_SUCCESS if an ACK was received from the destination or no ACK was requested. • EMBER_MAC_NO_ACK_RECEIVED if an ACK was requested and no ACK was received. • EMBER_MAC_INDIRECT_TIMEOUT if the MAC frame was sent out via the indirect queue and the it timed-out before a data request was received. • EMBER_MAC_INDIRECT_MESSAGE_PURGED if the MAC frame was sent out via the indirect queue and it was removed prior to a data request being received. See emberPurgeIndirectMessages(). • EMBER_MAC_SECURITY_FAILED if the stack failed to encrypt the message. This typically occurs when a node is sending a message using short source addressing with an address other than the node's short address and the no mapping to a corresponding address was found in the short-to-long address mapping table. The application should use the emberMacAddShortToLongAddressMapping to populate such table. • EMBER_PHY_TX_CCA_FAIL if the node failed all the clear channel assessment attempts. • EMBER_PHY_TX_INCOMPLETE if the transmission was not completed correctly.
[in]	message	An EmberOutgoingMacMessage describing the outgoing MAC frame.

Warnings

- Implement associated callback [emberAfMacMessageSentCallback\(\)](#) to use. See [Handlers](#) for additional information.

Definition at line 127 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberIncomingMessageHandler

```
void emberIncomingMessageHandler (EmberIncomingMessage *message)
```

This handler is invoked when a packet has been received from a node type other than [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#).

Parameters

[in]	message	An EmberIncomingMessage describing the incoming packet.
------	---------	---

Warnings

- Implement associated callback [emberAfIncomingMessageCallback\(\)](#) to use. See [Handlers](#) for additional information.

Definition at line 139 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberIncomingMacMessageHandler

```
void emberIncomingMacMessageHandler (EmberIncomingMacMessage *message)
```

This handler is invoked when a node of [EMBER_MAC_MODE_DEVICE](#) type or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) has received a MAC frame.

Parameters

[in]	message	An EmberIncomingMacMessage describing the incoming packet.
------	---------	--

Warnings

- Implement associated callback [emberAfIncomingMacMessageCallback\(\)](#) to use. See [Handlers](#) for additional information.

Definition at line 152 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberMessageSend

```
EmberStatus emberMessageSend (EmberNodeId destination, uint8_t endpoint, uint8_t messageTag, EmberMessageLength messageLength, uint8_t *message, EmberMessageOptions options)
```

Send a message to the passed destination short ID.

Parameters

[in]	destination	The destination node short ID.
[in]	endpoint	The destination endpoint of the outgoing message. This value can't exceed EMBER_MAX_ENDPOINT .
[in]	messageTag	A value chosen by the application. This value will be passed in the corresponding emberMessageSentHandler() call.
[in]	messageLength	The size of the message payload in bytes. Use the emberGetMaximumPayloadLength() API to determine the maximum message length allowed.
[in]	message	A pointer to an array of bytes containing the message payload.
[in]	options	Specifies the EmberMessageOptions for the outgoing message.

Returns

- an [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the message was accepted by the stack. If a success status is returned, the [emberMessageSentHandler\(\)](#) callback is invoked by the stack to indicate whether the message was successfully delivered or the reason for failure.
 - [EMBER_INVALID_CALL](#) if the node is not joined to a network or the node is of [EMBER_MAC_MODE_DEVICE](#) device type or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) (use [emberMacMessageSend](#) instead).
 - [EMBER_BAD_ARGUMENT](#) if the packet length is 0, the passed TX options indicates some feature that is not supported, the passed endpoint exceeds [EMBER_MAX_ENDPOINT](#)
 - [EMBER_MESSAGE_TOO_LONG](#) if the message does not fit in a single frame.
 - [EMBER_PHY_TX_BUSY](#) if the message cannot be sent since the node does not support MAC queuing and the radio is currently busy.
 - [EMBER_MAC_TRANSMIT_QUEUE_FULL](#) if the outgoing MAC queue is currently full.
 - [EMBER_NO_BUFFERS](#) if the stack could not allocate enough RAM to store the submitted message.
 - [EMBER_MAC_UNKNOWN_DESTINATION](#) if the node is part of a star network and the destination node does not appear in the node's routing table.
 - [EMBER_MAC_SECURITY_NOT_SUPPORTED](#) if the message was requested to be sent out secured and either the local node does not support security or the destination node is known to not support security.
 - [EMBER_MAC_BUSY](#) if the message was not accepted because the MAC is currently performing some critical operation.

Definition at line 203 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberMacMessageSend

```
EmberStatus emberMacMessageSend (EmberMacFrame *macFrame, uint8_t messageTag, EmberMessageLength messageLength, uint8_t *message, EmberMessageOptions options)
```

Create a MAC level frame and sends it to the passed destination. This API can only be used for nodes of [EMBER_MAC_MODE_DEVICE](#) node type or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) node type.

Parameters

[in]	macFrame	A pointer to an EmberMacFrame struct that specifies the source and destination addresses and the source and destination PAN IDs for the message to be sent. Note that if the source/destination PAN ID is not specified, it defaults to the node's PAN ID. Also, the destination address mode must be either EMBER_MAC_ADDRESS_MODE_SHORT or EMBER_MAC_ADDRESS_MODE_LONG .
------	----------	--

[in]	messageTag	A value chosen by the application. This value will be passed in the corresponding emberMacMessageSentHandler() call.
[in]	messageLength	The size in bytes of the message payload. The application can use the emberGetMaximumPayloadLength() API to determine the maximum allowable payload, given a permutation of source and destination addressing and other TX options.
[in]	message	A pointer to an array of bytes containing the message payload.
[in]	options	Specifies the EmberMessageOptions for the outgoing message.

Returns

- an [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the message was accepted by the stack. If a success status is returned, the [emberMacMessageSentHandler\(\)](#) callback will be invoked by the stack to indicate whether the message was successfully delivered or the reason for failure.
 - [EMBER_INVALID_CALL](#) if the node is of a node type other than [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#).
 - [EMBER_BAD_ARGUMENT](#) if the packet length is 0, the passed TX options indicates some feature that is not supported or the destination address mode is set to [EMBER_MAC_ADDRESS_MODE_NONE](#).
 - [EMBER_MESSAGE_TOO_LONG](#) if the message does not fit in a single frame.
 - [EMBER_PHY_TX_BUSY](#) if the message cannot be sent since the node does not support MAC queuing and the radio is currently busy.
 - [EMBER_MAC_TRANSMIT_QUEUE_FULL](#) if the outgoing MAC queue is currently full.
 - [EMBER_NO_BUFFERS](#) if the stack could not allocate enough RAM to store the submitted message.
 - [EMBER_MAC_SECURITY_NOT_SUPPORTED](#) if the message was requested to be sent out with a security but no security plugin was enabled.
 - [EMBER_MAC_BUSY](#) if the message was not accepted because the MAC is currently performing a critical operation.

Definition at line 257 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberPollForData

EmberStatus emberPollForData (void)

Send a data request command to the parent node. Note that if the node short ID is a value of [EMBER_USE_LONG_ADDRESS](#), the node shall use its long ID as source address.

Parameters

N/A

Returns

- and [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the data poll was accepted by the MAC layer.
 - [EMBER_INVALID_CALL](#) if the node is not joined to a network, the node is not an end device, an [EMBER_MAC_MODE_DEVICE](#) or an [EMBER_MAC_MODE_SLEEPY_DEVICE](#), or the node is of [EMBER_MAC_MODE_DEVICE](#) or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) node type, is not joined to a coordinator and the poll destination was not correctly set via the [emberSetPollDestinationAddress\(\)](#) API.
 - [EMBER_MAC_BUSY](#) if the MAC is currently performing a critical operation.

Definition at line 278 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

emberSetPollDestinationAddress

EmberStatus emberSetPollDestinationAddress (EmberMacAddress *destination)

Set data polls destination address for nodes of [EMBER_MAC_MODE_DEVICE](#) node type or [EMBER_MAC_MODE_SLEEPY_DEVICE](#) node type.

Parameters

N/A	destination	
-----	-------------	--

Returns

- and [EmberStatus](#) value of [EMBER_SUCCESS](#) if the data poll destination was correctly set, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 288 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberGetMaximumPayloadLength

```
uint16_t emberGetMaximumPayloadLength (EmberMacAddressMode srcAddressMode, EmberMacAddressMode dstAddressMode, bool interpan, bool secured)
```

Return the maximum payload according to the passed source and destination addressing modes, the passed secured flag, and the current configuration of the node.

Parameters

[in]	srcAddressMode	An EmberMacAddressMode value indicating the mode of the source address. Note, this parameter is only meaningful if the node was started as EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE .
[in]	dstAddressMode	An EmberMacAddressMode value indicating the mode of the destination address. Note, this parameter is only meaningful if the node was started as EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE .
[in]	interpan	Indicates whether the frame is an interpan frame or not. Note, this parameter is only meaningful if the node was started as EMBER_MAC_MODE_DEVICE or EMBER_MAC_MODE_SLEEPY_DEVICE .
[in]	secured	Indicates whether the frame should be secured or not.

Returns

- The maximum payload length in bytes achievable according to the passed parameters or **0xFF** if the node is currently active on a network or any of the passed parameters are invalid.

Definition at line 339 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberUsingLongMessages

```
bool emberUsingLongMessages (void)
```

Indicates if the stack is currently using long messages or not.

Parameters

N/A		
-----	--	--

Returns

- True if the stack currently uses long messages (length stored in a uint16_t) or false if it is not the case (length stored in a uint8_t).

Definition at line 351 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberNcpSetLongMessagesUse

EmberStatus emberNcpSetLongMessagesUse (bool useLongMessages)

Set the current message length that the stack uses.

Parameters

[in]	useLongMessages	True to use long messages (length stored in a uint16_t), false to use short messages (length stored in a uint8_t).
------	-----------------	--

Note

- This API is here to assure retro compatibility with old NCP Host lib versions. In NCP Host lib versions that do not support OFDM features (v1.1 and older), only short messaging is supported. For the NCP, short messages are used by default. The Host lib needs to call this API with useLongMessages set to true if it supports OFDM.

Warnings

- This API changes the behavior of the Connect Serialization Protocol. It only has effect when using a RTOS or the NCP. Changing it may result in packets being incorrectly transferred through CSP when using a SUN-OFDM or SUN-FSK PHY.

Definition at line 370 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberPurgeIndirectMessages

EmberStatus emberPurgeIndirectMessages (void)

Purge all indirect transmissions from the indirect message queue.

Parameters

N/A

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if all indirect messages were purged, or another [EmberStatus](#) value indicating the reason of failure.

Definition at line 299 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

emberSetIndirectQueueTimeout

EmberStatus emberSetIndirectQueueTimeout (uint32_t timeoutMs)

Set indirect queue timeout value. The indirect queue timeout is set by default to [EMBER_INDIRECT_TRANSMISSION_TIMEOUT_MS](#).

Parameters

N/A	timeoutMs	The timeout in milliseconds to be set.
-----	-----------	--

Returns

- an [EmberStatus](#) value of [EMBER_SUCCESS](#) if the passed timeout was successfully set, or a value of [EMBER_BAD_ARGUMENT](#) if the passed value is invalid.

Definition at line 313 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h

Macro Definition Documentation

EMBER_MAX_UNSECURED_APPLICATION_PAYLOAD_LENGTH

```
#define EMBER_MAX_UNSECURED_APPLICATION_PAYLOAD_LENGTH
```

Value:

```
111
```

DeprecatedThe maximum length in bytes of the application payload for an unsecured message. This define has been deprecated, you should use the [emberGetMaximumPayloadLength](#) API instead.

Definition at line 48 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

EMBER_MAX_SECURED_APPLICATION_PAYLOAD_LENGTH

```
#define EMBER_MAX_SECURED_APPLICATION_PAYLOAD_LENGTH
```

Value:

```
102
```

DeprecatedThe maximum length in bytes of the application payload for a secured message. This define has been deprecated, you should use the [emberGetMaximumPayloadLength](#) API instead.

Definition at line 54 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

EMBER_MAX_ENDPOINT

```
#define EMBER_MAX_ENDPOINT
```

Value:

```
0xF
```

The maximum allowed endpoint value.

Definition at line 58 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/stack/include/message.h`

Connect Application Framework API Reference

Connect Application Framework API Reference

Application Framework includes plugins that are built on top of the Connect stack.

Modules

[Application Framework Common](#)

[Command Interpreter Plugin](#)

[Debug Print Plugin](#)

[Mailbox Client Plugin](#)

[Mailbox Server Plugin](#)

[Mailbox Common](#)

[Ota Unicast Bootloader Client Plugin](#)

[Ota Unicast Bootloader Server Plugin](#)

[Ota Unicast Bootloader Common](#)

[Ota Broadcast Bootloader Client Plugin](#)

[Ota Broadcast Bootloader Server Plugin](#)

[Ota Broadcast Bootloader Common](#)

[Poll Plugin](#)

[WSTK Sensors Plugin](#)

Application Framework Common

Application Framework Common

Application framework common.

Declare all required application framework globals, initialize the Connect stack, and dispatch stack callbacks calls as needed to the application components.

Callbacks

- void [emberAfInitCallback](#)(void)
Application Framework Initialization Callback.
- void [emberAfTickCallback](#)(void)
Application Framework Tick Callback.
- void [emberAfStackStatusCallback](#)(EmberStatus status)
Application framework equivalent of [emberStackStatusHandler](#).
- void [emberAfIncomingMessageCallback](#)(EmberIncomingMessage *message)
Application framework equivalent of [emberIncomingMessageHandler](#).
- void [emberAfIncomingMacMessageCallback](#)(EmberIncomingMacMessage *message)
Application framework equivalent of [emberIncomingMacMessageHandler](#).
- void [emberAfMessageSentCallback](#)(EmberStatus status, EmberOutgoingMessage *message)
Application framework equivalent of [emberMessageSentHandler](#).
- void [emberAfMacMessageSentCallback](#)(EmberStatus status, EmberOutgoingMacMessage *message)
Application framework equivalent of [emberMacMessageSentHandler](#).
- void [emberAfChildJoinCallback](#)(EmberNodeType nodeType, EmberNodeId nodeId)
Application framework equivalent of [emberChildJoinHandler](#).
- void [emberAfActiveScanCompleteCallback](#)(void)
Application framework equivalent of [emberActiveScanCompleteHandler](#).
- void [emberAfEnergyScanCompleteCallback](#)(int8_t mean, int8_t min, int8_t max, uint16_t variance)
Application framework equivalent of [emberEnergyScanCompleteHandler](#).
- void [emberAfMarkApplicationBuffersCallback](#)(void)
Application framework equivalent of [::emberMarkApplicationBuffersHandler](#).
- void [emberAfIncomingBeaconCallback](#)(EmberPanId panId, EmberMacAddress *source, int8_t rssi, bool permitJoining, uint8_t beaconFieldsLength, uint8_t *beaconFields, uint8_t beaconPayloadLength, uint8_t *beaconPayload)
Application framework equivalent of [emberIncomingBeaconHandler](#).
- void [emberAfFrequencyHoppingStartClientCompleteCallback](#)(EmberStatus status)
Application framework equivalent of [emberFrequencyHoppingStartClientCompleteHandler](#).
- void [emberAfRadioNeedsCalibratingCallback](#)(void)
Application framework equivalent of [emberRadioNeedsCalibratingHandler](#).

- bool [emberAfStackIdleCallback](#)(uint32_t *idleTimeMs)
Application framework equivalent of [emberStackIdleHandler](#).
- bool [emberAfCommonOkToEnterLowPowerCallback](#)(bool enter_em2, uint32_t duration_ms)
Application framework Low Power notification Callback.

Functions

- uint32_t [emberAfGetResetCause](#)(void)
Get the last reset cause mask.
- [EmberStatus](#) [emberAfAllocateEvent](#)(EmberEventControl **control, void(*handler)(void))
Allocate a new event to the app event table.

Callbacks Documentation

emberAfInitCallback

```
void emberAfInitCallback (void)
```

Application Framework Initialization Callback.

Parameters

N/A		
-----	--	--

A callback invoked once during the initialization. It is called after the stack and plugins initialization.

Definition at line 53 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfTickCallback

```
void emberAfTickCallback (void)
```

Application Framework Tick Callback.

Parameters

N/A		
-----	--	--

A callback invoked in each iteration of the application super loop and can be used to perform periodic functions. The frequency with which this function is called depends on how quickly the main loop runs. If the application blocks at any time during the main loop, this function will not be called until execution resumes.

Definition at line 64 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfStackStatusCallback

```
void emberAfStackStatusCallback (EmberStatus status)
```

Application framework equivalent of [emberStackStatusHandler](#).

Parameters

N/A	status	
-----	--------	--

Definition at line 68 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfIncomingMessageCallback

```
void emberAfIncomingMessageCallback (EmberIncomingMessage *message)
```

Application framework equivalent of [emberIncomingMessageHandler](#).

Parameters

N/A	message	
-----	---------	--

Definition at line 72 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h

emberAfIncomingMacMessageCallback

```
void emberAfIncomingMacMessageCallback (EmberIncomingMacMessage *message)
```

Application framework equivalent of [emberIncomingMacMessageHandler](#).

Parameters

N/A	message	
-----	---------	--

Definition at line 76 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h

emberAfMessageSentCallback

```
void emberAfMessageSentCallback (EmberStatus status, EmberOutgoingMessage *message)
```

Application framework equivalent of [emberMessageSentHandler](#).

Parameters

N/A	status	
N/A	message	

Definition at line 80 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h

emberAfMacMessageSentCallback

```
void emberAfMacMessageSentCallback (EmberStatus status, EmberOutgoingMacMessage *message)
```

Application framework equivalent of [emberMacMessageSentHandler](#).

Parameters

N/A	status	
N/A	message	

Definition at line 85 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h

emberAfChildJoinCallback

```
void emberAfChildJoinCallback (EmberNodeType nodeType, EmberNodeId nodeId)
```

Application framework equivalent of [emberChildJoinHandler](#).

Parameters

N/A	nodeType	
N/A	nodeId	

Warnings

- Requires the parent support plugin installed.

Definition at line 91 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfActiveScanCompleteCallback

```
void emberAfActiveScanCompleteCallback (void)
```

Application framework equivalent of [emberActiveScanCompleteHandler](#).

Parameters

N/A		
-----	--	--

Definition at line 96 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfEnergyScanCompleteCallback

```
void emberAfEnergyScanCompleteCallback (int8_t mean, int8_t min, int8_t max, uint16_t variance)
```

Application framework equivalent of [emberEnergyScanCompleteHandler](#).

Parameters

N/A	mean	
N/A	min	
N/A	max	
N/A	variance	

Definition at line 100 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfMarkApplicationBuffersCallback

```
void emberAfMarkApplicationBuffersCallback (void)
```

Application framework equivalent of `::emberMarkApplicationBuffersHandler`.

Parameters

N/A		
-----	--	--

Definition at line 107 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfIncomingBeaconCallback

```
void emberAfIncomingBeaconCallback (EmberPanId panId, EmberMacAddress *source, int8_t rssi, bool permitJoining, uint8_t beaconFieldsLength, uint8_t *beaconFields, uint8_t beaconPayloadLength, uint8_t *beaconPayload)
```

Application framework equivalent of [emberIncomingBeaconHandler](#).

Parameters

N/A	panId		
N/A	source		
N/A	rsSi		
N/A	permitJoining		
N/A	beaconFieldsLength		
N/A	beaconFields		
N/A	beaconPayloadLength		
N/A	beaconPayload		

Definition at line 111 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfFrequencyHoppingStartClientCompleteCallback

```
void emberAfFrequencyHoppingStartClientCompleteCallback (EmberStatus status)
```

Application framework equivalent of [emberFrequencyHoppingStartClientCompleteHandler](#).

Parameters

N/A	status		
-----	--------	--	--

Definition at line 122 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfRadioNeedsCalibratingCallback

```
void emberAfRadioNeedsCalibratingCallback (void)
```

Application framework equivalent of [emberRadioNeedsCalibratingHandler](#).

Parameters

N/A			
-----	--	--	--

Definition at line 126 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfStackIdleCallback

```
bool emberAfStackIdleCallback (uint32_t *idleTimeMs)
```

Application framework equivalent of [emberStackIdleHandler](#).

Parameters

N/A	idleTimeMs		
-----	------------	--	--

Definition at line 130 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

emberAfCommonOkToEnterLowPowerCallback

```
bool emberAfCommonOkToEnterLowPowerCallback (bool enter_em2, uint32_t duration_ms)
```

Application framework Low Power notification Callback.

Parameters

[in]	enter_em2	true if the system is about to sleep or false to idle.
[in]	duration_ms	Duration of the low power period. Time to the next event.

A callback invoked when the system is about to go sleeping.

Returns

- **true** if the application allows the system to go to sleep.

Definition at line 142 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_callback.h`

Function Documentation

emberAfGetResetCause

```
uint32_t emberAfGetResetCause (void)
```

Get the last reset cause mask.

Parameters

N/A		
-----	--	--

Returns

- A reset cause mask.

Note

- This API replaces [halGetResetInfo\(\)](#) or [halGetExtendedResetInfo](#). [emberAfGetResetCause\(\)](#) is a `RMU_ResetCauseGet()` overhaul. See the reference manual of the EMLIB RMU for a description of the returned reset cause mask.

Definition at line 62 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_common.h`

emberAfAllocateEvent

```
EmberStatus emberAfAllocateEvent (EmberEventControl **control, void(*handler)(void))
```

Allocate a new event to the app event table.

Parameters

[out]	control	The EmberEventControl to allocate
[in]	handler	Pointer to the handler function associated to the event

Returns

- An [EmberStatus](#) value of:
 - [EMBER_SUCCESS](#) if the event was successfully allocated.
 - [EMBER_TABLE_FULL](#) if no more event could be allocated.

See Also

- [emberAfAllocateEvent\(\)](#)

Definition at line 77 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/app-framework-common/app_framework_common.h

Command Interpreter Plugin

Command Interpreter Plugin

Debug Print Plugin

Debug Print Plugin

Mailbox Client Plugin

Mailbox Client Plugin

APIs for mailbox client.

Mailbox protocol is designed for devices that can't be online on the network all the time. The most common example for this is a sleepy end device.

Mailbox clients and the server can submit messages into the mailbox, which is stored in RAM on the mailbox server. Clients can then query the mailbox server for available messages.

The mailbox server will notify clients who submit messages when a message was delivered or when it couldn't be delivered due to an error.

Mailbox uses a plugin-configurable protocol endpoint, which is 15 by default.

The server can also configure the size of the mailbox (in number of packets, 25 by default) and the packet timeout, after which the server drops the message and notifies the source of the error.

The mailbox protocol uses standard data messages, so in case of sleepy end devices, it will use the indirect queue. This means that if a sleepy end device sends a request to a mailbox server, the end device should poll for the response.

Note

- Mailbox is not available in MAC mode due to the lack of endpoints.

See [mailbox-client.h](#) and [mailbox-client.c](#) for source code.

Callbacks

void	emberAfPluginMailboxClientMessageSubmitCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer, EmberNodeId messageDestination, uint8_t tag) Mailbox Client Message Submit Callback.
void	emberAfPluginMailboxClientMessageDeliveredCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer, EmberNodeId messageDestination, uint8_t tag) Mailbox Client Message Delivered Callback.
void	emberAfPluginMailboxClientCheckInboxCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer, EmberNodeId messageSource, uint8_t *message, EmberMessageLength messageLength, uint8_t tag, bool moreMessages) Mailbox Client Check Inbox Callback.

Functions

EmberAfMailboxStatus	emberAfPluginMailboxClientMessageSubmit (EmberNodeId mailboxServer, EmberNodeId messageDestination, uint8_t *message, EmberMessageLength messageLength, uint8_t tag, bool useSecurity) Submit a data message to a mailbox server. If this API returns an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS , the corresponding asynchronous callback emberAfPluginMailboxClientMessageSubmitCallback() will be invoked to indicate whether the message was successfully submitted to the mailbox server or to inform the application of the reason of failure.
EmberAfMailboxStatus	emberAfPluginMailboxClientCheckInbox (EmberNodeId mailboxServer, bool useSecurity) Query a mailbox server for pending messages. If this API returns an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS , the corresponding asynchronous callback

[emberAfPluginMailboxClientCheckInboxCallback\(\)](#)

will be invoked either to provide the retrieved message or to indicate the reason for failure.

Callbacks Documentation

emberAfPluginMailboxClientMessageSubmitCallback

```
void emberAfPluginMailboxClientMessageSubmitCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer,
EmberNodeId messageDestination, uint8_t tag)
```

Mailbox Client Message Submit Callback.

Parameters

[in]	status	An EmberAfMailboxStatus value of: <ul style="list-style-type: none"> EMBER_MAILBOX_STATUS_SUCCESS if the data message was accepted by the mailbox server. EMBER_MAILBOX_STATUS_STACK_ERROR if the message couldn't be delivered to the mailbox server. EMBER_MAILBOX_STATUS_MESSAGE_NO_RESPONSE if the client timed-out waiting for a response from the server. EMBER_MAILBOX_STATUS_MESSAGE_TABLE_FULL if the mailbox server table is currently full. EMBER_MAILBOX_STATUS_MESSAGE_NO_BUFFERS if the server can't allocate enough memory to store the message.
[in]	mailboxServer	The node ID of the mailbox server.
[in]	messageDestination	The node ID of the destination.
N/A	tag	The tag value passed in the emberAfPluginMailboxClientMessageSubmit() API.

A callback invoked when a message arrived to the mailbox server after a call of [emberAfPluginMailboxClientMessageSubmit\(\)](#).

Note

- Receiving this callback requires the reception of a mailbox command message, which is only possible by polling if the message was submitted on a [EMBER_STAR_SLEEPY_END_DEVICE](#).

Definition at line 168 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-client/mailbox-client.h`

emberAfPluginMailboxClientMessageDeliveredCallback

```
void emberAfPluginMailboxClientMessageDeliveredCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer,
EmberNodeId messageDestination, uint8_t tag)
```

Mailbox Client Message Delivered Callback.

Parameters

[in]	status	An EmberAfMailboxStatus value of: <ul style="list-style-type: none"> EMBER_MAILBOX_STATUS_SUCCESS indicates that the message was successfully delivered to the final destination. EMBER_MAILBOX_STATUS_MESSAGE_TIMED_OUT indicates that the message timed-out and was removed from the server queue.
[in]	mailboxServer	The node ID of the mailbox server where the message was submitted to.

[in]	messageDestination	The node ID of the destination.
[in]	tag	The tag value passed in the emberAfPluginMailboxClientMessageSubmit() API.

A callback that may be invoked on the submitter of the message either if the message that was submitted to a mailbox server reached its final destination or it timed-out. Note that the callback is not always called. If the status message from the server is lost, the callback won't be called.

Note

- Receiving this callback requires the reception of a mailbox command message, which is only possible by polling if the message was submitted on a [EMBER_STAR_SLEEPY_END_DEVICE](#).

Definition at line 199 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-client/mailbox-client.h`

emberAfPluginMailboxClientCheckInboxCallback

```
void emberAfPluginMailboxClientCheckInboxCallback (EmberAfMailboxStatus status, EmberNodeId mailboxServer,
EmberNodeId messageSource, uint8_t *message, EmberMessageLength messageLength, uint8_t tag, bool
moreMessages)
```

Mailbox Client Check Inbox Callback.

Parameters

[in]	status	An EmberAfMailboxStatus value of: <ul style="list-style-type: none"> EMBER_MAILBOX_STATUS_SUCCESS if a message was retrieved from the mailbox server. EMBER_MAILBOX_STATUS_MESSAGE_NO_DATA if the server has currently no message for this mailbox client. EMBER_MAILBOX_STATUS_MESSAGE_NO_RESPONSE if the client timed-out waiting for a query response from the mailbox server. EMBER_MAILBOX_STATUS_STACK_ERROR if the stack failed to deliver the query message to the mailbox server.
[in]	mailboxServer	The node id of the mailbox server responding.
[in]	messageSource	The source node ID of the retrieved message. Note that this parameter is meaningful only if the status parameter has an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS .
[in]	message	A pointer to the retrieved message payload. Note that this parameter is meaningful only if the status parameter has an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS .
[in]	messageLength	The length in bytes of the retrieved message payload. Note that this parameter is meaningful only if the status parameter has an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS .
[in]	tag	The tag value passed in the emberAfPluginMailboxClientMessageSubmit() API. Note that this parameter is meaningful only if the status parameter has an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS .
[in]	moreMessages	This flag is true if the mailbox server has more pending messages for this mailbox client. Note that this parameter is meaningful only if the status parameter has an EmberAfMailboxStatus value of EMBER_MAILBOX_STATUS_SUCCESS .

This callback is invoked after a successful call to the [emberAfPluginMailboxClientCheckInbox\(\)](#) API. If a message was retrieved from the mailbox server, this callback passes it to the application. Otherwise, it indicates the reason for failure to the application.

Note

- Receiving this callback requires the reception of a mailbox command message, which is only possible by polling if the message was submitted on a [EMBER_STAR_SLEEPY_END_DEVICE](#).

Definition at line 250 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-client/mailbox-client.h

Function Documentation

emberAfPluginMailboxClientMessageSubmit

```
EmberAfMailboxStatus emberAfPluginMailboxClientMessageSubmit (EmberNodeId mailboxServer, EmberNodeId messageDestination, uint8_t *message, EmberMessageLength messageLength, uint8_t tag, bool useSecurity)
```

Submit a data message to a mailbox server. If this API returns an [EmberAfMailboxStatus](#) value of [EMBER_MAILBOX_STATUS_SUCCESS](#), the corresponding asynchronous callback [emberAfPluginMailboxClientMessageSubmitCallback\(\)](#) will be invoked to indicate whether the message was successfully submitted to the mailbox server or to inform the application of the reason of failure.

Parameters

[in]	mailboxServer	The node ID of the mailbox server.
[in]	messageDestination	The node ID of the destination for this data message.
[in]	message	A pointer to the message to be sent.
[in]	messageLength	The length in bytes of the message to be sent.
[in]	tag	A tag value which will be returned in all of the corresponding callbacks: emberAfPluginMailboxClientMessageSubmitCallback() , emberAfPluginMailboxClientMessageDeliveredCallback() and emberAfPluginMailboxClientCheckInboxCallback() . The application can use it to match the callbacks with the call.
[in]	useSecurity	Set it true if the data message should be sent to the server using security.

Returns

- An [EmberAfMailboxStatus](#) value of:
 - [EMBER_MAILBOX_STATUS_SUCCESS](#) if the message was successfully passed to the network layer to be transmitted to the mailbox server.
 - [EMBER_MAILBOX_STATUS_INVALID_CALL](#) if the passed data message is invalid.
 - [EMBER_MAILBOX_STATUS_INVALID_ADDRESS](#) if the server ID or the destination ID is an invalid address.
 - [EMBER_MAILBOX_STATUS_MESSAGE_TOO_LONG](#) if the passed message does not fit in a single mailbox data message.
 - [EMBER_MAILBOX_STATUS_BUSY](#) if the client is still performing a submit message or a query for message action.
 - [EMBER_MAILBOX_STATUS_STACK_ERROR](#) if the network layer refused the message (the outgoing queue is currently full).

Note

- Receiving the [emberAfPluginMailboxClientMessageSubmitCallback\(\)](#) requires the reception of a mailbox command message, which is only possible by polling if the message was submitted on a [EMBER_STAR_SLEEPY_END_DEVICE](#).

See Also

- [emberAfPluginMailboxServerAddMessage\(\)](#)

Definition at line 92 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-client/mailbox-client.h

emberAfPluginMailboxClientCheckInbox

```
EmberAfMailboxStatus emberAfPluginMailboxClientCheckInbox (EmberNodeId mailboxServer, bool useSecurity)
```

Query a mailbox server for pending messages. If this API returns an [EmberAfMailboxStatus](#) value of [EMBER_MAILBOX_STATUS_SUCCESS](#), the corresponding asynchronous callback [emberAfPluginMailboxClientCheckInboxCallback\(\)](#) will be invoked either to provide the retrieved message or to indicate the reason for failure.

Parameters

[in]	mailboxServer	The node ID of the mailbox server.
[in]	useSecurity	Set it true if the request command and the responses to it should be sent secured. If a pending message was sent to a server securely, it will be always retrieved securely. This option only affects the request command and the pending messages that were sent without security to the server.

Returns

- An [EmberAfMailboxStatus](#) value of:
 - [EMBER_MAILBOX_STATUS_SUCCESS](#) if the query command was successfully passed to the network layer to be transmitted to the mailbox server.
 - [EMBER_MAILBOX_STATUS_INVALID_ADDRESS](#) if the passed mailbox server short ID is an invalid address.
 - [EMBER_MAILBOX_STATUS_BUSY](#) if the client is still performing a submit message or a query for message action.
 - [EMBER_MAILBOX_STATUS_STACK_ERROR](#) if the network layer refused the command (the outgoing queue is currently full).

Note

- Receiving the [emberAfPluginMailboxClientCheckInboxCallback\(\)](#) requires the reception of a mailbox command message, which is only possible by polling if the message was submitted on a [EMBER_STAR_SLEEPY_END_DEVICE](#).

Definition at line 128 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-client/mailbox-client.h`

Mailbox Server Plugin

Mailbox Server Plugin

APIs for mailbox server.

Mailbox protocol is designed for devices that can't be online on the network all the time. The most common example for this is a sleepy end device.

Mailbox clients and the server can submit messages into the mailbox, which is stored in RAM on the mailbox server. Clients can then query the mailbox server for available messages.

The mailbox server will notify clients who submit messages when a message was delivered or when it couldn't be delivered due to an error.

Mailbox uses a plugin-configurable protocol endpoint, which is 15 by default.

The server can also configure the size of the mailbox (in number of packets, 25 by default) and the packet timeout, after which the server drops the message and notifies the source of the error.

The mailbox protocol uses standard data messages, so in case of sleepy end devices, it will use the indirect queue. This means that if a sleepy end device sends a request to a mailbox server, the end device should poll for the response.

Note

- Mailbox is not available in MAC mode due to the lack of endpoints.

See [mailbox-server.h](#) and `mailbox-server.c` for source code.

Callbacks

```
void emberAfPluginMailboxServerMessageDeliveredCallback(EmberAfMailboxStatus status, EmberNodeId
messageDestination, uint8_t tag)
Mailbox Server Message Delivered Callback.
```

Functions

```
EmberAfMailboxS emberAfPluginMailboxServerAddMessage(EmberNodeId destination, uint8_t *message,
tatus EmberMessageLength messageLength, uint8_t tag, bool useSecurity)
Add a message to the mailbox server queue. The message is stored in the internal queue until the destination node
queries the mailbox server node for messages or upon timeout.
```

Callbacks Documentation

emberAfPluginMailboxServerMessageDeliveredCallback

```
void emberAfPluginMailboxServerMessageDeliveredCallback (EmberAfMailboxStatus status, EmberNodeId
messageDestination, uint8_t tag)
```

Mailbox Server Message Delivered Callback.

Parameters

[in]	status	An EmberAfMailboxStatus value of: <ul style="list-style-type: none"> EMBER_MAILBOX_STATUS_SUCCESS indicates that the message was successfully delivered to the final destination. EMBER_MAILBOX_STATUS_MESSAGE_TIMED_OUT indicates that the message timed-out and was removed from the server queue.
[in]	messageDestination	The node ID of the destination.
[in]	tag	The tag value passed in the emberAfPluginMailboxServerAddMessage() API.

This callback is invoked at the server when a message submitted locally by the server was successfully delivered or when it timed-out.

See Also

- [emberAfPluginMailboxClientMessageDeliveredCallback\(\)](#)

Definition at line 110 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-server/mailbox-server.h`

Function Documentation

emberAfPluginMailboxServerAddMessage

```
EmberAfMailboxStatus emberAfPluginMailboxServerAddMessage (EmberNodeId destination, uint8_t *message,
EmberMessageLength messageLength, uint8_t tag, bool useSecurity)
```

Add a message to the mailbox server queue. The message is stored in the internal queue until the destination node queries the mailbox server node for messages or upon timeout.

Parameters

[in]	destination	The node ID of the destination for this data message.
[in]	message	A pointer to the message to be enqueued.
[in]	messageLength	The length in bytes of the message to be enqueued.
[in]	tag	A tag value which will be returned in the corresponding emberAfPluginMailboxServerMessageDeliveredCallback() callback. The application can use to match the callbacks with the call.
[in]	useSecurity	Set it true if the data message should be sent to the server using security.

Returns

- An [EmberAfMailboxStatus](#) value of:
 - [EMBER_MAILBOX_STATUS_SUCCESS](#) if the message was successfully added to the packet queue.
 - [EMBER_MAILBOX_STATUS_INVALID_CALL](#) if the passed message is invalid.
 - [EMBER_MAILBOX_STATUS_INVALID_ADDRESS](#) if the passed destination address is invalid.
 - [EMBER_MAILBOX_STATUS_MESSAGE_TOO_LONG](#) if the payload size of the passed message exceeds the maximum allowable payload for the passed transmission options.
 - [EMBER_MAILBOX_STATUS_MESSAGE_TABLE_FULL](#) if the packet table is already full.
 - [EMBER_MAILBOX_STATUS_MESSAGE_NO_BUFFERS](#) if not enough memory buffers are available for storing the message content.

See Also

- [emberAfPluginMailboxClientMessageSubmit\(\)](#)

Definition at line 79 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-server/mailbox-server.h`

Mailbox Common

Mailbox Common

Types defined for mailbox.

Mailbox protocol is designed for devices that can't be online on the network all the time. The most common example for this is a sleepy end device.

Mailbox clients and the server can submit messages into the mailbox, which is stored in RAM on the mailbox server. Clients can then query the mailbox server for available messages.

The mailbox server will notify clients who submit messages when a message was delivered or when it couldn't be delivered due to an error.

Mailbox uses a plugin-configurable protocol endpoint, which is 15 by default.

The server can also configure the size of the mailbox (in number of packets, 25 by default) and the packet timeout, after which the server drops the message and notifies the source of the error.

The mailbox protocol uses standard data messages, so in case of sleepy end devices, it will use the indirect queue. This means that if a sleepy end device sends a request to a mailbox server, the end device should poll for the response.

Note

- Mailbox is not available in MAC mode due to the lack of endpoints.

Enumerations

```
enum EmberAfMailboxStatus {
    EMBER_MAILBOX_STATUS_SUCCESS = 0x00
    EMBER_MAILBOX_STATUS_INVALID_CALL = 0x01
    EMBER_MAILBOX_STATUS_BUSY = 0x02
    EMBER_MAILBOX_STATUS_STACK_ERROR = 0x03
    EMBER_MAILBOX_STATUS_INVALID_ADDRESS = 0x04
    EMBER_MAILBOX_STATUS_MESSAGE_TOO_LONG = 0x05
    EMBER_MAILBOX_STATUS_MESSAGE_TABLE_FULL = 0x06
    EMBER_MAILBOX_STATUS_MESSAGE_NO_BUFFERS = 0x07
    EMBER_MAILBOX_STATUS_MESSAGE_NO_RESPONSE = 0x08
    EMBER_MAILBOX_STATUS_MESSAGE_TIMED_OUT = 0x09
    EMBER_MAILBOX_STATUS_MESSAGE_NO_DATA = 0x0A
}
```

Mailbox return status codes.

Enumeration Documentation

EmberAfMailboxStatus

EmberAfMailboxStatus

Mailbox return status codes.

Enumerator

EMBER_MAILBOX_STATUS_SUCCESS

EMBER_MAILBOX_STATUS_INVALID_CALL	
EMBER_MAILBOX_STATUS_BUSY	
EMBER_MAILBOX_STATUS_STACK_ERROR	
EMBER_MAILBOX_STATUS_INVALID_ADDRESS	
EMBER_MAILBOX_STATUS_MESSAGE_TOO_LONG	
EMBER_MAILBOX_STATUS_MESSAGE_TABLE_FULL	
EMBER_MAILBOX_STATUS_MESSAGE_NO_BUFFERS	
EMBER_MAILBOX_STATUS_MESSAGE_NO_RESPONSE	
EMBER_MAILBOX_STATUS_MESSAGE_TIMED_OUT	
EMBER_MAILBOX_STATUS_MESSAGE_NO_DATA	

Definition at line 68 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/mailbox/mailbox-types.h

Ota Unicast Bootloader Client Plugin

APIs/callbacks for ota-unicast-bootloader clients.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Unicast OTA plugins implement the OTA download operation in a unicast, addressed way, so only a single client can be addressed from a server in an OTA session, and downloading images to multiple devices will require the server to send the image multiple times. Communication relies on standard unicast data messages, which also means that the routing provided by the Connect stack is available.

Although bootloading sleepy end devices is theoretically possible with polling, it is not very effective, and it's probably simpler to reconnect as a normal end device while the OTA is active.

Unicast OTA uses a plugin configurable endpoint, which is 13 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Unicast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

See [ota-unicast-bootloader-client.h](#) and [ota-unicast-bootloader-client.c](#) for source code.

Callbacks

bool	emberAfPluginOtaUnicastBootloaderClientNewIncomingImageCallback (EmberNodeId serverId, uint8_t imageTag, uint32_t imageSize, uint32_t *startIndex)	A callback invoked when the client starts receiving a new image. The application can choose to start receiving the image or ignore it. If the application chooses to receive the image, other images sent out by other servers shall be ignored until the client completes the download.
void	emberAfPluginOtaUnicastBootloaderClientIncomingImageSegmentCallback (EmberNodeId serverId, uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)	A callback invoked when an image segment that is part of an image the application chose to download was received.
void	emberAfPluginOtaUnicastBootloaderClientImageDownloadCompleteCallback (EmberAfOtaUnicastBootloaderStatus status, uint8_t imageTag, uint32_t imageSize)	A callback invoked to indicate that an image download has completed.
bool	emberAfPluginOtaUnicastBootloaderClientIncomingRequestBootloadCallback (EmberNodeId serverId, uint8_t imageTag, uint32_t bootloadDelayMs)	A callback invoked to indicate that a server has requested to perform a bootload operation at a certain point in time in the future.

Functions

[EmberAfOtaUnicastBootloaderStatus](#) `emberAfPluginOtaUnicastBootloaderClientAbortImageDownload(uint8_t imageTag)`
An API for aborting an ongoing image download process.

Callbacks Documentation

emberAfPluginOtaUnicastBootloaderClientNewIncomingImageCallback

```
bool emberAfPluginOtaUnicastBootloaderClientNewIncomingImageCallback (EmberNodeId serverId, uint8_t imageTag,
uint32_t imageSize, uint32_t *startIndex)
```

A callback invoked when the client starts receiving a new image. The application can choose to start receiving the image or ignore it. If the application chooses to receive the image, other images sent out by other servers shall be ignored until the client completes the download.

Parameters

[in]	serverId	The node ID of the server that initiated the new image distribution process.
[in]	imageTag	A 1-byte tag that identifies the incoming image.
[in]	imageSize	The size in bytes of the new image.
[out]	startIndex	The index of the first byte at which the image download shall be started/resumed. The client can use this argument to resume a partially downloaded image. If this value is not set, it defaults to 0 (that is, the download starts at the beginning of the image). Note, this is ignored in case the server does not support download resume.

Returns

- Return **true** to accept the image or **false** to ignore it.

Definition at line 88 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-client/ota-unicast-bootloader-client.h`

emberAfPluginOtaUnicastBootloaderClientIncomingImageSegmentCallback

```
void emberAfPluginOtaUnicastBootloaderClientIncomingImageSegmentCallback (EmberNodeId serverId, uint32_t
startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)
```

A callback invoked when an image segment that is part of an image the application chose to download was received.

Parameters

[in]	serverId	The node ID of the server that initiated the image distribution process.
[in]	startIndex	The index of the first byte of the passed segment.
[in]	endIndex	The index of the last byte of the passed segment.
[in]	imageTag	A 1-byte tag of the image the passed segment belongs to.
[in]	imageSegment	An array containing the image segment.

Definition at line 110 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-client/ota-unicast-bootloader-client.h`

emberAfPluginOtaUnicastBootloaderClientImageDownloadCompleteCallback

```
void emberAfPluginOtaUnicastBootloaderClientImageDownloadCompleteCallback (EmberAfOtaUnicastBootloaderStatus
status, uint8_t imageTag, uint32_t imageSize)
```

A callback invoked to indicate that an image download has completed.

Parameters

[in]	status	An EmberAfOtaUnicastBootloaderStatus value of: <ul style="list-style-type: none"> EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS indicating that the full image corresponding to the passed tag has been received. If this is the case, the client previously handed all the image segments to the application using the emberAfPluginOtaUnicastBootloaderClientIncomingImageSegmentCallback() callback. EMBER_OTA_UNICAST_BOOTLOADER_STATUS_FAILED indicating that the client failed to fully download the image and the download process was terminated. EMBER_OTA_UNICAST_BOOTLOADER_STATUS_TIMEOUT indicating that the client timed out waiting for a message from the server. EMBER_OTA_UNICAST_BOOTLOADER_STATUS_ABORTED indicating that the application aborted the ongoing image download process as result of calling the API emberAfPluginOtaUnicastBootloaderClientAbortImageDownload().
[in]	imageTag	A 1-byte tag of the image this callback refers to.
[in]	imageSize	The total size of the downloaded image in bytes. This parameter is meaningful only in case the status parameter is set to EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS .

Definition at line 140 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-client/ota-unicast-bootloader-client.h`

emberAfPluginOtaUnicastBootloaderClientIncomingRequestBootloadCallback

```
bool emberAfPluginOtaUnicastBootloaderClientIncomingRequestBootloadCallback (EmberNodeId serverId, uint8_t
imageTag, uint32_t bootloadDelayMs)
```

A callback invoked to indicate that a server has requested to perform a bootload operation at a certain point in time in the future.

Parameters

[in]	serverId	The ID of the server the request came from.
[in]	imageTag	A 1-byte tag of the image this callback refers to.
[in]	bootloadDelayMs	The delay in milliseconds after which the client has been requested to perform a bootload operation.

Returns

- Return **true** if the application accepted the request of bootloading the specified image at the requested time, **false** otherwise.

Definition at line 159 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-client/ota-unicast-bootloader-client.h`

Function Documentation

emberAfPluginOtaUnicastBootloaderClientAbortImageDownload

```
EmberAfOtaUnicastBootloaderStatus emberAfPluginOtaUnicastBootloaderClientAbortImageDownload (uint8_t imageTag)
```

An API for aborting an ongoing image download process.

Parameters

[in]	imageTag	A 1-byte tag that identifies the image the client should no longer download.
------	----------	--

Returns

- An [EmberAfOtaUnicastBootloaderStatus](#) value of:
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS](#) If the ongoing image download process was successfully aborted.
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL](#) If the client was not currently involved in an image download process or it was currently downloading an image with a different tag.

Definition at line 59 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-client/ota-unicast-bootloader-client.h`

Ota Unicast Bootloader Server Plugin

Ota Unicast Bootloader Server Plugin

Macros and APIs for ota-unicast-bootloader server.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Unicast OTA plugins implement the OTA download operation in a unicast, addressed way, so only a single client can be addressed from a server in an OTA session, and downloading images to multiple devices will require the server to send the image multiple times. Communication relies on standard unicast data messages, which also means that the routing provided by the Connect stack is available.

Although bootloading sleepy end devices is theoretically possible with polling, it is not very effective, and it's probably simpler to reconnect as a normal end device while the OTA is active.

Unicast OTA uses a plugin configurable endpoint, which is 13 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Unicast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

See [ota-unicast-bootloader-server.h](#) and [ota-unicast-bootloader-server.c](#) for source code.

Callbacks

bool [emberAfPluginOtaUnicastBootloaderServerGetImageSegmentCallback](#)(uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)
A callback invoked during an image distribution process to retrieve a contiguous segment of the image being distributed.

void [emberAfPluginOtaUnicastBootloaderServerImageDistributionCompleteCallback](#)(EmberAfOtaUnicastBootloaderStatus status)
A callback invoked when the image distribution process is terminated.

void [emberAfPluginOtaUnicastBootloaderServerRequestTargetBootloadCompleteCallback](#)(EmberAfOtaUnicastBootloaderStatus status)
A callback invoked when a bootload request process has completed.

Functions

[EmberAfOtaUnicastBootloaderStatus](#) [US](#) [emberAfPluginOtaUnicastBootloaderServerInitiateImageDistribution](#)(EmberNodeId targetId, uint32_t imageSize, uint8_t imageTag)
Initiate the image distribution process.

[EmberAfOtaUnicastBootloaderStat-](#)

US `emberAfPluginUnicastBootloaderServerInitiateRequestTargetBootload`(uint32_t bootloadDelayMs, uint8_t imageTag, EmberNodeId targetId)
Request a target device to initiate the bootload of a received image at some point in the future.

EmberAfOtaUnicastBootloaderStatus `emberAfPluginOtaUnicastBootloaderServerAbortCurrentProcess`(void)
Abort the ongoing process, such as image distribution or bootload request.

Macros

`#define` `EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS` 8
The number of consecutive stack message submission errors or stack related errors such as CSMA failures after which the plugin gives up.

`#define` `EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS` 4
The number of consecutive unicast attempts after which a target is declared unreachable. Legal values for this are in the [0,7] range.

`#define` `EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS` 250
The time in milliseconds after which the server gives up waiting for a response from a client.

Callbacks Documentation

emberAfPluginOtaUnicastBootloaderServerGetImageSegmentCallback

```
bool emberAfPluginOtaUnicastBootloaderServerGetImageSegmentCallback (uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)
```

A callback invoked during an image distribution process to retrieve a contiguous segment of the image being distributed.

Parameters

[in]	startIndex	The index of the first byte the application should copy into the passed array.
[in]	endIndex	The index of the last byte the application should copy into the passed array.
[in]	imageTag	A 1-byte tag of the image for which a segment is requested.
[out]	imageSegment	An array of (endIndex - startIndex + 1) length to which the application should copy the requested image segment.

Returns

- A boolean indicating whether the application successfully copied the requested bytes into the passed array. If the application returns **false**, the server will abort the ongoing distribution process.

Definition at line 159 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h`

emberAfPluginOtaUnicastBootloaderServerImageDistributionCompleteCallback

```
void emberAfPluginOtaUnicastBootloaderServerImageDistributionCompleteCallback (EmberAfOtaUnicastBootloaderStatus status)
```

A callback invoked when the image distribution process is terminated.

Parameters

[in]	status	An EmberAfOtaUnicastBootloaderStatus value of: <ul style="list-style-type: none"> • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS if the target confirms that the full image is received. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_DATA_UNDERFLOW if the application failed to supply the requested image segments. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_STACK_ERROR if the server encountered multiple consecutive transmission errors. The Server gives up the image distribution process if EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS consecutive transmission errors are encountered. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_FAILED if the distribution process terminated prematurely because the target can't be reached. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_UNREACHABLE if the server can not establish communication with the target client. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_ABORTED if the application aborted the current image distribution process. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_REFUSED if the client refused the image.
------	--------	--

Definition at line 188 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h`

emberAfPluginOtaUnicastBootloaderServerRequestTargetBootloadCompleteCallback

```
void emberAfPluginOtaUnicastBootloaderServerRequestTargetBootloadCompleteCallback
(EmberAfOtaUnicastBootloaderStatus status)
```

A callback invoked when a bootload request process has completed.

Parameters

[in]	status	An EmberAfOtaUnicastBootloaderStatus value of: <ul style="list-style-type: none"> • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS if the target has been requested to perform a bootload. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_STACK_ERROR if the server encountered multiple consecutive transmission errors. The Server gives up the bootload request process if EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS consecutive transmission errors are encountered. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_ABORTED if the application aborted the current bootload request process. • EMBER_OTA_UNICAST_BOOTLOADER_STATUS_UNREACHABLE if the server can not establish communication with the target client.
------	--------	--

Definition at line 207 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h`

Function Documentation

emberAfPluginOtaUnicastBootloaderServerInitiateImageDistribution

```
EmberAfOtaUnicastBootloaderStatus emberAfPluginOtaUnicastBootloaderServerInitiateImageDistribution (EmberNodeId
targetId, uint32_t imageSize, uint8_t imageTag)
```

Initiate the image distribution process.

Parameters

[in]	targetId	The node ID of the target.
[in]	imageSize	The image size in bytes to be distributed.
[in]	imageTag	A 1-byte tag that will be embedded in the server-to-client over-the-air messages. The application can use the image tag for versioning purposes and/or for distinguishing between different image types.

Returns

- An [EmberAfOtaUnicastBootloaderStatus](#) value of:
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_BUSY](#) if an image distribution is already in progress
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL](#) if the given target or the image size is invalid
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS](#) if the image distribution was successfully initiated.

Definition at line 87 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h`

emberAfPluginUnicastBootloaderServerInitiateRequestTargetBootload

```
EmberAfOtaUnicastBootloaderStatus emberAfPluginUnicastBootloaderServerInitiateRequestTargetBootload (uint32_t bootloadDelayMs, uint8_t imageTag, EmberNodeId targetId)
```

Request a target device to initiate the bootload of a received image at some point in the future.

Parameters

[in]	bootloadDelayMs	The delay in milliseconds after which the target should perform an image bootload.
[in]	imageTag	A 1-byte tag that identifies the image to be bootloaded at the target device.
[in]	targetId	The node ID of the target.

Returns

- An [EmberAfOtaUnicastBootloaderStatus](#) value of:
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS](#) if the plugin successfully started the process to request a target and initiate a bootload. If this is the case, the corresponding callback [emberAfPluginOtaUnicastBootloaderServerRequestTargetBootloadCompleteCallback\(\)](#) is invoked when the request process is completed.
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL](#) if some of the passed parameters are invalid.
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_BUSY](#) if the server is currently involved in another over-the-air process.

Definition at line 116 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h`

emberAfPluginOtaUnicastBootloaderServerAbortCurrentProcess

```
EmberAfOtaUnicastBootloaderStatus emberAfPluginOtaUnicastBootloaderServerAbortCurrentProcess (void)
```

Abort the ongoing process, such as image distribution or bootload request.

Parameters

N/A		
-----	--	--

Returns

- An [EmberAfOtaUnicastBootloaderStatus](#) value of:
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS](#) if the current ongoing process was successfully aborted.
 - [EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL](#) if the server is not currently involved in any process.

Definition at line 131 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h

Macro Definition Documentation

EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS

```
#define EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS
```

Value:

```
8
```

The number of consecutive stack message submission errors or stack related errors such as CSMA failures after which the plugin gives up.

Definition at line 51 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h

EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS

```
#define EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS
```

Value:

```
4
```

The number of consecutive unicast attempts after which a target is declared unreachable. Legal values for this are in the [0,7] range.

Definition at line 57 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h

EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS

```
#define EMBER_AF_PLUGIN_OTA_UNICAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS
```

Value:

```
250
```

The time in milliseconds after which the server gives up waiting for a response from a client.

Definition at line 63 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-server/ota-unicast-bootloader-server.h

Ota Unicast Bootloader Common

Ota Unicast Bootloader Common

Macros and types defined for ota-unicast-bootloaders.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Unicast OTA plugins implement the OTA download operation in a unicast, addressed way, so only a single client can be addressed from a server in an OTA session, and downloading images to multiple devices will require the server to send the image multiple times. Communication relies on standard unicast data messages, which also means that the routing provided by the Connect stack is available.

Although bootloading sleepy end devices is theoretically possible with polling, it is not very effective, and it's probably simpler to reconnect as a normal end device while the OTA is active.

Unicast OTA uses a plugin configurable endpoint, which is 13 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Unicast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

Enumerations

```
enum EmberAfOtaUnicastBootloaderStatus {
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS = 0x00
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL = 0x01
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_BUSY = 0x02
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_DATA_UNDERFLOW = 0x03
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_STACK_ERROR = 0x04
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_TIMEOUT = 0x05
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_FAILED = 0x06
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_ABORTED = 0x07
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_REFUSED = 0x08
    EMBER_OTA_UNICAST_BOOTLOADER_STATUS_UNREACHABLE = 0x09
}
```

OTA Unicast Bootloader return status codes.

Enumeration Documentation

EmberAfOtaUnicastBootloaderStatus

EmberAfOtaUnicastBootloaderStatus

OTA Unicast Bootloader return status codes.

Enumerator

EMBER_OTA_UNICAST_BOOTLOADER_STATUS_SUCCESS	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_INVALID_CALL	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_BUSY	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_DATA_UNDERFLOW	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_STACK_ERROR	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_TIMEOUT	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_FAILED	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_ABORTED	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_REFUSED	
EMBER_OTA_UNICAST_BOOTLOADER_STATUS_UNREACHABLE	

Definition at line 75 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-unicast-bootloader/ota-unicast-bootloader-types.h

Ota Broadcast Bootloader Client Plugin

Set of APIs for ota-broadcast-bootloader-client.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader-related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Broadcast OTA plugins implement the OTA download operation in broadcast, so the same image can be sent to many devices at the same time. The server however requires to know the clients downloading the image, because it implements error handling by querying all clients for missing segments, and then the server will re-broadcast those segments.

Communication relies on standard broadcast data messages, which means routing is not available, and only clients that are in the range of the server can download. However, the same device can be both client and server, i.e. after downloading the image, a client can configure itself to be a server, and provide the image to another part of the network.

Sleepy end devices cannot be addressed in broadcast, but a sleepy end device can reconnect as a normal end device while the OTA is active.

Broadcast OTA uses a plugin configurable endpoint, which is 14 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Broadcast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

See [ota-broadcast-bootloader-client.h](#) and [ota-broadcast-bootloader-client.c](#) for source code.

Callbacks

bool	emberAfPluginOtaBootloaderClientNewIncomingImageCallback (EmberNodeId serverId, EmberNodeId *alternateServerId, uint8_t imageTag)	A callback invoked when the OTA Bootloader Client starts receiving a new image. The application can choose to start receiving the image or it can ignore it. If the application chooses to receive the image, other images sent out by other servers are ignored until the client completes this download.
void	emberAfPluginOtaBootloaderClientIncomingImageSegmentCallback (EmberNodeId serverId, uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)	A callback invoked when an image segment, that is part of an image that the application elected to download, was received on the OTA Bootloader Client.
void	emberAfPluginOtaBootloaderClientImageDownloadCompleteCallback (EmberAfOtaBootloaderStatus status, uint8_t imageTag, uint32_t imageSize)	A callback invoked on an OTA Bootloader Client to indicate that an image download is completed.

- void [emberAfPluginOtaBootloaderClientIncomingRequestStatusCallback](#)(EmberNodeId serverId, uint8_t applicationServerStatus, uint8_t *applicationStatus)
A callback invoked on the OTA Bootloader Client to indicate that an OTA Bootloader Server has requested the status of the client device.
- bool [emberAfPluginOtaBootloaderClientIncomingRequestBootloadCallback](#)(EmberNodeId serverId, uint8_t imageTag, uint32_t bootloadDelayMs, uint8_t *applicationStatus)
A callback invoked by the OTA Bootloader Client plugin to indicate that an OTA Bootloader Server has requested to perform a bootload operation at a certain point in time in the future.

Functions

- [EmberAfOtaBootloaderStatus](#) [emberAfPluginOtaBootloaderClientAbortImageDownload](#)(uint8_t imageTag, uint8_t applicationErrorStatus)
Abort an ongoing image download process.

Callbacks Documentation

emberAfPluginOtaBootloaderClientNewIncomingImageCallback

```
bool emberAfPluginOtaBootloaderClientNewIncomingImageCallback (EmberNodeId serverId, EmberNodeId *alternateServerId, uint8_t imageTag)
```

A callback invoked when the OTA Bootloader Client starts receiving a new image. The application can choose to start receiving the image or it can ignore it. If the application chooses to receive the image, other images sent out by other servers are ignored until the client completes this download.

Parameters

[in]	serverId	The node ID of the server that initiated the new image distribution process.
[out]	alternateServerId	This node ID can be set by the application to include a well-known alternate server. If this is set to a valid address, the client allows segments also from this alternate server. If this is set to EMBER_BROADCAST_ADDRESS , the client accepts segments with the same image tag from any server.
[in]	imageTag	A 1-byte tag that identifies the incoming image.

Returns

- Return **true** to accept the image or **false** to ignore it.

Definition at line 94 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h`

emberAfPluginOtaBootloaderClientIncomingImageSegmentCallback

```
void emberAfPluginOtaBootloaderClientIncomingImageSegmentCallback (EmberNodeId serverId, uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)
```

A callback invoked when an image segment, that is part of an image that the application elected to download, was received on the OTA Bootloader Client.

Parameters

[in]	serverId	The node ID of the server that initiated the image distribution process.
[in]	startIndex	The index of the first byte of the passed segment.
[in]	endIndex	The index of the last byte of the passed segment.
[in]	imageTag	A 1-byte tag of the image the passed segment belongs to.

[in]	imageSegment	An array containing the image segment.
------	--------------	--

Definition at line 114 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h

emberAfPluginOtaBootloaderClientImageDownloadCompleteCallback

```
void emberAfPluginOtaBootloaderClientImageDownloadCompleteCallback (EmberAfOtaBootloaderStatus status, uint8_t imageTag, uint32_t imageSize)
```

A callback invoked on an OTA Bootloader Client to indicate that an image download is completed.

Parameters

[in]	status	An EmberAfOtaBootloaderStatus value of: <ul style="list-style-type: none"> EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS indicating that the full image corresponding to the passed tag has been received. If this is the case, the client previously handed all the image segments to the application using the emberAfPluginOtaBootloaderClientIncomingImageSegmentCallback() callback. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_FAILED indicating that the client failed to fully download the image and the download process was terminated. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_TIMEOUT indicating that the client timed out waiting for a message from the server. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED indicating that the application aborted the ongoing image download process as result of calling the API emberAfPluginOtaBootloaderClientAbortImageDownload().
[in]	imageTag	A 1-byte tag of the image this callback refers to.
[in]	imageSize	The total size of the downloaded image in bytes. This parameter is meaningful only in case the status parameter is set to EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS .

Definition at line 143 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h

emberAfPluginOtaBootloaderClientIncomingRequestStatusCallback

```
void emberAfPluginOtaBootloaderClientIncomingRequestStatusCallback (EmberNodeId serverId, uint8_t applicationServerStatus, uint8_t *applicationStatus)
```

A callback invoked on the OTA Bootloader Client to indicate that an OTA Bootloader Server has requested the status of the client device.

Parameters

[in]	serverId	The ID of the server the request came from.
[in]	applicationServerStatus	The server application status, which was set by emberAfPluginBootloaderServerInitiateRequestTargetsStatus()
[out]	applicationStatus	A 1-byte status set by the client application that is reported to the server.

Definition at line 158 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h

emberAfPluginOtaBootloaderClientIncomingRequestBootloadCallback

```
bool emberAfPluginOtaBootloaderClientIncomingRequestBootloadCallback (EmberNodeId serverId, uint8_t imageTag,
uint32_t bootloadDelayMs, uint8_t *applicationStatus)
```

A callback invoked by the OTA Bootloader Client plugin to indicate that an OTA Bootloader Server has requested to perform a bootload operation at a certain point in time in the future.

Parameters

[in]	serverId	The ID of the server the request came from.
[in]	imageTag	A 1-byte tag of the image this callback refers to.
[in]	bootloadDelayMs	The delay in milliseconds after which the client has been requested to perform a bootload operation.
[out]	applicationStatus	A 1-byte status set by the client application that is reported to the server.

Returns

- Return **true** if the application accepted the request of bootloading the specified image at the requested time, **false** otherwise.

Definition at line 179 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h

Function Documentation

emberAfPluginOtaBootloaderClientAbortImageDownload

```
EmberAfOtaBootloaderStatus emberAfPluginOtaBootloaderClientAbortImageDownload (uint8_t imageTag, uint8_t
applicationErrorStatus)
```

Abort an ongoing image download process.

Parameters

[in]	imageTag	A 1-byte tag that identifies the image the client should no longer download.
[in]	applicationErrorStatus	A 1-byte error code reported to the server.

Returns

- An [EmberAfOtaBootloaderStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS](#) If the ongoing image download process was successfully aborted.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL](#) If the client was not currently involved in an image download process or it was currently downloading an image with a different tag.

Definition at line 62 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-client/ota-broadcast-bootloader-client.h

Ota Broadcast Bootloader Server Plugin

Set of APIs for ota-broadcast-bootloader-server.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader-related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Broadcast OTA plugins implement the OTA download operation in broadcast, so the same image can be sent to many devices at the same time. The server however requires to know the clients downloading the image, because it implements error handling by querying all clients for missing segments, and then the server will re-broadcast those segments.

Communication relies on standard broadcast data messages, which means routing is not available, and only clients that are in the range of the server can download. However, the same device can be both client and server, i.e. after downloading the image, a client can configure itself to be a server, and provide the image to another part of the network.

Sleepy end devices cannot be addressed in broadcast, but a sleepy end device can reconnect as a normal end device while the OTA is active.

Broadcast OTA uses a plugin configurable endpoint, which is 14 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Broadcast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

See [ota-broadcast-bootloader-server.h](#) and [ota-broadcast-bootloader-server.c](#) for source code.

Callbacks

bool	emberAfPluginOtaBootloaderServerGetImageSegmentCallback (uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment) A callback invoked on the OTA Bootloader Server during an image distribution process to retrieve a contiguous segment of the image being distributed.
void	emberAfPluginOtaBootloaderServerImageDistributionCompleteCallback (EmberAfOtaBootloaderStatus status) A callback invoked on the OTA Bootloader Server when the image distribution process is terminated. The application can use the emberAfPluginBootloaderServerGetTargetStatus() API to retrieve the status reported by each target device.
void	emberAfPluginBootloaderServerRequestTargetsStatusCompleteCallback (EmberAfOtaBootloaderStatus status) A callback invoked on the OTA Bootloader Server when bootload request process has completed. Within this callback, the application should use the emberAfPluginBootloaderServerGetTargetStatus() API to retrieve the status and application status reported by each target.

void [emberAfPluginBootloaderServerRequestTargetsBootloadCompleteCallback](#)(EmberAfOtaBootloaderStatus status)
 A callback invoked on the OTA Bootloader Server when a bootload request process has completed. Within this callback, the application should use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API to retrieve the status and the application status reported by each target.

Functions

- [EmberAfOtaBootloaderStatus](#) [emberAfPluginOtaBootloaderServerInitiateImageDistribution](#)(uint32_t imageSize, uint8_t imageTag, EmberNodeId *targetList, uint16_t targetListLength)
 Initiate the image distribution process. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the image distribution process to check the status of each target.
- [EmberAfOtaBootloaderStatus](#) [emberAfPluginBootloaderServerInitiateRequestTargetsStatus](#)(EmberNodeId *targetList, uint16_t targetListLength, uint8_t applicationServerStatus)
 Initiate the process to request the status of a set of target devices. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the target status request process to check the status of each target.
- [EmberAfOtaBootloaderStatus](#) [emberAfPluginBootloaderServerInitiateRequestTargetsBootload](#)(uint32_t bootloadDelayMs, uint8_t imageTag, EmberNodeId *targetList, uint16_t targetListLength)
 Start the process where a server requests a set of target devices to initiate the bootload of a received image at some point in the future. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the bootload request process to check the status of each target.
- [EmberAfOtaBootloaderTargetStatus](#) [emberAfPluginBootloaderServerGetTargetStatus](#)(EmberNodeId targetId, uint8_t *applicationTargetStatus)
 Retrieve the locally stored status of an individual target in the distribution list. The locally stored status can be updated by calling [emberAfPluginBootloaderServerInitiateRequestTargetsStatus\(\)](#).
- [EmberAfOtaBootloaderStatus](#) [emberAfPluginOtaBootloaderServerAbortCurrentProcess](#)(void)
 Abort the ongoing process (image distribution, status request or bootload request). Note that aborting a bootload request process likely results in some targets performing the bootload while some others do not.

Macros

- #define [EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS](#) 8
 The number of consecutive stack message submission errors or stack-related errors, such as CSMA failures, after which the plugin gives up.
- #define [EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS](#) 4
 The number of consecutive unicast attempts after which a target is declared unreachable. Legal values for this are in the [0,7] range.
- #define [EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS](#) 250
 The time in milliseconds after which the server gives up waiting for a response from a client.
- #define [EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_BROADCAST_ROUNDS](#) 5
 The maximum number of image broadcast rounds the server performs before declaring an image distribution process failed.

Callbacks Documentation

emberAfPluginOtaBootloaderServerGetImageSegmentCallback

```
bool emberAfPluginOtaBootloaderServerGetImageSegmentCallback (uint32_t startIndex, uint32_t endIndex, uint8_t imageTag, uint8_t *imageSegment)
```

A callback invoked on the OTA Bootloader Server during an image distribution process to retrieve a contiguous segment of the image being distributed.

Parameters

[in]	startIndex	The index of the first byte the application should copy into the passed array.
[in]	endIndex	The index of the last byte the application should copy into the passed array.
[in]	imageTag	A 1-byte tag of the image for which a segment is being requested.
[out]	imageSegment	An array of (endIndex - startIndex + 1) length to which the application should copy the requested image segment.

Returns

- A boolean indicating whether the application successfully copied the requested bytes into the passed array. If the application returns **false**, the OTA Server plugin aborts the ongoing distribution process.

Definition at line 267 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h

emberAfPluginOtaBootloaderServerImageDistributionCompleteCallback

```
void emberAfPluginOtaBootloaderServerImageDistributionCompleteCallback (EmberAfOtaBootloaderStatus status)
```

A callback invoked on the OTA Bootloader Server when the image distribution process is terminated. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API to retrieve the status reported by each target device.

Parameters

[in]	status	An EmberAfOtaBootloaderStatus value of: <ul style="list-style-type: none"> EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS if all targets have confirmed that the full image was received except for those that have been declared "unreachable". EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_DATA_UNDERFLOW if the application failed to supply the requested image segments. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_STACK_ERROR if the server encountered multiple consecutive transmission errors. The Server gives up the image distribution process if EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS consecutive transmission errors are encountered. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_FAILED if the distribution process terminated prematurely because all targets have been declared unreachable. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_TIMEOUT if the server performed all the allowable broadcast rounds and there are still missing segments at one or more targets. The maximum allowable rounds are defined by EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_BROADCAST_ROUNDS. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED if the application aborted the current image distribution process.
------	--------	---

Definition at line 298 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h

emberAfPluginBootloaderServerRequestTargetsStatusCompleteCallback

```
void emberAfPluginBootloaderServerRequestTargetsStatusCompleteCallback (EmberAfOtaBootloaderStatus status)
```

A callback invoked on the OTA Bootloader Server when bootload request process has completed. Within this callback, the application should use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API to retrieve the status and application

status reported by each target.

Parameters

[in]	status	An EmberAfOtaBootloaderStatus value of: <ul style="list-style-type: none"> EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS if all the targets have been queried for their status. Notice that some targets might have been declared unreachable. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_STACK_ERROR if the server encountered multiple consecutive transmission errors. The Server gives up the targets status request process if EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS consecutive transmission errors are encountered. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED if the application aborted the current targets status request process.
------	--------	--

Definition at line 317 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

emberAfPluginBootloaderServerRequestTargetsBootloadCompleteCallback

```
void emberAfPluginBootloaderServerRequestTargetsBootloadCompleteCallback (EmberAfOtaBootloaderStatus status)
```

A callback invoked on the OTA Bootloader Server when a bootload request process has completed. Within this callback, the application should use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API to retrieve the status and the application status reported by each target.

Parameters

[in]	status	An EmberAfOtaBootloaderStatus value of: <ul style="list-style-type: none"> EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS if all targets have been requested to perform a bootload. Notice that some targets might have been declared unreachable. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_STACK_ERROR if the server encountered multiple consecutive transmission errors. The Server gives up the bootload request process if EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS consecutive transmission errors are encountered. EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED if the application aborted the current bootload request process.
------	--------	---

Definition at line 336 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

Function Documentation

emberAfPluginOtaBootloaderServerInitiateImageDistribution

```
EmberAfOtaBootloaderStatus emberAfPluginOtaBootloaderServerInitiateImageDistribution (uint32_t imageSize, uint8_t imageTag, EmberNodeId *targetList, uint16_t targetListLength)
```

Initiate the image distribution process. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the image distribution process to check the status of each target.

Parameters

[in]	imageSize	The image size in bytes to be distributed.
[in]	imageTag	A 1-byte tag that will be embedded in the server-to-client over-the-air messages. The application can use the image tag for versioning purposes and/or for distinguishing between different image types.

[out]	targetList	An array of EmberNodeId indicating the node IDs of the target devices.
[in]	targetListLength	The length of the passed <code>targetList</code>

Returns

- An [EmberAfOtaBootloaderStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS](#) if the image distribution is successfully initiated. If this is the case, the [emberAfPluginOtaBootloaderServerImageDistributionCompleteCallback\(\)](#) callback is invoked when the distribution process terminates.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL](#) if some of the passed parameters are invalid.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_BUSY](#) if the server is already performing another image distribution or some other over-the-air process.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_NO_BUFFERS](#) if the server can't allocate memory from the heap to store the passed target list. (See [Memory Buffer](#) for details).

Definition at line 104 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

emberAfPluginBootloaderServerInitiateRequestTargetsStatus

```
EmberAfOtaBootloaderStatus emberAfPluginBootloaderServerInitiateRequestTargetsStatus (EmberNodeId *targetList,
uint16_t targetListLength, uint8_t applicationServerStatus)
```

Initiate the process to request the status of a set of target devices. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the target status request process to check the status of each target.

Parameters

[in]	targetList	An array of EmberNodeId indicating the node IDs of the target devices that are queried for their status.
[in]	targetListLength	The length of the passed <code>targetlist</code> .
[in]	applicationServerStatus	The application can set a status here which will be sent to the clients in emberAfPluginOtaBootloaderClientIncomingRequestStatusCallback()

Returns

- An [EmberAfOtaBootloaderStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS](#) if the plugin successfully initiated the process of requesting the status of a set of targets. If this is the case, the corresponding callback [emberAfPluginBootloaderServerRequestTargetsStatusCompleteCallback\(\)](#) is invoked when the request process to all targets completes.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL](#) if some of the passed parameters are invalid.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_BUSY](#) if the server is currently involved in another over-the-air process.

Definition at line 135 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

emberAfPluginBootloaderServerInitiateRequestTargetsBootload

```
EmberAfOtaBootloaderStatus emberAfPluginBootloaderServerInitiateRequestTargetsBootload (uint32_t bootloadDelayMs,
uint8_t imageTag, EmberNodeId *targetList, uint16_t targetListLength)
```

Start the process where a server requests a set of target devices to initiate the bootload of a received image at some point in the future. The application can use the [emberAfPluginBootloaderServerGetTargetStatus\(\)](#) API at any time during the bootload request process to check the status of each target.

Parameters

[in]	bootloadDelayMs	The delay in milliseconds after which all the targets should perform an image bootload.
[in]	imageTag	A 1-byte tag that identifies the image to be bootloaded at the target devices.
[in]	targetList	An array of EmberNodeId indicating the node IDs of the target devices that is requested to bootload an image.
[in]	targetListLength	The length of the passed <code>targetlist</code> .

Returns

- An [EmberAfOtaBootloaderStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS](#) if the plugin successfully initiated the process of requesting a set of targets to initiate a bootload. If this is the case, the corresponding callback [emberAfPluginBootloaderServerRequestTargetsBootloadCompleteCallback\(\)](#) shall be invoked when the request process to all targets has completed.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL](#) if some of the passed parameters are invalid.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_BUSY](#) if the server is currently involved in another over-the-air process.

Definition at line 167 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

emberAfPluginBootloaderServerGetTargetStatus

```
EmberAfOtaBootloaderTargetStatus emberAfPluginBootloaderServerGetTargetStatus (EmberNodeId targetId, uint8_t *applicationTargetStatus)
```

Retrieve the locally stored status of an individual target in the distribution list. The locally stored status can be updated by calling [emberAfPluginBootloaderServerInitiateRequestTargetsStatus\(\)](#).

Parameters

[in]	targetId	The node ID of the target device whose status is being requested.
[out]	applicationTargetStatus	The application status reported by the client side application. This parameter is valid only for certain return status codes (see return status documentation).

Returns

- An [EmberAfOtaBootloaderTargetStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_INVALID](#) if the passed node ID does not appear in the current server target list of the current ongoing process or if there is no current ongoing process.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_UNREACHABLE](#) if the target has not responded to any of the server's unicast messages.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_COMPLETED](#) if the server is currently performing an image distribution process and the target confirmed that it received the full image.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ONGOING](#) if the server is currently performing an image distribution process and the target has partially received the image and distribution is continuing.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_REFUSED](#) if the target has refused the current image.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_FAILED](#) if the server is currently performing an image distribution process and the target reported that an error was encountered.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ABORTED](#) if the server is currently performing an image distribution process and the target decided to abort the image download process. In this case, the client also reports an application status. Therefore, the `applicationTargetStatus` parameter is valid.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_COMPLETED](#) if the server is currently performing a target status request process and the target has responded to the server's inquiry. In this case, the client also reports an application status. Therefore, the `applicationTargetStatus` parameter is valid.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_ONGOING](#) if the server is currently performing a target status request process and the target is not yet queried by the server.

[EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ACCEPTED](#) if the server is currently performing a bootload request process and the target has accepted to perform the requested image bootload.

- [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_REFUSED](#) if the server is currently performing a bootload request process and the target has refused to perform the requested image bootload.
- [EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ONGOING](#) if the server is currently performing a bootload request process and the target is not yet reached by the server.

Definition at line 223 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

emberAfPluginOtaBootloaderServerAbortCurrentProcess

```
EmberAfOtaBootloaderStatus emberAfPluginOtaBootloaderServerAbortCurrentProcess (void)
```

Abort the ongoing process (image distribution, status request or bootload request). Note that aborting a bootload request process likely results in some targets performing the bootload while some others do not.

Parameters

N/A

Returns

- An [EmberAfOtaBootloaderStatus](#) value of:
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS](#) if the current ongoing process was successfully aborted.
 - [EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL](#) if the server is not currently involved in any process.

Definition at line 237 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

Macro Definition Documentation

EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_STACK_ERRORS
```

Value:

8

The number of consecutive stack message submission errors or stack-related errors, such as CSMA failures, after which the plugin gives up.

Definition at line 51 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h`

EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_UNICAST_ERRORS
```

Value:

4

The number of consecutive unicast attempts after which a target is declared unreachable. Legal values for this are in the [0,7] range.

Definition at line 57 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h

EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_RESPONSE_TIMEOUT_MS
```

Value:

```
250
```

The time in milliseconds after which the server gives up waiting for a response from a client.

Definition at line 63 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h

EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_BROADCAST_ROUNDS

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_SERVER_MAX_BROADCAST_ROUNDS
```

Value:

```
5
```

The maximum number of image broadcast rounds the server performs before declaring an image distribution process failed.

Definition at line 69 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-server/ota-broadcast-bootloader-server.h

Ota Broadcast Bootloader Common

Ota Broadcast Bootloader Common

Set of types defined for ota-broadcast-bootloader.

OTA bootloading plugins are usable to send firmware images Over The Air when the application is running. When the firmware is downloaded to a device, a bootloader can be started to replace the application in the flash to the one just downloaded.

All Connect bootloader-related code relies on the Gecko Bootloader for bootloading and it must be installed on the device for these plugins to work. For details on the Gecko Bootloader, see UG266.

The Broadcast OTA plugins implement the OTA download operation in broadcast, so the same image can be sent to many devices at the same time. The server however requires to know the clients downloading the image, because it implements error handling by querying all clients for missing segments, and then the server will re-broadcast those segments.

Communication relies on standard broadcast data messages, which means routing is not available, and only clients that are in the range of the server can download. However, the same device can be both client and server, i.e. after downloading the image, a client can configure itself to be a server, and provide the image to another part of the network.

Sleepy end devices cannot be addressed in broadcast, but a sleepy end device can reconnect as a normal end device while the OTA is active.

Broadcast OTA uses a plugin configurable endpoint, which is 14 by default.

Security can be also enabled as plugin configuration on the server, as well as the interval of the messages. The client has a timeout plugin configuration after which it stops the OTA session with an error.

See UG235.06 for further details.

Note

- OTA Broadcast Bootloading plugins are not available in MAC mode due to the lack of endpoints.

Enumerations

```
enum EmberAfOtaBootloaderStatus {  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS = 0x00  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL = 0x01  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_BUSY = 0x02  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_NO_BUFFERS = 0x03  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_DATA_UNDERFLOW = 0x04  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_STACK_ERROR = 0x05  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_TIMEOUT = 0x06  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_FAILED = 0x07  
    EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED = 0x08  
}
```

OTA Broadcast Bootloader return status codes.


```
enum EmberAfOtaBootloaderTargetStatus {
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_INVALID = 0x00
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_UNREACHABLE = 0x01
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_COMPLETED = 0x02
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ONGOING = 0x03
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_FAILED = 0x04
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_REFUSED = 0x05
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ABORTED = 0x06
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_COMPLETED = 0x07
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_ONGOING = 0x08
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ACCEPTED = 0x09
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ONGOING = 0x0A
    EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_REFUSED = 0x0B
}
```

OTA Broadcast Bootloader target status codes, returned by [emberAfPluginBootloaderServerGetTargetStatus\(\)](#).

Macros

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_INVALID_APPLICATION_TARGET_STATUS 0xFF
```

A value indicating that client application did not set the application level target status in any of the client callbacks.

Enumeration Documentation

EmberAfOtaBootloaderStatus

EmberAfOtaBootloaderStatus

OTA Broadcast Bootloader return status codes.

Enumerator

EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_SUCCESS	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_INVALID_CALL	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_BUSY	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_NO_BUFFERS	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_DATA_UNDERFLOW	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_STACK_ERROR	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_TIMEOUT	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_FAILED	
EMBER_OTA_BROADCAST_BOOTLOADER_STATUS_ABORTED	

Definition at line 79 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-types.h`

EmberAfOtaBootloaderTargetStatus

EmberAfOtaBootloaderTargetStatus

OTA Broadcast Bootloader target status codes, returned by [emberAfPluginBootloaderServerGetTargetStatus\(\)](#).

Enumerator

EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_INVALID	
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_UNREACHABLE	
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_COMPLETED	
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ONGOING	

EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_FAILED
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_REFUSED
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_DISTRIBUTION_ABORTED
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_COMPLETED
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_STATUS_REQUEST_ONGOING
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ACCEPTED
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_ONGOING
EMBER_OTA_BROADCAST_BOOTLOADER_TARGET_STATUS_BOOTLOAD_REQUEST_REFUSED

Definition at line 117 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-types.h`

Macro Definition Documentation

EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_INVALID_APPLICATION_TARGET_STATUS

```
#define EMBER_AF_PLUGIN_OTA_BROADCAST_BOOTLOADER_INVALID_APPLICATION_TARGET_STATUS
```

Value:

0xFF

A value indicating that client application did not set the application level target status in any of the client callbacks.

Definition at line 189 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/ota-broadcast-bootloader/ota-broadcast-bootloader-types.h`

Poll Plugin

Poll Plugin

APIs for the poll plugin.

The Connect stack supports polling which enables (sleepy) end devices to retrieve pending messages from the parent node (coordinator or range extender).

To use this feature, the Poll plugin must be enabled on the end devices. If polling is enabled, the end device sends a data request to the parent node, which notifies the device whether a message is pending or not using the acknowledge with the pending bit cleared or set. If a message is not pending, the communication ends with the acknowledge. If a message is pending, the parent node sends a data packet containing the pending message which will be acknowledged by the end device.

For convenience, Connect supports two polling intervals, long and short, which behave the same only the polling period differs. For long polling, the period is specified in seconds while for short polling, the period is in quarter seconds. The API provides a function to easily switch between the two. The purpose of long polling is maintaining the connection between the end device and the parent.

The application will receive the polled message via the [emberAfIncomingMessageCallback\(\)](#) function.

The poll plugin uses [emberPollForData\(\)](#) to retrieve the pending message. If the poll plugin is enabled, using [emberPollForData\(\)](#) is strongly not recommended.

See [poll.h](#) for source code.

Functions

- void [emberAfPluginPollSetShortPollInterval](#)(uint8_t intervalQS)
Set the short poll interval.
- void [emberAfPluginPollSetLongPollInterval](#)(uint16_t intervalS)
Set the long poll interval.
- void [emberAfPluginPollEnableShortPolling](#)(bool enable)
Enable/disable short polling.

Function Documentation

emberAfPluginPollSetShortPollInterval

```
void emberAfPluginPollSetShortPollInterval (uint8_t intervalQS)
```

Set the short poll interval.

Parameters

[in]	intervalQS	The short poll interval in quarter seconds.
------	------------	---

Definition at line 68 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/poll/poll.h`

emberAfPluginPollSetLongPollInterval

```
void emberAfPluginPollSetLongPollInterval (uint16_t intervals)
```

Set the long poll interval.

Parameters

[in]	intervals	The long poll interval in seconds.
------	-----------	------------------------------------

Definition at line 74 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/poll/poll.h

emberAfPluginPollEnableShortPolling

```
void emberAfPluginPollEnableShortPolling (bool enable)
```

Enable/disable short polling.

Parameters

[in]	enable	If this parameter is true, short polling is enabled. Otherwise, the node switches back to long polling.
------	--------	---

Definition at line 81 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/protocol/flex/poll/poll.h

WSTK Sensors Plugin

WSTK Sensors Plugin

Hardware Abstraction Layer (HAL) API Reference

Hardware Abstraction Layer (HAL) API Reference

HAL function names have the following prefix conventions:

halCommon: API that is used by the EmberZNet stack and can also be called from an application. This API must be implemented. Custom applications can change the implementation of the API but its functionality must remain the same.

hal: API that is used by sample applications. Custom applications can remove this API or change its implementation as they see fit.

halStack: API used only by the EmberZNet stack. This API must be implemented and should not be directly called from any application. Custom applications can change the implementation of the API, but its functionality must remain the same.

halInternal: API that is internal to the HAL. The EmberZNet stack and applications must never call this API directly. Custom applications can change this API as they see fit. However, be careful not to impact the functionality of any halStack or halCommon APIs.

See also [hal.h](#).

Modules

[Hardware Abstraction Layer \(HAL\)](#)

[Common Microcontroller Functions](#)

[Token Access](#)

[Sample APIs for Peripheral Access](#)

[System Timer Control](#)

[Symbol Timer Control](#)

[HAL Configuration](#)

[HAL Utilities](#)

Hardware Abstraction Layer (HAL)

Hardware Abstraction Layer (HAL)

The Hardware Abstraction Layer (HAL) is program code between a system's hardware and its software that provides a consistent interface for applications that can run on several different hardware platforms. To take advantage of this capability, applications should access hardware through the API provided by the HAL, rather than directly. Then, when you move to new hardware, you only need to update the HAL. In some cases, due to extreme differences in hardware, the HAL API may also change slightly to accommodate the new hardware. In these cases, the limited scope of the update makes moving the application easier with the HAL than without.

HAL function names have the following prefix conventions:

- **halCommon:** API that is used by the EmberZNet stack and can also be called from an application. This API must be implemented. Custom applications can change the implementation of the API but its functionality must remain the same.
- **hal:** API that is used by sample applications. Custom applications can remove this API or change its implementation as they see fit.
- **halStack:** API used only by the EmberZNet stack. This API must be implemented and should not be directly called from any application. Custom applications can change the implementation of the API, but its functionality must remain the same.
- **halInternal:** API that is internal to the HAL. The EmberZNet stack and applications must never call this API directly. Custom applications can change this API as they see fit. However, be careful not to impact the functionality of any halStack or halCommon APIs.

See also [hal.h](#).

Common Microcontroller Functions

Common Microcontroller Functions

Many of the supplied example applications use these microcontroller functions. See [hal/micro/micro.h](#) for source code.

Note

- The term SFD refers to the Start Frame Delimiter.

Many of the supplied example applications use these microcontroller functions. See [hal/micro/micro-common.h](#) for source code.

Modules

[RTCCRamData](#)

Enumerations

```
enum SleepModes {
    SLEEPMODE_RUNNING = 0U
    SLEEPMODE_IDLE = 1U
    SLEEPMODE_WAKETIMER = 2U
    SLEEPMODE_MAINTAINTIMER = 3U
    SLEEPMODE_NOTIMER = 4U
    SLEEPMODE_HIBERNATE = 5U
    SLEEPMODE_RESERVED = 6U
    SLEEPMODE_POWERDOWN = 7U
    SLEEPMODE_POWERSAVE = 8U
}
```

Enumerations for the possible microcontroller sleep modes.

Typedefs

```
typedef uint32_t WakeEvents
```

```
typedef uint32_t WakeMask
```

Variables

```
volatile int8_t halCommonVreg1v8EnableCount
```

Helper variable to track the state of 1.8V regulator.

Functions

```
void halStackProcessBootCount(void)
```

Called from emberInit and provides a means for the HAL to increment a boot counter, most commonly in non-volatile memory.

```
uint8_t halGetResetInfo(void)
```

Gets information about what caused the microcontroller to reset.

PGM_P	halGetResetString(void) Calls halGetResetInfo() and supplies a string describing it.
void	halInit(void) Initializes microcontroller-specific peripherals.
void	halReboot(void) Restarts the microcontroller and therefore everything else.
void	halPowerUp(void) Powers up microcontroller peripherals and board peripherals.
void	halPowerDown(void) Powers down microcontroller peripherals and board peripherals.
void	halResume(void) Resumes microcontroller peripherals and board peripherals.
void	halSuspend(void) Suspends microcontroller peripherals and board peripherals.
void	halInternalEnableWatchDog(void) Enables the watchdog timer.
void	halInternalDisableWatchDog(uint8_t magicKey) Disables the watchdog timer.
bool	halInternalWatchDogEnabled(void) Determines whether the watchdog has been enabled or disabled.
void	halSleep(SleepModes sleepMode) Puts the microcontroller to sleep in a specified mode.
void	halSleepPreserveInts(SleepModes sleepMode) Same as halSleep() except it preserves the current interrupt state rather than always enabling interrupts prior to returning.
void	halCommonDelayMicroseconds(uint16_t us) Blocks the current thread of execution for the specified amount of time, in microseconds.
void	halCommonDisableVreg1v8(void) Disable the 1.8V regulator. This function is to be used when the 1.8V supply is provided externally. Disabling the regulator saves current consumption. Disabling the regulator will cause ADC readings of external signals to be wrong. These external signals include analog sources ADC0 thru ADC5 and VDD_PADS/4.
void	halCommonEnableVreg1v8(void) Enable the 1.8V regulator. Normally the 1.8V regulator is enabled out of reset. This function is only needed if the 1.8V regulator has been disabled and ADC conversions on external signals are needed. These external signals include analog sources ADC0 thru ADC5 and VDD_PADS/4. The state of 1v8 survives deep sleep.
void	halBeforeEM4(uint32_t duration, RTCCRamData input)
RTCCRamData	halAfterEM4(void)

Macros

#define	halGetEm2xxResetInfo () Calls ::halGetExtendedResetInfo() and translates the EM35x reset code to the corresponding value used by the EM2XX HAL. Any reset codes not present in the EM2XX are returned after being OR'ed with 0x80.
---------	---

```
#define MICRO_DISABLE_WATCH_DOG_KEY 0xA5U
    The value that must be passed as the single parameter to halInternalDisableWatchDog\(\) in order to successfully disable
    the watchdog timer.

#define GPIO_MASK_SIZE 24

#define GPIO_MASK 0xFFFFFFFF

#define WAKE_GPIO_MASK GPIO_MASK

#define WAKE_GPIO_SIZE GPIO_MASK_SIZE

#define WAKE_MASK_INVALID (-1)

#define WAKE_EVENT_SIZE WakeMask

#define DEBUG_TOGGLE (n)
```

Enumeration Documentation

SleepModes

SleepModes

Enumerations for the possible microcontroller sleep modes.

- SLEEPMODE_RUNNING Everything is active and running. In practice this mode is not used, but it is defined for completeness of information.
- SLEEPMODE_IDLE Only the CPU is idled. The rest of the chip continues running normally. The chip will wake from any interrupt.
- SLEEPMODE_WAKETIMER The sleep timer clock sources remain running. The RC is always running and the 32kHz XTAL depends on the board header. Wakeup is possible from both GPIO and the sleep timer. System time is maintained. The sleep timer is assumed to be configured properly for wake events.
- SLEEPMODE_MAINTAINTIMER The sleep timer clock sources remain running. The RC is always running and the 32kHz XTAL depends on the board header. Wakeup is possible from only GPIO. System time is maintained. NOTE: This mode is not available on EM2XX chips.
- SLEEPMODE_NOTIMER The sleep timer clock sources (both RC and XTAL) are turned off. Wakeup is possible from only GPIO. System time is lost.
- SLEEPMODE_HIBERNATE This maps to EM4 Hibernate on the EFM32/EFR32 devices. RAM is not retained in SLEEPMODE_HIBERNATE so waking up from this sleepmode will behave like a reset. NOTE: This mode is only available on EFM32/EFR32

Enumerator

SLEEPMODE_RUNNING	
SLEEPMODE_IDLE	
SLEEPMODE_WAKETIMER	
SLEEPMODE_MAINTAINTIMER	
SLEEPMODE_NOTIMER	
SLEEPMODE_HIBERNATE	
SLEEPMODE_RESERVED	
SLEEPMODE_POWERDOWN	
SLEEPMODE_POWERSAVE	

Definition at line 106 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

Typedef Documentation

WakeEvents

```
typedef uint32_t WakeEvents
```

Definition at line 141 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

WakeMask

```
typedef uint32_t WakeMask
```

Definition at line 142 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

Variable Documentation

halCommonVreg1v8EnableCount

```
volatile int8_t halCommonVreg1v8EnableCount
```

Helper variable to track the state of 1.8V regulator.

Note

- : Only used when `DISABLE_INTERNAL_1V8_REGULATOR` is defined.

Definition at line 195 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

Function Documentation

halStackProcessBootCount

```
void halStackProcessBootCount (void)
```

Called from emberlnit and provides a means for the HAL to increment a boot counter, most commonly in non-volatile memory.

Parameters

N/A

This is useful while debugging to determine the number of resets that might be seen over a period of time. Exposing this functionality allows the application to disable or alter processing of the boot counter if, for example, the application is expecting a lot of resets that could wear out non-volatile storage or some

- **EmberStack Usage:** Called from emberlnit only as helpful debugging information.

This should be left enabled by default, but this function can also be reduced to a simple return statement if boot counting is not desired.

Definition at line 68 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro.h`

halGetResetInfo

```
uint8_t halGetResetInfo (void)
```

Gets information about what caused the microcontroller to reset.

Parameters

N/A

Returns

- A code identifying the cause of the reset.

Definition at line 74 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro.h

halGetResetString

```
PGM_P halGetResetString (void)
```

Calls [halGetResetInfo\(\)](#) and supplies a string describing it.

Parameters

N/A

- Application Usage:
Useful for diagnostic printing of text just after program

initialization.

Returns

- A pointer to a program space string.

Definition at line 83 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro.h

hallnit

```
void hallnit (void)
```

Initializes microcontroller-specific peripherals.

Parameters

N/A

Definition at line 30 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halReboot

```
void halReboot (void)
```

Restarts the microcontroller and therefore everything else.

Parameters

N/A

Definition at line 34 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halPowerUp

```
void halPowerUp (void)
```

Powers up microcontroller peripherals and board peripherals.

Parameters

N/A		
-----	--	--

Definition at line 38 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halPowerDown

```
void halPowerDown (void)
```

Powers down microcontroller peripherals and board peripherals.

Parameters

N/A		
-----	--	--

Definition at line 42 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halResume

```
void halResume (void)
```

Resumes microcontroller peripherals and board peripherals.

Parameters

N/A		
-----	--	--

Definition at line 46 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halSuspend

```
void halSuspend (void)
```

Suspends microcontroller peripherals and board peripherals.

Parameters

N/A		
-----	--	--

Definition at line 50 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halInternalEnableWatchDog

```
void halInternalEnableWatchDog (void)
```

Enables the watchdog timer.

Parameters

N/A

Definition at line 60 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halInternalDisableWatchDog

```
void halInternalDisableWatchDog (uint8_t magicKey)
```

Disables the watchdog timer.

Parameters

N/A	magicKey	A value (MICRO_DISABLE_WATCH_DOG_KEY) that enables the function.
-----	----------	--

Note

- To prevent the watchdog from being disabled accidentally, a magic key must be provided.

Definition at line 69 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halInternalWatchDogEnabled

```
bool halInternalWatchDogEnabled (void)
```

Determines whether the watchdog has been enabled or disabled.

Parameters

N/A

Returns

- A bool value indicating if the watchdog is current enabled.

Definition at line 75 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halSleep

```
void halSleep (SleepModes sleepMode)
```

Puts the microcontroller to sleep in a specified mode.

Parameters

N/A	sleepMode	A microcontroller sleep mode
-----	-----------	------------------------------

Note

- This routine always enables interrupts.

See Also

- [SleepModes](#)

Definition at line 160 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

halSleepPreserveInts

```
void halSleepPreserveInts (SleepModes sleepMode)
```

Same as [halSleep\(\)](#) except it preserves the current interrupt state rather than always enabling interrupts prior to returning.

Parameters

N/A	sleepMode	A microcontroller sleep mode
-----	-----------	------------------------------

See Also

- [SleepModes](#)

Definition at line 169 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

halCommonDelayMicroseconds

```
void halCommonDelayMicroseconds (uint16_t us)
```

Blocks the current thread of execution for the specified amount of time, in microseconds.

Parameters

N/A	us	The specified time, in microseconds. Values should be between 1 and 65535 microseconds.
-----	----	---

The function is implemented with cycle-counted busy loops and is intended to create the short delays required when interfacing with hardware peripherals.

The accuracy of the timing provided by this function is not specified, but a general rule is that when running off of a crystal oscillator it will be within 10us. If the micro is running off of another type of oscillator (e.g. RC) the timing accuracy will potentially be much worse.

Definition at line 186 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

halCommonDisableVreg1v8

```
void halCommonDisableVreg1v8 (void)
```

Disable the 1.8V regulator. This function is to be used when the 1.8V supply is provided externally. Disabling the regulator saves current consumption. Disabling the regulator will cause ADC readings of external signals to be wrong. These external signals include analog sources ADC0 thru ADC5 and VDD_PADS/4.

Parameters

N/A		
-----	--	--

Note

- : Only used when `DISABLE_INTERNAL_1V8_REGULATOR` is defined.

Definition at line 206 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

halCommonEnableVreg1v8

```
void halCommonEnableVreg1v8 (void)
```

Enable the 1.8V regulator. Normally the 1.8V regulator is enabled out of reset. This function is only needed if the 1.8V regulator has been disabled and ADC conversions on external signals are needed. These external signals include analog sources ADC0 thru ADC5 and VDD_PADS/4. The state of 1v8 survives deep sleep.

Parameters

N/A		
-----	--	--

Note

- : Only used when DISABLE_INTERNAL_1V8_REGULATOR is defined.

Definition at line 217 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

halBeforeEM4

```
void halBeforeEM4 (uint32_t duration, RTCCRamData input)
```

Parameters

N/A	duration	
N/A	input	

Definition at line 228 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

halAfterEM4

```
RTCCRamData halAfterEM4 (void)
```

Parameters

N/A		
-----	--	--

Definition at line 229 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

Macro Definition Documentation

halGetEm2xxResetInfo

```
#define halGetEm2xxResetInfo
```

Value:

```
0
```

Calls `::halGetExtendedResetInfo()` and translates the EM35x reset code to the corresponding value used by the EM2XX HAL. Any reset codes not present in the EM2XX are returned after being OR'ed with 0x80.

- **Application Usage:** Used by the EZSP host as a platform-independent NCP reset code.

Returns

- The EM2XX-compatible reset code. If not supported by the EM2XX, return the platform-specific code with B7 set.

Definition at line 98 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro.h

MICRO_DISABLE_WATCH_DOG_KEY

```
#define MICRO_DISABLE_WATCH_DOG_KEY
```

Value:

```
0xA5U
```

The value that must be passed as the single parameter to [halInternalDisableWatchDog\(\)](#) in order to successfully disable the watchdog timer.

Definition at line 56 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

GPIO_MASK_SIZE

```
#define GPIO_MASK_SIZE
```

Value:

```
24
```

Definition at line 137 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

GPIO_MASK

```
#define GPIO_MASK
```

Value:

```
0xFFFFFFFF
```

Definition at line 138 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

WAKE_GPIO_MASK

```
#define WAKE_GPIO_MASK
```

Value:

```
GPIO_MASK
```

Definition at line 139 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

WAKE_GPIO_SIZE

```
#define WAKE_GPIO_SIZE
```

Value:

```
GPIO_MASK_SIZE
```

Definition at line 140 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h

```
#define WAKE_MASK_INVALID
```

Value:

```
(-1)
```

Definition at line 145 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

WAKE_EVENT_SIZE

```
#define WAKE_EVENT_SIZE
```

Value:

```
WakeMask
```

Note

- The preprocessor symbol WAKE_EVENT_SIZE has been deprecated. Please use WakeMask instead.

Definition at line 150 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

DEBUG_TOGGLE

```
#define DEBUG_TOGGLE
```

Definition at line 188 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

RTCCRamData

Public Attributes

uint32_t [outgoingNwkFrameCounter](#)

uint32_t [incomingParentNwkFrameCounter](#)

uint32_t [outgoingLinkKeyFrameCounter](#)

uint32_t [incomingLinkKeyFrameCounter](#)

Public Attribute Documentation

outgoingNwkFrameCounter

```
uint32_t RTCCRamData::outgoingNwkFrameCounter
```

Definition at line 223 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

incomingParentNwkFrameCounter

```
uint32_t RTCCRamData::incomingParentNwkFrameCounter
```

Definition at line 224 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

outgoingLinkKeyFrameCounter

```
uint32_t RTCCRamData::outgoingLinkKeyFrameCounter
```

Definition at line 225 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

incomingLinkKeyFrameCounter

```
uint32_t RTCCRamData::incomingLinkKeyFrameCounter
```

Definition at line 226 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/micro-common.h`

Token Access

Token Access

The token system stores such non-volatile information as the manufacturing ID, channel number, transmit power, and various pieces of information that the application needs to be persistent between device power cycles. The token system is design to abstract implementation details and simplify interacting with differing non-volatile systems. The majority of tokens are stored in Simulated EEPROM or NVM3 (in Flash) where they can be rewritten. Manufacturing tokens are stored in dedicated regions of flash and are not designed to be rewritten.

Refer to the [Tokens](#) module for a detailed description of the token system. Refer to the [Simulated EEPROM](#) module for a detailed description of the necessary support functions for Simulated EEPROM. Refer to the [simeeprom2](#) module for a detailed description of the necessary support functions for Simulated EEPROM, version 2. Refer to the [nvm3](#) module for a detailed description of the necessary support functions for NVM3. Refer to [token-stack.h](#) for stack token definitions. Refer to [token-manufacturing.h](#) for manufacturing token definitions.**Note**

- Simulated EEPROM, version 2 is only supported on EM335x chips.
- NVM3 is currently only supported on EFX32 chips.

Modules

[Tokens](#)

[Simulated EEPROM](#)

Tokens

Tokens

There are three main types of tokens:

- **Manufacturing tokens:** Tokens that are set at the factory and must not be changed through software operations.
- **Stack-level tokens:** Tokens that can be changed via the appropriate stack API calls.
- **Application level tokens:** Tokens that can be set via the token system API calls in this file.

The token system API controls writing tokens to non-volatile data and reading tokens from non-volatile data. If an application wishes to use application specific normal tokens, it must do so by creating its own token header file similar to [token-stack.h](#). The macro `APPLICATION_TOKEN_HEADER` should be defined to equal the name of the header file in which application tokens are defined. If an application wishes to use application specific manufacturing tokens, it must do so by creating its own manufacturing token header file similar to `token-manufacturing.h`. The macro `APPLICATION_MFG_TOKEN_HEADER` should be defined to equal the name of the header file in which manufacturing tokens are defined.

Because the token system is based on memory locations within non-volatile storage, the token information could become out of sync without some kind of version tracking. The two defines, `CURRENT_MFG_TOKEN_VERSION` and `CURRENT_STACK_TOKEN_VERSION`, are used to make sure the stack stays in sync with the proper token set. If the application defines its own tokens, it is recommended that the application also define an application token to be a application version to ensure the application stays in sync with the proper token set.

The most general format of a token definition is:

```
#define CREATOR_name 16bit_value
#define NVM3KEY_name 20bit_value
#ifdef DEFINETYPES
    typedef data_type type
#endif
#ifdef DEFINETOKENS
    DEFINE_*_TOKEN(name, type, ..., defaults)
#endif
```

The defined CREATOR is used as a distinct identifier tag for the token when using Simulated EEPROM or with manufacturing tokens. The CREATOR is necessary because the token name is defined differently depending on underlying implementation, so the CREATOR makes sure token definitions and data stay tagged and known. The only requirement on these creator definitions is that they all must be unique. A favorite method for picking creator codes is to use two ASCII characters in order to make the codes more memorable. The 'name' part of the `#define CREATOR_name` must match the 'name' provided in the `DEFINE_*_TOKEN` because the token system uses this name to automatically link the two.

The defined NVM3KEY is used to map the token to an NVM3 key and is needed using NVM3 as the underlying storage mechanism. This key can also be used as an identifier for a token's NVM3 object when using the native NVM3 API. The NVM3 keys must be unique for one instance of the NVM3 backing storage. All tokens share the same NVM3 instance and hence all NVM3KEYS for tokens must be unique. The 'name' part of the `#define NVM3KEY_name` must match the 'name' provided in the `DEFINE_*_TOKEN` because the token system uses this name to automatically link the two. For indexed tokens, the 127 NVM3KEY values following the defined NVM3KEY for a token should also be reserved. This is done as one NVM3KEY is used for each index in an indexed token and hence these NVM3KEYS should not collide with the keys of other tokens.

As NVM3 is shared among several stacks and application code, the NVM3KEY values chosen must be defined in the correct region to avoid collisions.

The following NVM3KEY regions are defined: 0x0xxxx : User objects 0x1xxxx : zigbee stack objects 0x2xxxx : Thread stack objects 0x3xxxx : Connect stack objects 0x4xxxx : Bluetooth stack objects

The typedef provides a convenient and efficient abstraction of the token data. Since some tokens are structs with multiple pieces of data inside of them, type defining the token type allows more efficient and readable local copies of the tokens throughout the code.

The typedef is wrapped with an `#ifdef DEFINETYPES` because the typedefs and token defs live in the same file, and `DEFINETYPES` is used to select only the typedefs when the file is included. Similarly, the `DEFINE_*_TOKEN` is wrapped with an `#ifdef DEFINETOKENS` as a method for selecting only the token definitions when the file is included.

The abstract definition, `DEFINE_*_TOKEN(name, type, ... ,defaults)`, has seven possible complete definitions: `DEFINE_BASIC_TOKEN(name, type, ...)` `DEFINE_INDEXED_TOKEN(name, type, arraysize, ...)` `DEFINE_COUNTER_TOKEN(name, type, ...)` `DEFINE_MFG_TOKEN(name, type, address, ...)` The three fields common to all `DEFINE_*_TOKEN` are: name - The name of the token, which all information is tied to. type - Type of the token which is the same as the typedef mentioned before. ... - The default value to which the token is set upon initialization.

Note

- The old `DEFINE_FIXED*` token definitions are no longer used. They remain defined for backwards compatibility. In current systems, the Simulated EEPROM or NVM3 is used for storing non-manufacturing tokens and the Simulated EEPROM or NVM3 intelligently manages where tokens are stored to provide wear leveling across the flash memory and increase the number of write cycles. Manufacturing tokens live at a fixed address, but they must use `DEFINE_MFG_TOKEN` so the token system knows they are manufacturing tokens.

`DEFINE_BASIC_TOKEN` is the simplest definition and will be used for the majority of tokens (tokens that are not indexed, not counters, and not manufacturing). Basic tokens are designed for data storage that is always accessed as a single element.

`DEFINE_INDEXED_TOKEN` should be used on tokens that look like arrays. For example, data storage that looks like:

```
uint32_t myData[5]
```

This example data storage can be a token with typedef of `uint32_t` and defined as `INDEXED` with arraysize of 5. The extra field in this token definition is: arraysize - The number of elements in the indexed token. Indexed tokens are designed for data storage that is logically grouped together, but elements are accessed individually. Note that when assigning an NVM3KEY for an indexed token, the 126 higher numbered NVM3KEYs following the NVM3KEY that you define are reserved for that token and no other tokens should be defined with NVM3KEYs in this region.

`DEFINE_COUNTER_TOKEN` should be used on tokens that are simple numbers where the majority of operations on the token is to increment the count. The reason for using `DEFINE_COUNTER_TOKEN` instead of `DEFINE_BASIC_TOKEN` is the special support that the token system provides for incrementing counters. The function call `halCommonIncrementCounterToken()` only operates on counter tokens and is more efficient in terms of speed, data compression, and write cycles for incrementing simple numbers in the token system.

`DEFINE_MFG_TOKEN` is a `DEFINE_BASIC_TOKEN` token at a specific address and the token is manufacturing data that is written only once. The major difference is this token is designated manufacturing, which means the token system treats it differently from stack or app tokens. Primarily, a manufacturing token is written only once and lives at a fixed address outside of the Simulated EEPROM or NVM3 system. Being a write once token, the token system will also aid in debugging by asserting if there is an attempt to write a manufacturing token.

Here is an example of two application tokens. The definition is compatible with both Simulated EEPROM and NVM3 as both `CREATOR` and `NVM3KEY` defines are included.

```

#define CREATOR_SENSOR_NAME    0x5354
#define CREATOR_SENSOR_PARAMETERS 0x5350
#define NVM3KEY_SENSOR_NAME    0x0AB54
#define NVM3KEY_SENSOR_PARAMETERS 0x00150
#ifdef DEFINETYPES
typedef uint8_t tokTypeSensorName[10];
typedef struct {
    uint8_t initValues[5];
    uint8_t reportInterval;
    uint16_t calibrationValue;
} tokTypeSensorParameters;
#endif
#ifdef DEFINETOKENS
DEFINE_BASIC_TOKEN(SENSOR_NAME,
    tokTypeSensorName,
    {'U','N','A','M','E',' ',' ',' ',' ',' ',' '})
DEFINE_BASIC_TOKEN(SENSOR_PARAMETERS,
    tokTypeSensorParameters,
    {{0x01,0x02,0x03,0x04,0x05},5,0x0000})
#endif

```

Here is an example of how to use the two application tokens:

```

{
    tokTypeSensorName sensor;
    tokTypeSensorParameters params;

    halCommonGetToken(&sensor, TOKEN_SENSOR_NAME);
    halCommonGetToken(&params, TOKEN_SENSOR_PARAMETERS);
    if(params.calibrationValue == 0xBEEF) {
        params.reportInterval = 5;
    }
    halCommonSetToken(TOKEN_SENSOR_PARAMETERS, &params);
}

```

See [token-stack.h](#) to see the default set of tokens and their values.

The `nodetest` utility app can be used for generic manipulation such as loading default token values, viewing tokens, and writing tokens. **The `nodetest` utility cannot work with customer defined application tokens or manufacturing tokens. Using the `nodetest` utility will erase customer defined application tokens in the Simulated EEPROM and NVM3.**

The Simulated EEPROM or NVM3 will initialize tokens to their default values if the token does not yet exist, the token's creator code is changed, or the token's size changes.

Changing the number indexes in an INDEXED token will not alter existing entries. If the number of indexes is reduced, the entries that still fit in the token will retain their data and the entries that no longer fit will be erased. If the number of indexes is increased, the existing entries retain their data and the new entries are initialized to the token's defaults.

Further details on exact implementation can be found in code comments in [token-stack.h](#) file, the platform specific `token-manufacturing.h` file, the platform specific `token.h` file, and the platform specific `token.c` file.

Some functions in this file return an `EmberStatus` value. See [error-def.h](#) for definitions of all `EmberStatus` return values.

See [hal/micro/token.h](#) for source code.

Functions

`EmberStatus` `halStackInitTokens(void)`
 Initializes and enables the token system. Checks if the manufacturing and stack non-volatile data versions are correct.

Macros

- #define** [halCommonGetToken](#) (data, token)
Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_BASIC_TOKEN.
- #define** [halCommonGetMfgToken](#) (data, token)
Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_MFG_TOKEN.
- #define** [halCommonGetIndexedToken](#) (data, token, index)
Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_INDEXED_TOKEN.
- #define** [halCommonSetToken](#) (token, data)
Macro that sets the value of a token in non-volatile storage. This macro can only be used with tokens that are defined using DEFINE_BASIC_TOKEN.
- #define** [halCommonSetIndexedToken](#) (token, index, data)
Macro that sets the value of a token in non-volatile storage. This macro can only be used with tokens that are defined using DEFINE_INDEXED_TOKEN.
- #define** [halCommonIncrementCounterToken](#) (token)
Macro that increments the value of a token that is a counter. This macro can only be used with tokens that are defined using either DEFINE_COUNTER_TOKEN.

Function Documentation

halStackInitTokens

```
EmberStatus halStackInitTokens (void)
```

Initializes and enables the token system. Checks if the manufacturing and stack non-volatile data versions are correct.

Parameters

N/A		
-----	--	--

Returns

- An EmberStatus value indicating the success or failure of the command.

Definition at line 294 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h`

Macro Definition Documentation

halCommonGetToken

```
#define halCommonGetToken
```

Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_BASIC_TOKEN.

Note

- To better understand the parameters of this macro, refer to the example of token usage above.

Definition at line 318 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h`

halCommonGetMfgToken

```
#define halCommonGetMfgToken
```

Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_MFG_TOKEN.

Note

- To better understand the parameters of this macro, refer to the example of token usage above.

Definition at line 333 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h

halCommonGetIndexedToken

```
#define halCommonGetIndexedToken
```

Macro that copies the token value from non-volatile storage into a RAM location. This macro can only be used with tokens that are defined using DEFINE_INDEXED_TOKEN.

Note

- To better understand the parameters of this macro, refer to the example of token usage above.

Definition at line 349 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h

halCommonSetToken

```
#define halCommonSetToken
```

Macro that sets the value of a token in non-volatile storage. This macro can only be used with tokens that are defined using DEFINE_BASIC_TOKEN.

Note

- To better understand the parameters of this macro, refer to the example of token usage above. For EFR32 devices this function must not be called in IRQ context as it can cause data corruption.

Definition at line 365 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h

halCommonSetIndexedToken

```
#define halCommonSetIndexedToken
```

Macro that sets the value of a token in non-volatile storage. This macro can only be used with tokens that are defined using DEFINE_INDEXED_TOKEN.

Note

- To better understand the parameters of this macro, refer to the example of token usage above.

Definition at line 382 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h

halCommonIncrementCounterToken

```
#define halCommonIncrementCounterToken
```

Macro that increments the value of a token that is a counter. This macro can only be used with tokens that are defined using either `DEFINE_COUNTER_TOKEN`.

Note

- To better understand the parameters of this macro, refer to the example of token usage above.

Definition at line 395 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/token.h`

Simulated EEPROM

Simulated EEPROM

The Simulated EEPROM system (typically referred to as SimEE) is designed to operate under the [Token Access](#) API and provide a non-volatile storage system. Since the flash write cycles are finite, the Simulated EEPROM's primary purpose is to perform wear leveling across several hardware flash pages, ultimately increasing the number of times tokens may be written before a hardware failure.

The Simulated EEPROM needs to periodically perform a page erase operation to recover storage area for future token writes. The page erase operation requires an ATOMIC block of 21ms. Since this is such a long time to not be able to service any interrupts, the page erase operation is under application control providing the application the opportunity to decide when to perform the operation and complete any special handling needed that might be needed.

Note

- The best, safest, and recommended practice is for the application to regularly and always call the function [halSimEepromErasePage\(\)](#) when the application can expect and deal with the page erase delay. [halSimEepromErasePage\(\)](#) will immediately return if there is nothing to erase. If there is something that needs to be erased, doing so as regularly and as soon as possible will keep the SimEE in the healthiest state possible.

::ERASE_CRITICAL_THRESHOLD is the metric the freePtr is compared against. This metric is set to about 3/4 full. The freePtr is a marker used internally by the Simulated EEPROM to track where data ends and where available write space begins. If the freePtr crosses this threshold, [halSimEepromCallback\(\)](#) will be called with an EmberStatus of [EMBER_SIM_EEPROM_ERASE_PAGE_RED](#), indicating a critical need for the application to call [halSimEepromErasePage\(\)](#) which will erase a hardware page and provide fresh storage for the Simulated EEPROM to write token data. If freePtr is less than the threshold, the callback will have an EmberStatus of [EMBER_SIM_EEPROM_ERASE_PAGE_GREEN](#) indicating the application should call [halSimEepromErasePage\(\)](#) at its earliest convenience, but doing so is not critically important at this time.

Some functions in this file return an [EmberStatus](#) value. See [error-def.h](#) for definitions of all [EmberStatus](#) return values.

See [hal/plugin/sim-eeprom/sim-eeprom.h](#) for source code.

Functions

void	halSimEepromCallback(EmberStatus status) The Simulated EEPROM callback function, implemented by the application.
uint8_t	halSimEepromErasePage(void) Erases a hardware flash page, if needed.
uint8_t	halSimEepromPagesRemainingToBeErased(void) Get count of pages to be erased.
void	halSimEepromStatus(uint16_t *freeWordsUntilFull, uint16_t *totalPageUseCount) Provides two basic statistics.

Function Documentation

halSimEepromCallback

```
void halSimEepromCallback (EmberStatus status)
```

The Simulated EEPROM callback function, implemented by the application.

Parameters

N/A	status	An EmberStatus error code indicating one of the conditions described below.
-----	--------	---

This callback will report an EmberStatus of [EMBER_SIM_EEPROM_ERASE_PAGE_GREEN](#) whenever a token is set and a page needs to be erased. If the main application loop does not periodically call [halSimEepromErasePage\(\)](#), it is best to then erase a page in response to [EMBER_SIM_EEPROM_ERASE_PAGE_GREEN](#).

This callback will report an EmberStatus of [EMBER_SIM_EEPROM_ERASE_PAGE_RED](#) when the pages **must** be erased to prevent data loss. [halSimEepromErasePage\(\)](#) needs to be called until it returns 0 to indicate there are no more pages that need to be erased. Ignoring this indication and not erasing the pages will cause dropping the new data trying to be written.

This callback will report an EmberStatus of [EMBER_SIM_EEPROM_FULL](#) when the new data cannot be written due to unerased pages. **Not erasing pages regularly, not erasing in response to [EMBER_SIM_EEPROM_ERASE_PAGE_GREEN](#), or not erasing in response to [EMBER_SIM_EEPROM_ERASE_PAGE_RED](#) will cause [EMBER_SIM_EEPROM_FULL](#) and the new data will be lost!** Any future write attempts will be lost as well.

This callback will report an EmberStatus of [EMBER_SIM_EEPROM_REPAIRING](#) when the Simulated EEPROM needs to repair itself. While there's nothing for an app to do when the SimEE is going to repair itself (SimEE has to be fully functional for the rest of the system to work), alert the application to the fact that repairing is occurring. There are debugging scenarios where an app might want to know that repairing is happening; such as monitoring frequency. **Note**

- Common situations will trigger an expected repair, such as using a new chip or changing token definitions.

If the callback ever reports the status [EMBER_ERR_FLASH_WRITE_INHIBITED](#) or [EMBER_ERR_FLASH_VERIFY_FAILED](#), this indicates a catastrophic failure in flash writing, meaning either the address being written is not empty or the write itself has failed. If [EMBER_ERR_FLASH_WRITE_INHIBITED](#) is encountered, the function `::halInternalSimEeRepair(false)` should be called and the chip should then be reset to allow proper initialization to recover. If [EMBER_ERR_FLASH_VERIFY_FAILED](#) is encountered the Simulated EEPROM (and tokens) on the specific chip with this error should not be trusted anymore.

Definition at line 130 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/plugin/sim-eeeprom/sim-eeeprom.h`

halSimEepromErasePage

```
uint8_t halSimEepromErasePage (void)
```

Erases a hardware flash page, if needed.

Parameters

N/A

This function can be called at anytime from anywhere in the application (except ISRs) and will only take effect if needed (otherwise it will return immediately). Since this function takes 21ms to erase a hardware page during which interrupts cannot be serviced, it is preferable to call this function while in a state that can withstand being unresponsive for so long. The Simulated EEPROM will periodically request through the [halSimEepromCallback\(\)](#) that a page be erased. The Simulated EEPROM will never erase a page (which could result in data loss) and relies entirely on the application to call this function to approve a page erase (only one erase per call to this function).

The Simulated EEPROM depends on the ability to move between two Virtual Pages, which are comprised of multiple hardware pages. Before moving to the unused Virtual Page, all hardware pages comprising the unused Virtual Page must be erased first. The erase time of a hardware flash page is 21ms. During this time the chip will be unresponsive and unable to service an interrupt or execute any code (due to the flash being unavailable during the erase procedure). This function is used to trigger a page erase.

Returns

- A count of how many hardware pages are left to be erased. This return value allows for calling code to easily loop over this function until the function returns 0.

Definition at line 158 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/plugin/sim-eeeprom/sim-eeeprom.h

halSimEepromPagesRemainingToBeErased

```
uint8_t halSimEepromPagesRemainingToBeErased (void)
```

Get count of pages to be erased.

Parameters

N/A

This function returns the same value [halSimEepromErasePage\(\)](#) would return, but without modifying/erasing any flash.

Returns

- A count of how many hardware pages are left to be erased. This code assist with loops wanting to know how much is left to erase.

Definition at line 168 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/plugin/sim-eeeprom/sim-eeeprom.h

halSimEepromStatus

```
void halSimEepromStatus (uint16_t *freeWordsUntilFull, uint16_t *totalPageUseCount)
```

Provides two basic statistics.

Parameters

N/A	freeWordsUntilFull	Number of unused words available to SimEE until the SimEE is full and would trigger an EMBER_SIM_EEPROM_ERASE_PAGE_RED then EMBER_SIM_EEPROM_FULL callback.
N/A	totalPageUseCount	The value of the highest page counter indicating how many times the Simulated EEPROM has rotated physical flash pages (and approximate write cycles).

- The number of unused words until SimEE is full
- The total page use count

There is a lot of management and state processing involved with the Simulated EEPROM, and most of it has no practical purpose in the application. These two parameters provide a simple metric for knowing how soon the Simulated EEPROM will be full (::freeWordsUntilFull) and how many times (approximatly) SimEE has rotated pysical flash pages (::totalPageUseCount).

Definition at line 190 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/plugin/sim-eeeprom/sim-eeeprom.h

Sample APIs for Peripheral Access

Sample APIs for Peripheral Access

These are sample API for accessing peripherals and can be modified as needed for your applications.

Modules

[Serial UART Communication](#)

[Button Control](#)

[Buzzer Control](#)

[LED Control](#)

[Flash Memory Control](#)

Serial UART Communication

Serial UART Communication

This API contains the HAL interfaces that applications must implement for the high-level serial code.

This header describes the interface between the high-level serial APIs in `serial/serial.h` and the low level UART implementation.

Some functions in this file return an `EmberStatus` value. See `error-def.h` for definitions of all `EmberStatus` return values.

See `hal/micro/serial.h` for source code.

Serial HAL APIs

These functions must be implemented by the HAL in order for the serial code to operate. Only the higher-level serial code uses these functions, so they should not be called directly. The HAL should also implement the appropriate interrupt handlers to drain the TX queues and fill the RX FIFO queue.

- `EmberStatus` `halInternalUartInit(uint8_t port, SerialBaudRate rate, SerialParity parity, uint8_t stopBits)`
 Initializes the UART to the given settings (same parameters as `::emberSerialInit()`).
- `void` `halInternalPowerDownUart(void)`
 This function is typically called by `halPowerDown()` and it is responsible for performing all the work internal to the UART needed to stop the UART before a sleep cycle.
- `void` `halInternalPowerUpUart(void)`
 This function is typically called by `halPowerUp()` and it is responsible for performing all the work internal to the UART needed to restart the UART after a sleep cycle.
- `void` `halInternalStartUartTx(uint8_t port)`
 Called by serial code whenever anything is queued for transmission to start any interrupt-driven transmission. May be called when transmission is already in progress.
- `void` `halInternalStopUartTx(uint8_t port)`
 Called by serial code to stop any interrupt-driven serial transmission currently in progress.
- `EmberStatus` `halInternalForceWriteUartData(uint8_t port, uint8_t *data, uint8_t length)`
 Directly writes a byte to the UART for transmission, regardless of anything currently queued for transmission. Should wait for anything currently in the UART hardware registers to finish transmission first, and block until `data` is finished being sent.
- `EmberStatus` `halInternalForceReadUartByte(uint8_t port, uint8_t *dataByte)`
 Directly reads a byte from the UART for reception, regardless of anything currently queued for reception. Does not block if a data byte has not been received.
- `void` `halInternalWaitUartTxComplete(uint8_t port)`
 Blocks until the UART has finished transmitting any data in its hardware registers.
- `void` `halInternalRestartUart(void)`
 This function is typically called by `::halInternalPowerUpBoard()` and it is responsible for performing all the work internal to the UART needed to restart the UART after a sleep cycle. (For example, resyncing the DMA hardware and the serial FIFO.)

bool	halInternalUartFlowControlRxIsEnabled (uint8_t port) Checks to see if the host is allowed to send serial data to the ncp - i.e., it is not being held off by nCTS or an XOFF. Returns true if the host is able to send.
bool	halInternalUartXonRefreshDone (uint8_t port) When Xon/Xoff flow control is used, returns true if the host is not being held off and XON refreshing is complete.
bool	halInternalUartTxIsIdle (uint8_t port) Returns true if the uart transmitter is idle, including the transmit shift register.
bool	serialDropPacket (void) Testing function implemented by the upper layer. Determines whether the next packet should be dropped. Returns true if the next packet should be dropped, false otherwise.
#define	halInternalUartFlowControl (port) This function is used in FIFO mode when flow control is enabled. It is called from <code>emberSerialReadByte()</code> , and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.
#define	halInternalUartRxPump (port) This function exists only in software UART (SOFTUART) mode on the EM3xx. This function is called by <code>::emberSerialReadByte()</code> . It is responsible for maintaining synchronization between the <code>emSerialRxQueue</code> and the UART DMA.
#define	halInternalUart1FlowControlRxIsEnabled () This function is used in FIFO mode when flow control is enabled. It is called from <code>emberSerialReadByte()</code> , and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.
#define	halInternalUart1XonRefreshDone () This function is used in FIFO mode when flow control is enabled. It is called from <code>emberSerialReadByte()</code> , and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.
#define	halInternalUart1TxIsIdle () This function is used in FIFO mode when flow control is enabled. It is called from <code>emberSerialReadByte()</code> , and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.

Virtual UART API

API used by the stack in debug builds to receive data arriving over the virtual UART.

void	halStackReceiveVuartMessage (uint8_t *data, uint8_t length) When using a debug build with virtual UART support, this API is called by the stack when virtual UART data has been received over the debug channel.
------	---

Serial Mode Definitions

These are numerical definitions for the possible serial modes so that code can test for the one being used. There may be additional modes defined in the micro-specific `micro.h`.

#define	EMBER_SERIAL_UNUSED 0 A numerical definition for a possible serial mode the code can test for.
#define	EMBER_SERIAL_FIFO 1 A numerical definition for a possible serial mode the code can test for.
#define	EMBER_SERIAL_LOWLEVEL 2 A numerical definition for a possible serial mode the code can test for.

FIFO Utility Macros

Initializes the UART to the given settings (same parameters as `::emberSerialInit()`).

Parameters

N/A	port	Serial port number (0 or 1).
N/A	rate	Baud rate (see <code>SerialBaudRate</code>).
N/A	parity	Parity value (see <code>SerialParity</code>).
N/A	stopBits	Number of stop bits.

Returns

- An error code if initialization failed (such as invalid baud rate), otherwise `EMBER_SUCCESS`.

Definition at line 410 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalPowerDownUart

```
void halInternalPowerDownUart (void)
```

This function is typically called by `halPowerDown()` and it is responsible for performing all the work internal to the UART needed to stop the UART before a sleep cycle.

Parameters

N/A		
-----	--	--

Definition at line 419 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalPowerUpUart

```
void halInternalPowerUpUart (void)
```

This function is typically called by `halPowerUp()` and it is responsible for performing all the work internal to the UART needed to restart the UART after a sleep cycle.

Parameters

N/A		
-----	--	--

Definition at line 425 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalStartUartTx

```
void halInternalStartUartTx (uint8_t port)
```

Called by serial code whenever anything is queued for transmission to start any interrupt-driven transmission. May be called when transmission is already in progress.

Parameters

N/A	port	Serial port number (0 or 1).
-----	------	------------------------------

Definition at line 433 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalStopUartTx

```
void halInternalStopUartTx (uint8_t port)
```

Called by serial code to stop any interrupt-driven serial transmission currently in progress.

Parameters

N/A	port	Serial port number (0 or 1).
-----	------	------------------------------

Definition at line 440 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalForceWriteUartData

```
EmberStatus halInternalForceWriteUartData (uint8_t port, uint8_t *data, uint8_t length)
```

Directly writes a byte to the UART for transmission, regardless of anything currently queued for transmission. Should wait for anything currently in the UART hardware registers to finish transmission first, and block until `data` is finished being sent.

Parameters

N/A	port	Serial port number (0 or 1).
N/A	data	Pointer to the data to be transmitted.
N/A	length	The length of data to be transmitted

Definition at line 453 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalForceReadUartByte

```
EmberStatus halInternalForceReadUartByte (uint8_t port, uint8_t *dataByte)
```

Directly reads a byte from the UART for reception, regardless of anything currently queued for reception. Does not block if a data byte has not been received.

Parameters

N/A	port	Serial port number (0 or 1).
N/A	dataByte	The byte to receive data into.

Definition at line 463 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalWaitUartTxComplete

```
void halInternalWaitUartTxComplete (uint8_t port)
```

Blocks until the UART has finished transmitting any data in its hardware registers.

Parameters

N/A	port	Serial port number (0 or 1).
-----	------	------------------------------

Definition at line 470 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalRestartUart

```
void halInternalRestartUart (void)
```

This function is typically called by `::halInternalPowerUpBoard()` and it is responsible for performing all the work internal to the UART needed to restart the UART after a sleep cycle. (For example, resyncing the DMA hardware and the serial FIFO.)

Parameters

N/A		
-----	--	--

Definition at line 506 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalUartFlowControlRxIsEnabled

```
bool halInternalUartFlowControlRxIsEnabled (uint8_t port)
```

Checks to see if the host is allowed to send serial data to the ncp - i.e., it is not being held off by nCTS or an XOFF. Returns true is the host is able to send.

Parameters

N/A	port	
-----	------	--

Definition at line 513 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalUartXonRefreshDone

```
bool halInternalUartXonRefreshDone (uint8_t port)
```

When Xon/Xoff flow control is used, returns true if the host is not being held off and XON refreshing is complete.

Parameters

N/A	port	
-----	------	--

Definition at line 525 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalUartTxIsIdle

```
bool halInternalUartTxIsIdle (uint8_t port)
```

Returns true if the uart transmitter is idle, including the transmit shift register.

Parameters

N/A	port	
-----	------	--

Definition at line 537 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

serialDropPacket

```
bool serialDropPacket (void)
```

Testing function implemented by the upper layer. Determines whether the next packet should be dropped. Returns true if the next packet should be dropped, false otherwise.

Parameters

N/A

Definition at line 547 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

halInternalUartFlowControl

#define halInternalUartFlowControl

Value:

(port)

This function is used in FIFO mode when flow control is enabled. It is called from emberSerialReadByte(), and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.

Definition at line 484 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

halInternalUartRxPump

#define halInternalUartRxPump

Value:

(port)

This function exists only in software UART (SOFTUART) mode on the EM3xx. This function is called by ::emberSerialReadByte(). It is responsible for maintaining synchronization between the emSerialRxQueue and the UART DMA.

Definition at line 498 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

halInternalUart1FlowControlRxIsEnabled

#define halInternalUart1FlowControlRxIsEnabled

Value:

0

This function is used in FIFO mode when flow control is enabled. It is called from emberSerialReadByte(), and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.

Definition at line 516 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

halInternalUart1XonRefreshDone

#define halInternalUart1XonRefreshDone

Value:

0

This function is used in FIFO mode when flow control is enabled. It is called from `emberSerialReadByte()`, and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.

Definition at line 528 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

halInternalUart1TxIsIdle

```
#define halInternalUart1TxIsIdle
```

Value:

```
0
```

This function is used in FIFO mode when flow control is enabled. It is called from `emberSerialReadByte()`, and based on the number of bytes used in the uart receive queue, decides when to tell the host it may resume transmission.

Definition at line 541 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

Virtual UART API Documentation

halStackReceiveVuartMessage

```
void halStackReceiveVuartMessage (uint8_t *data, uint8_t length)
```

When using a debug build with virtual UART support, this API is called by the stack when virtual UART data has been received over the debug channel.

Parameters

N/A	data	Pointer to the the data received
N/A	length	Length of the data received

Definition at line 574 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

Serial Mode Definitions Documentation

EMBER_SERIAL_UNUSED

```
#define EMBER_SERIAL_UNUSED
```

Value:

```
0
```

A numerical definition for a possible serial mode the code can test for.

Definition at line 91 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h`

EMBER_SERIAL_FIFO

```
#define EMBER_SERIAL_FIFO
```

Value:

1

A numerical definition for a possible serial mode the code can test for.

Definition at line 92 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

EMBER_SERIAL_LOWLEVEL

```
#define EMBER_SERIAL_LOWLEVEL
```

Value:

2

A numerical definition for a possible serial mode the code can test for.

Definition at line 93 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

FIFO Utility Macros Documentation

FIFO_ENQUEUE

```
#define FIFO_ENQUEUE
```

Value:

```
0 | do {
0 |     (queue)->fifo[(queue)->head] = (data);
0 |     (queue)->head = (((queue)->head + 1) % (size));
0 |     (queue)->used++;
0 | } while (0)
```

Macro that enqueues a byte of data in a FIFO queue.

Definition at line 272 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

FIFO_DEQUEUE

```
#define FIFO_DEQUEUE
```

Value:

```
0 | (queue)->fifo[(queue)->tail];
0 | (queue)->tail = (((queue)->tail + 1) % (size));
0 | (queue)->used--
```

Macro that de-queues a byte of data from a FIFO queue.

Definition at line 287 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

Enumeration Documentation

SerialBaudRate

```
SerialBaudRate
```


halHostEnqueueTx

```
uint16_t halHostEnqueueTx (const uint8_t *data, uint16_t length)
```

Parameters

N/A	data	
N/A	length	

Definition at line 586 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

halHostFlushTx

```
void halHostFlushTx (void)
```

Parameters

N/A		
-----	--	--

Definition at line 587 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

serialCopyFromRx

```
uint16_t serialCopyFromRx (const uint8_t *data, uint16_t length)
```

Parameters

N/A	data	
N/A	length	

Definition at line 590 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

emLoadSerialTx

```
void emLoadSerialTx (void)
```

Parameters

N/A		
-----	--	--

Definition at line 593 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/serial.h

Button Control

Button Control

Sample API functions for using push-buttons.

See [button.h](#) for source code.

Button State Definitions

A set of numerical definitions for use with the button APIs indicating the state of a button.

```
#define BUTTON_PRESSED 1  
Button state is pressed.
```

```
#define BUTTON_RELEASED 0  
Button state is released.
```

Functions

- void [halInternalInitButton](#)(void)
Initializes the buttons. This function is automatically called by [halInit](#)() .
- uint8_t [halButtonState](#)(uint8_t button)
Returns the current state (pressed or released) of a button.
- uint8_t [halButtonPinState](#)(uint8_t button)
Returns the current state (pressed or released) of the pin associated with a button.
- void [halButtonIsr](#)(uint8_t button, uint8_t state)
A callback called in interrupt context whenever a button changes its state.

Button State Definitions Documentation

BUTTON_PRESSED

```
#define BUTTON_PRESSED
```

Value:

```
1
```

Button state is pressed.

Definition at line 32 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

BUTTON_RELEASED

```
#define BUTTON_RELEASED
```

Value:

```
0
```

Button state is released.

Definition at line 36 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

Function Documentation

halInternalInitButton

```
void halInternalInitButton (void)
```

Initializes the buttons. This function is automatically called by [hallnit\(\)](#).

Parameters

N/A		
-----	--	--

Definition at line 43 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

halButtonState

```
uint8_t halButtonState (uint8_t button)
```

Returns the current state (pressed or released) of a button.

Parameters

N/A	button	The button being queried, either BUTTON0 or BUTTON1 as defined in the appropriate BOARD_HEADER.
-----	--------	---

Note

- This function is correlated with [halButtonIsr\(\)](#) and so returns the shadow state rather than reading the actual state of the pin.

Returns

- [BUTTON_PRESSED](#) if the button is pressed or [BUTTON_RELEASED](#) if the button is not pressed.

Definition at line 56 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

halButtonPinState

```
uint8_t halButtonPinState (uint8_t button)
```

Returns the current state (pressed or released) of the pin associated with a button.

Parameters

N/A	button	The button being queried, either BUTTON0 or BUTTON1 as defined in the appropriate BOARD_HEADER.
-----	--------	---

This reads the actual state of the pin and can be used on startup to determine the initial position of the buttons.

Returns

- [BUTTON_PRESSED](#) if the button is pressed or [BUTTON_RELEASED](#) if the button is not pressed.

Definition at line 70 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

halButtonIsr

```
void halButtonIsr (uint8_t button, uint8_t state)
```

A callback called in interrupt context whenever a button changes its state.

Parameters

N/A	button	The button which has changed state, either BUTTON0 or BUTTON1 as defined in the appropriate BOARD_HEADER.
N/A	state	The new state of the button referenced by the button parameter, either BUTTON_PRESSED if the button has been pressed or BUTTON_RELEASED if the button has been released.

Application Usage: Must be implemented by the application. This function should

contain the functionality to be executed in response to changes of state in each of the buttons, or callbacks to the appropriate functionality.

Definition at line 86 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/button.h`

Buzzer Control

Buzzer Control

LED Control

LED Control

Sample API functions for controlling LEDs.

When specifying an LED to use, always use the BOARDLEDx definitions that are defined within the BOARD_HEADER.

See [led.h](#) for source code.

Typedefs

```
typedef enum HalBoardLeds HalBoardLeds;
HalBoardLeds
```

Ensures that the definitions from the BOARD_HEADER are always used as parameters to the LED functions.

Functions

- void [halInternalInitLed](#)(void)
Configures GPIOs pertaining to the control of LEDs.
- void [halToggleLed](#)(HalBoardLeds led)
Atomically wraps an XOR or similar operation for a single GPIO pin attached to an LED.
- void [halSetLed](#)(HalBoardLeds led)
Turns on (sets) a GPIO pin connected to an LED so that the LED turns on.
- void [halClearLed](#)(HalBoardLeds led)
Turns off (clears) a GPIO pin connected to an LED, which turns off the LED.
- void [halStackIndicateActivity](#)(bool turnOn)
Called by the stack to indicate activity over the radio (for both transmission and reception). It is called once with `turnOn` true and shortly thereafter with `turnOn` false.

Typedef Documentation

HalBoardLeds

```
typedef enum HalBoardLeds HalBoardLeds
```

Ensures that the definitions from the BOARD_HEADER are always used as parameters to the LED functions.

Definition at line 78 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h`

Function Documentation

halInternalInitLed

```
void halInternalInitLed (void)
```

Configures GPIOs pertaining to the control of LEDs.

Parameters

N/A		
-----	--	--

Definition at line 70 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h

halToggleLed

```
void halToggleLed (HalBoardLed led)
```

Atomically wraps an XOR or similar operation for a single GPIO pin attached to an LED.

Parameters

N/A	led	Identifier (from BOARD_HEADER) for the LED to be toggled.
-----	-----	---

Definition at line 90 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h

halSetLed

```
void halSetLed (HalBoardLed led)
```

Turns on (sets) a GPIO pin connected to an LED so that the LED turns on.

Parameters

N/A	led	Identifier (from BOARD_HEADER) for the LED to turn on.
-----	-----	--

Definition at line 97 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h

halClearLed

```
void halClearLed (HalBoardLed led)
```

Turns off (clears) a GPIO pin connected to an LED, which turns off the LED.

Parameters

N/A	led	Identifier (from BOARD_HEADER) for the LED to turn off.
-----	-----	---

Definition at line 104 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h

halStackIndicateActivity

```
void halStackIndicateActivity (bool turnOn)
```

Called by the stack to indicate activity over the radio (for both transmission and reception). It is called once with `turnOn` true and shortly thereafter with `turnOn` false.

Parameters

N/A	turnOn	See Usage.
-----	--------	------------

Typically does something interesting, such as change the state of an LED.

Definition at line 115 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/led.h`

Flash Memory Control

Flash Memory Control

Definition and description of public flash manipulation routines.

Note

- During an erase or a write the flash is not available, which means code will not be executable from flash. These routines still execute from flash, though, since the bus architecture can support doing so. **Additionally, this also means all interrupts will be disabled.**

Hardware documentation indicates 40us for a write and 21ms for an erase.

See [flash.h](#) for source code.

Functions

bool [halFlashEraselsActive](#)(void)
Tells the calling code if a Flash Erase operation is active.

Function Documentation

halFlashEraselsActive

```
bool halFlashEraselsActive (void)
```

Tells the calling code if a Flash Erase operation is active.

Parameters

N/A		
-----	--	--

This state is import to know because Flash Erasing is ATOMIC for 21ms and could disrupt interrupt latency. But if an ISR can know that it wasn't serviced immediately due to Flash Erasing, then the ISR has the opportunity to correct in whatever manner it needs to.

Returns

- A bool flag: true if Flash Erase is active, false otherwise.

Definition at line 46 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/flash.h`

System Timer Control

System Timer Control

Functions that provide access to the system clock.

A single system tick (as returned by [halCommonGetInt16uMillisecondTick\(\)](#) and [halCommonGetInt32uMillisecondTick\(\)](#)) is approximately 1 millisecond.

- When used with a 32.768kHz crystal, the system tick is 0.976 milliseconds.
- When used with a 3.6864MHz crystal, the system tick is 1.111 milliseconds.

A single quarter-second tick (as returned by [halCommonGetInt16uQuarterSecondTick\(\)](#)) is approximately 0.25 seconds.

The values used by the time support functions will wrap after an interval. The length of the interval depends on the length of the tick and the number of bits in the value. However, there is no issue when comparing time deltas of less than half this interval with a subtraction, if all data types are the same.

See [system-timer.h](#) for source code.

Functions

uint16_t	halInternalStartSystemTimer(void) Initializes the system tick.
uint16_t	halCommonGetInt16uMillisecondTick(void) Returns the current system time in system ticks, as a 16-bit value.
uint32_t	halCommonGetInt32uMillisecondTick(void) Returns the current system time in system ticks, as a 32-bit value.
uint64_t	halCommonGetInt64uMillisecondTick(void) Returns the current system time in system ticks, as a 64-bit value.
uint16_t	halCommonGetInt16uQuarterSecondTick(void) Returns the current system time in quarter second ticks, as a 16-bit value.
EmberStatus	halSleepForQuarterSeconds(uint32_t *duration) Uses the system timer to enter SLEEPMODE_WAKETIMER for approximately the specified amount of time (provided in quarter seconds).
EmberStatus	halSleepForMilliseconds(uint32_t *duration) Uses the system timer to enter SLEEPMODE_WAKETIMER for approximately the specified amount of time (provided in milliseconds). Note that since the system timer ticks at a rate of 1024Hz, a second is comprised of 1024 milliseconds in this function.
EmberStatus	halCommonIdleForMilliseconds(uint32_t *duration) Uses the system timer to enter SLEEPMODE_IDLE for approximately the specified amount of time (provided in milliseconds).

Macros

#define [halIdleForMilliseconds](#) (duration)

Function Documentation

halInternalStartSystemTimer

```
uint16_t halInternalStartSystemTimer (void)
```

Initializes the system tick.

Parameters

N/A

Returns

- Time to update the async registers after RTC is started (units of 100 microseconds).

Definition at line 57 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halCommonGetInt16uMillisecondTick

```
uint16_t halCommonGetInt16uMillisecondTick (void)
```

Returns the current system time in system ticks, as a 16-bit value.

Parameters

N/A

Returns

- The least significant 16 bits of the current system time, in system ticks.

Definition at line 66 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halCommonGetInt32uMillisecondTick

```
uint32_t halCommonGetInt32uMillisecondTick (void)
```

Returns the current system time in system ticks, as a 32-bit value.

Parameters

N/A

• EmberStack Usage:\n Unused, implementation optional.

Returns

- The least significant 32 bits of the current system time, in system ticks.

Definition at line 77 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halCommonGetInt64uMillisecondTick

```
uint64_t halCommonGetInt64uMillisecondTick (void)
```

Returns the current system time in system ticks, as a 64-bit value.

Parameters

N/A		
-----	--	--

• EmberStack Usage:\n Unused, implementation optional.

Returns

- 64 bits containing the current system time, in system ticks.

Definition at line 87 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halCommonGetInt16uQuarterSecondTick

```
uint16_t halCommonGetInt16uQuarterSecondTick (void)
```

Returns the current system time in quarter second ticks, as a 16-bit value.

Parameters

N/A		
-----	--	--

• EmberStack Usage:\n Unused, implementation optional.

Returns

- The least significant 16 bits of the current system time, in system ticks multiplied by 256.

Definition at line 98 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halSleepForQuarterSeconds

```
EmberStatus halSleepForQuarterSeconds (uint32_t *duration)
```

Uses the system timer to enter [SLEEPMODE_WAKETIMER](#) for approximately the specified amount of time (provided in quarter seconds).

Parameters

N/A	duration	The amount of time, expressed in quarter seconds, that the micro should be placed into SLEEPMODE_WAKETIMER . When the function returns, this parameter provides the amount of time remaining out of the original sleep time request (normally the return value will be 0).
-----	----------	--

This function returns [EMBER_SUCCESS](#) and the duration parameter is decremented to 0 after sleeping for the specified amount of time. If an interrupt occurs that brings the chip out of sleep, the function returns [EMBER_SLEEP_INTERRUPTED](#) and the duration parameter reports the amount of time remaining out of the original request.

Note

- This routine always enables interrupts.
- The maximum sleep time of the hardware is limited on AVR-based platforms to 8 seconds, on EM2XX-based platforms to 64 seconds, and on EM35x platforms to 48.5 days. Any sleep duration greater than this limit will wake up briefly (e.g. 16 microseconds) to reenable another sleep cycle.

The EM2xx has a 16 bit sleep timer, which normally runs at 1024Hz. In order to support long sleep durations, the chip will periodically wake up to manage a larger timer in software. This periodic wakeup is normally triggered once every 32 seconds. However, this period can be extended to once every 2.275 hours by building with `ENABLE_LONG_SLEEP_CYCLES` defined. This definition enables the use of a prescaler when sleeping for more than 63 seconds at a time. However, this define also imposes the following limitations:

1. The chip may only wake up from the sleep timer. (External GPIO wake events may not be used)
2. Each time a sleep cycle is performed, a loss of accuracy up to +/-750ms will be observed in the system timer.

EmberStack Usage:\n Unused, implementation optional.

Returns

- An EmberStatus value indicating the success or failure of the command.

Definition at line 141 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halSleepForMilliseconds

```
EmberStatus halSleepForMilliseconds (uint32_t *duration)
```

Uses the system timer to enter `SLEEPMODE_WAKETIMER` for approximately the specified amount of time (provided in milliseconds). Note that since the system timer ticks at a rate of 1024Hz, a second is comprised of 1024 milliseconds in this function.

Parameters

N/A	duration	The amount of time, expressed in milliseconds (1024 milliseconds = 1 second), that the micro should be placed into <code>SLEEPMODE_WAKETIMER</code> . When the function returns, this parameter provides the amount of time remaining out of the original sleep time request (normally the return value will be 0).
-----	----------	---

This function returns `EMBER_SUCCESS` and the duration parameter is decremented to 0 after sleeping for the specified amount of time. If an interrupt occurs that brings the chip out of sleep, the function returns `EMBER_SLEEP_INTERRUPTED` and the duration parameter reports the amount of time remaining out of the original request.

Note

- This routine always enables interrupts.
- This function is not implemented on AVR-based platforms.
- Sleep durations less than 3 milliseconds are not allowed on on EM2XX-based platforms. Any attempt to sleep for less than 3 milliseconds on EM2XX-based platforms will cause the function to immediately exit without sleeping and return `EMBER_SLEEP_INTERRUPTED`.
- The maximum sleep time of the hardware is limited on EM2XX-based platforms to 32 seconds. Any sleep duration greater than this limit will wake up briefly (e.g. 16 microseconds) to reenable another sleep cycle. Due to this limitation, this function should not be used with durations within 3 milliseconds of a multiple 32 seconds. The short sleep cycle that results from such durations is not handled reliably by the system timer on EM2XX-based platforms. If a sleep duration within 3 milliseconds of a multiple of 32 seconds is desired, `halSleepForQuarterSeconds` should be used.

EmberStack Usage:\n Unused, implementation optional.

Returns

- An EmberStatus value indicating the success or failure of the command.

Definition at line 184 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h

halCommonIdleForMilliseconds

```
EmberStatus halCommonIdleForMilliseconds (uint32_t *duration)
```

Uses the system timer to enter [SLEEPMODE_IDLE](#) for approximately the specified amount of time (provided in milliseconds).

Parameters

N/A	duration	The amount of time, expressed in milliseconds, that the micro should be placed into SLEEPMODE_IDLE . When the function returns, this parameter provides the amount of time remaining out of the original idle time request (normally the return value will be 0).
-----	----------	---

This function returns [EMBER_SUCCESS](#) and the duration parameter is decremented to 0 after idling for the specified amount of time. If an interrupt occurs that brings the chip out of idle, the function returns [EMBER_SLEEP_INTERRUPTED](#) and the duration parameter reports the amount of time remaining out of the original request.

Note

- This routine always enables interrupts.

• EmberStack Usage:\n Unused, implementation optional.

Returns

- An EmberStatus value indicating the success or failure of the command.

Definition at line 208 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h`

Macro Definition Documentation

halIdleForMilliseconds

```
#define halIdleForMilliseconds
```

Value:

```
(duration)
```

Definition at line 211 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/system-timer.h`

Symbol Timer Control

Symbol Timer Control

HAL Configuration

HAL Configuration

Modules

[Sample Breakout Board Configuration](#)

[IAR PLATFORM_HEADER Configuration](#)

[Common PLATFORM_HEADER Configuration](#)

[NVIC Configuration](#)

[Reset Cause Type Definitions](#)

Sample Breakout Board Configuration

Sample Breakout Board Configuration

IAR PLATFORM_HEADER Configuration

IAR PLATFORM_HEADER Configuration

Compiler and Platform specific definitions and typedefs for the IAR ARM C compiler.

Note

- [iar.h](#) should be included first in all source files by setting the preprocessor macro PLATFORM_HEADER to point to it. [iar.h](#) automatically includes [platform-common.h](#).

See [iar.h](#) and [platform-common.h](#) for source code.

Master Variable Types

LEGACY_PHY_BUILDThese are a set of typedefs to make the size of all variable declarations explicitly known.

typedef bool	boolean	A typedef to make the size of the variable explicitly known.
typedef unsigned char	int8u	Denotes that this platform supports 64-bit data-types.
typedef signed char	int8s	Denotes that this platform supports 64-bit data-types.
typedef unsigned short	int16u	Denotes that this platform supports 64-bit data-types.
typedef signed short	int16s	Denotes that this platform supports 64-bit data-types.
typedef unsigned int	int32u	Denotes that this platform supports 64-bit data-types.
typedef signed int	int32s	Denotes that this platform supports 64-bit data-types.
typedef unsigned long long	int64u	Denotes that this platform supports 64-bit data-types.
typedef signed long long	int64s	Denotes that this platform supports 64-bit data-types.
typedef unsigned int	PointerType	Denotes that this platform supports 64-bit data-types.
#define	HAL_HAS_INT64 undefined	Denotes that this platform supports 64-bit data-types.
#define	_HAL_USE_COMMON_PGM_ undefined	Use the Master Program Memory Declarations from platform-common.h .

Miscellaneous Macros

void [halInternalAssertFailed](#)(const char *filename, int lineNumber)
A prototype definition for use by the assert macro. (see [hal/micro/micro.h](#))

void [halInternalResetWatchDog](#)(void)
Macro to reset the watchdog timer. Note: be very very careful when using this as you can easily get into an infinite loop if you are not careful.

#define [BIGENDIAN_CPU](#) false
A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

#define [NTOHS](#) (val)
Define intrinsics for NTOHL and NTOHS to save code space by making endian.c compile to nothing.

#define [NTOHL](#) (val)
A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

#define [NO_STRIPPING](#) __root
A friendlier name for the compiler's intrinsic for not stripping.

#define [EEPROM](#) errorerror
A friendlier name for the compiler's intrinsic for eeprom reference.

#define [__SOURCEFILE__](#) __FILE__
The [SOURCEFILE](#) macro is used by asserts to list the filename if it isn't otherwise defined, set it to the compiler intrinsic which specifies the whole filename and path of the sourcefile.

#define [assert](#) (condition)
A custom implementation of the C language assert macro. This macro implements the conditional evaluation and calls the function [halInternalAssertFailed\(\)](#). (see [hal/micro/micro.h](#))

#define [halResetWatchdog](#) ()
A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

#define [UNUSED](#) undefined
Declare a variable as unused to avoid a warning. Has no effect in IAR builds.

#define [SIGNED_ENUM](#) undefined
Some platforms need to cast enum values that have the high bit set.

#define [STACK_FILL_VALUE](#) 0xCDCDCDCDU
Define the magic value that is interpreted by IAR C-SPY's Stack View.

#define [RAMFUNC](#) __ramfunc
Define a generic RAM function identifier to a compiler specific one.

#define [NO_OPERATION](#) ()
Define a generic no operation identifier to a compiler specific one.

#define [SET_REG_FIELD](#) (reg, field, value)
A convenience macro that makes it easy to change the field of a register to any unsigned value.

#define [SET_CMSIS_REG](#) (reg, mask, value)
A convenience macro that makes it easy to change a register using the provided mask(s) and value(s). Example:
`SET_CMSIS_REG(GPIO->P[1].CFGH, (_GPIO_P_CFGH_Px5_MASK | _GPIO_P_CFGH_Px6_MASK), (GPIO_P_CFGH_Px5_OUT | GPIO_P_CFGH_Px6_OUT));`

#define [SET_CMSIS_REG_FIELD](#) (reg, field, value)
A convenience macro that makes it easy to change the field of a register, as defined in CMSIS Device headers, to any unsigned value. Example using EM35xx: `SET_CMSIS_REG_FIELD(GPIO->P[0].CFGL, GPIO_P_CFGL_Px0, _GPIO_P_CFGL_Px0_OUT);`

```
#define simulatedTimePasses ()
Stub for code not running in simulation.

#define simulatedTimePassesMs (x)
Stub for code not running in simulation.

#define simulatedSerialTimePasses ()
Stub for code not running in simulation.

#define _HAL_USE_COMMON_DIVMOD_ undefined
Use the Divide and Modulus Operations from platform-common.h.

#define VAR_AT_SEGMENT (__variableDeclaration, __segmentName)
Provide a portable way to specify the segment where a variable lives.

#define STRINGIZE (X)
Convenience macro for turning a token into a string.

#define ALIGNMENT (X)
Provide a portable way to align data.

#define WEAK (__symbol)
Provide a portable way to specify a symbol as weak.

#define NO_INIT (__symbol)
Provide a portable way to specify a non initialized symbol.

#define STATIC_ASSERT (__condition, __errorstr)
Provide a portable way to specify a compile time assert.
```

External Declarations

If the line below is uncommented we will use Ember memory APIs, otherwise, we will use the C Standard library (memset,memcpy,memmove) APIs. These are routines that are defined in certain header files that we don't want to include, e.g. stdlib.h

```
int abs(int l)
Returns the absolute value of l (also called the magnitude of l). That is, if l is negative, the result is the opposite of l, but if l is nonnegative the result is l.

#define PLATCOMMONOKTOINCLUDE undefined
Include platform-common.h last to pick up defaults and common definitions.

#define MAIN_FUNCTION_PARAMETERS void
The kind of arguments the main function takes.

#define MAIN_FUNCTION_ARGUMENTS undefined
Include platform-common.h last to pick up defaults and common definitions.
```

Portable segment names

```
#define __NO_INIT_ ".noinitlegacy"
Portable segment names.

#define __DEBUG_CHANNEL_ "DEBUG_CHANNEL"
Portable segment names.

#define __INTVEC_ ".intvec"
Portable segment names.
```

```
#define \_\_CSTACK\_\_ "CSTACK"  
Portable segment names.  
  
#define \_\_RESETINFO\_\_ "RESETINFO"  
Portable segment names.  
  
#define \_\_DATA\_INIT\_\_ ".data_init"  
Portable segment names.  
  
#define \_\_DATA\_\_ ".data"  
Portable segment names.  
  
#define \_\_BSS\_\_ ".bss"  
Portable segment names.  
  
#define \_\_CONST\_\_ ".rodata"  
Portable segment names.  
  
#define \_\_TEXT\_\_ ".text"  
Portable segment names.  
  
#define \_\_TEXTRW\_INIT\_\_ ".textrw_init"  
Portable segment names.  
  
#define \_\_TEXTRW\_\_ ".textrw"  
Portable segment names.  
  
#define \_\_AAT\_\_ "AAT"  
Portable segment names.  
  
#define \_\_BAT\_\_ "BAT"  
Portable segment names.  
  
#define \_\_BAT\_INIT\_\_ "BAT"  
Portable segment names.  
  
#define \_\_FAT\_\_ "FAT"  
Portable segment names.  
  
#define \_\_RAT\_\_ "RAT"  
Portable segment names.  
  
#define \_\_SIMEE\_\_ "SIMEE"  
Portable segment names.  
  
#define \_\_PSSTORE\_\_ "PSSTORE"  
Portable segment names.  
  
#define \_\_LONGTOKEN\_\_ "LONGTOKEN"  
Portable segment names.  
  
#define \_\_EMHEAP\_\_ "EMHEAP"  
Portable segment names.  
  
#define \_\_GUARD\_REGION\_\_ "GUARD_REGION"  
Portable segment names.  
  
#define \_\_DLIB\_PERTHREAD\_INIT\_\_ "__DLIB_PERTHREAD_init"  
Portable segment names.  
  
#define \_\_DLIB\_PERTHREAD\_INITIALIZED\_DATA\_\_ "DLIB_PERTHREAD_INITIALIZED_DATA"  
Portable segment names.  
  
#define \_\_DLIB\_PERTHREAD\_ZERO\_DATA\_\_ "DLIB_PERTHREAD_ZERO_DATA"  
Portable segment names.
```

```
#define \_\_INTERNAL\_STORAGE\_\_ "INTERNAL_STORAGE"  
Portable segment names.  
  
#define \_\_LOCKBITS\_IN\_MAINFLASH\_\_ "LOCKBITS_IN_MAINFLASH"  
Portable segment names.  
  
#define \_\_UNRETAINED\_RAM\_\_ "UNRETAINED_RAM"  
Portable segment names.  
  
#define \_\_NO\_INIT\_SEGMENT\_BEGIN __segment_begin(__NO_INIT__)  
Portable segment names.  
  
#define \_\_DEBUG\_CHANNEL\_SEGMENT\_BEGIN __segment_begin(__DEBUG_CHANNEL__)  
Portable segment names.  
  
#define \_\_INTVEC\_SEGMENT\_BEGIN __segment_begin(__INTVEC__)  
Portable segment names.  
  
#define \_\_CSTACK\_SEGMENT\_BEGIN __segment_begin(__CSTACK__)  
Portable segment names.  
  
#define \_\_RESETINFO\_SEGMENT\_BEGIN __segment_begin(__RESETINFO__)  
Portable segment names.  
  
#define \_\_DATA\_INIT\_SEGMENT\_BEGIN __segment_begin(__DATA_INIT__)  
Portable segment names.  
  
#define \_\_DATA\_SEGMENT\_BEGIN __segment_begin(__DATA__)  
Portable segment names.  
  
#define \_\_BSS\_SEGMENT\_BEGIN __segment_begin(__BSS__)  
Portable segment names.  
  
#define \_\_CONST\_SEGMENT\_BEGIN __segment_begin(__CONST__)  
Portable segment names.  
  
#define \_\_TEXT\_SEGMENT\_BEGIN __segment_begin(__TEXT__)  
Portable segment names.  
  
#define \_\_TEXTRW\_INIT\_SEGMENT\_BEGIN __segment_begin(__TEXTRW_INIT__)  
Portable segment names.  
  
#define \_\_TEXTRW\_SEGMENT\_BEGIN __segment_begin(__TEXTRW__)  
Portable segment names.  
  
#define \_\_AAT\_SEGMENT\_BEGIN __segment_begin(__AAT__)  
Portable segment names.  
  
#define \_\_BAT\_SEGMENT\_BEGIN __segment_begin(__BAT__)  
Portable segment names.  
  
#define \_\_BAT\_INIT\_SEGMENT\_BEGIN __segment_begin(__BAT_INIT__)  
Portable segment names.  
  
#define \_\_FAT\_SEGMENT\_BEGIN __segment_begin(__FAT__)  
Portable segment names.  
  
#define \_\_RAT\_SEGMENT\_BEGIN __segment_begin(__RAT__)  
Portable segment names.  
  
#define \_\_SIMEE\_SEGMENT\_BEGIN __segment_begin(__SIMEE__)  
Portable segment names.
```

```
#define \_PSSTORE\_SEGMENT\_BEGIN __segment_begin(__PSSTORE__)  
Portable segment names.  
  
#define \_LONGTOKEN\_SEGMENT\_BEGIN __segment_begin(__LONGTOKEN__)  
Portable segment names.  
  
#define \_EMHEAP\_SEGMENT\_BEGIN __segment_begin(__EMHEAP__)  
Portable segment names.  
  
#define \_GUARD\_REGION\_SEGMENT\_BEGIN __segment_begin(__GUARD_REGION__)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_INIT\_SEGMENT\_BEGIN __segment_begin(__DLIB_PERTHREAD_INIT__)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_INITIALIZED\_DATA\_SEGMENT\_BEGIN  
\_\_segment\_begin\(\_\_DLIB\_PERTHREAD\_INITIALIZED\_DATA\_\_\)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_ZERO\_DATA\_SEGMENT\_BEGIN __segment_begin(__DLIB_PERTHREAD_ZERO_DATA__)  
Portable segment names.  
  
#define \_INTERNAL\_STORAGE\_SEGMENT\_BEGIN __segment_begin(__INTERNAL_STORAGE__)  
Portable segment names.  
  
#define \_LOCKBITS\_IN\_MAINFLASH\_SEGMENT\_BEGIN __segment_begin(__LOCKBITS_IN_MAINFLASH__)  
Portable segment names.  
  
#define \_UNRETAINED\_RAM\_SEGMENT\_BEGIN __segment_begin(__UNRETAINED_RAM__)  
Portable segment names.  
  
#define \_NO\_INIT\_SEGMENT\_END __segment_end(__NO_INIT__)  
Portable segment names.  
  
#define \_DEBUG\_CHANNEL\_SEGMENT\_END __segment_end(__DEBUG_CHANNEL__)  
Portable segment names.  
  
#define \_INTVEC\_SEGMENT\_END __segment_end(__INTVEC__)  
Portable segment names.  
  
#define \_CSTACK\_SEGMENT\_END __segment_end(__CSTACK__)  
Portable segment names.  
  
#define \_RESETINFO\_SEGMENT\_END __segment_end(__RESETINFO__)  
Portable segment names.  
  
#define \_DATA\_INIT\_SEGMENT\_END __segment_end(__DATA_INIT__)  
Portable segment names.  
  
#define \_DATA\_SEGMENT\_END __segment_end(__DATA__)  
Portable segment names.  
  
#define \_BSS\_SEGMENT\_END __segment_end(__BSS__)  
Portable segment names.  
  
#define \_CONST\_SEGMENT\_END __segment_end(__CONST__)  
Portable segment names.  
  
#define \_TEXT\_SEGMENT\_END __segment_end(__TEXT__)  
Portable segment names.  
  
#define \_TEXTRW\_INIT\_SEGMENT\_END __segment_end(__TEXTRW_INIT__)  
Portable segment names.
```

```
#define \_TEXTRW\_SEGMENT\_END __segment_end(__TEXTRW__)  
Portable segment names.  
  
#define \_AAT\_SEGMENT\_END __segment_end(__AAT__)  
Portable segment names.  
  
#define \_BAT\_SEGMENT\_END __segment_end(__BAT__)  
Portable segment names.  
  
#define \_BAT\_INIT\_SEGMENT\_END __segment_end(__BAT_INIT__)  
Portable segment names.  
  
#define \_FAT\_SEGMENT\_END __segment_end(__FAT__)  
Portable segment names.  
  
#define \_RAT\_SEGMENT\_END __segment_end(__RAT__)  
Portable segment names.  
  
#define \_SIMEE\_SEGMENT\_END __segment_end(__SIMEE__)  
Portable segment names.  
  
#define \_PSSTORE\_SEGMENT\_END __segment_end(__PSSTORE__)  
Portable segment names.  
  
#define \_LONGTOKEN\_SEGMENT\_END __segment_end(__LONGTOKEN__)  
Portable segment names.  
  
#define \_EMHEAP\_SEGMENT\_END __segment_end(__EMHEAP__)  
Portable segment names.  
  
#define \_GUARD\_REGION\_SEGMENT\_END __segment_end(__GUARD_REGION__)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_INIT\_SEGMENT\_END __segment_end(__DLIB_PERTHREAD_INIT__)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_INITIALIZED\_DATA\_SEGMENT\_END  
\_\_segment\_end\(\_\_DLIB\_PERTHREAD\_INITIALIZED\_DATA\_\_\)  
Portable segment names.  
  
#define \_DLIB\_PERTHREAD\_ZERO\_DATA\_SEGMENT\_END __segment_end(__DLIB_PERTHREAD_ZERO_DATA__)  
Portable segment names.  
  
#define \_INTERNAL\_STORAGE\_SEGMENT\_END __segment_end(__INTERNAL_STORAGE__)  
Portable segment names.  
  
#define \_LOCKBITS\_IN\_MAINFLASH\_SEGMENT\_END __segment_end(__LOCKBITS_IN_MAINFLASH__)  
Portable segment names.  
  
#define \_UNRETAINED\_RAM\_SEGMENT\_END __segment_end(__UNRETAINED_RAM__)  
Portable segment names.  
  
#define \_NO\_INIT\_SEGMENT\_SIZE __segment_size(__NO_INIT__)  
Portable segment names.  
  
#define \_DEBUG\_CHANNEL\_SEGMENT\_SIZE __segment_size(__DEBUG_CHANNEL__)  
Portable segment names.  
  
#define \_INTVEC\_SEGMENT\_SIZE __segment_size(__INTVEC__)  
Portable segment names.  
  
#define \_CSTACK\_SEGMENT\_SIZE __segment_size(__CSTACK__)  
Portable segment names.
```



```
#define _RESETINFO_SEGMENT_SIZE __segment_size(__RESETINFO__)  
Portable segment names.  
  
#define _DATA_INIT_SEGMENT_SIZE __segment_size(__DATA_INIT__)  
Portable segment names.  
  
#define _DATA_SEGMENT_SIZE __segment_size(__DATA__)  
Portable segment names.  
  
#define _BSS_SEGMENT_SIZE __segment_size(__BSS__)  
Portable segment names.  
  
#define _CONST_SEGMENT_SIZE __segment_size(__CONST__)  
Portable segment names.  
  
#define _TEXT_SEGMENT_SIZE __segment_size(__TEXT__)  
Portable segment names.  
  
#define _TEXTRW_INIT_SEGMENT_SIZE __segment_size(__TEXTRW_INIT__)  
Portable segment names.  
  
#define _TEXTRW_SEGMENT_SIZE __segment_size(__TEXTRW__)  
Portable segment names.  
  
#define _AAT_SEGMENT_SIZE __segment_size(__AAT__)  
Portable segment names.  
  
#define _BAT_SEGMENT_SIZE __segment_size(__BAT__)  
Portable segment names.  
  
#define _BAT_INIT_SEGMENT_SIZE __segment_size(__BAT_INIT__)  
Portable segment names.  
  
#define _FAT_SEGMENT_SIZE __segment_size(__FAT__)  
Portable segment names.  
  
#define _RAT_SEGMENT_SIZE __segment_size(__RAT__)  
Portable segment names.  
  
#define _SIMEE_SEGMENT_SIZE __segment_size(__SIMEE__)  
Portable segment names.  
  
#define _PSSTORE_SEGMENT_SIZE __segment_size(__PSSTORE__)  
Portable segment names.  
  
#define _LONGTOKEN_SEGMENT_SIZE __segment_size(__LONGTOKEN__)  
Portable segment names.  
  
#define _EMHEAP_SEGMENT_SIZE __segment_size(__EMHEAP__)  
Portable segment names.  
  
#define _GUARD_REGION_SEGMENT_SIZE __segment_size(__GUARD_REGION__)  
Portable segment names.  
  
#define _DLIB_PERTHREAD_INIT_SEGMENT_SIZE __segment_size(__DLIB_PERTHREAD_INIT__)  
Portable segment names.  
  
#define _DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_SIZE  
__segment_size(__DLIB_PERTHREAD_INITIALIZED_DATA__)  
Portable segment names.  
  
#define _DLIB_PERTHREAD_ZERO_DATA_SEGMENT_SIZE __segment_size(__DLIB_PERTHREAD_ZERO_DATA__)  
Portable segment names.
```

```
#define \_INTERNAL\_STORAGE\_SEGMENT\_SIZE __segment_size(__INTERNAL_STORAGE_)
Portable segment names.

#define \_LOCKBITS\_IN\_MAINFLASH\_SEGMENT\_SIZE __segment_size(__LOCKBITS_IN_MAINFLASH_)
Portable segment names.

#define \_UNRETAINED\_RAM\_SEGMENT\_SIZE __segment_size(__UNRETAINED_RAM_)
Portable segment names.
```

Functions

```
void \_executeBarrierInstructions(void)
```

Master Variable Types Documentation

boolean

```
typedef bool boolean
```

A typedef to make the size of the variable explicitly known.

Definition at line 82 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int8u

```
typedef unsigned char int8u
```

Denotes that this platform supports 64-bit data-types.

Definition at line 83 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int8s

```
typedef signed char int8s
```

Denotes that this platform supports 64-bit data-types.

Definition at line 84 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int16u

```
typedef unsigned short int16u
```

Denotes that this platform supports 64-bit data-types.

Definition at line 85 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int16s

```
typedef signed short int16s
```

Denotes that this platform supports 64-bit data-types.

Definition at line 86 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int32u

```
typedef unsigned int int32u
```

Denotes that this platform supports 64-bit data-types.

Definition at line 87 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int32s

```
typedef signed int int32s
```

Denotes that this platform supports 64-bit data-types.

Definition at line 88 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int64u

```
typedef unsigned long long int64u
```

Denotes that this platform supports 64-bit data-types.

Definition at line 89 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

int64s

```
typedef signed long long int64s
```

Denotes that this platform supports 64-bit data-types.

Definition at line 90 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

PointerType

```
typedef unsigned int PointerType
```

Denotes that this platform supports 64-bit data-types.

Definition at line 91 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

HAL_HAS_INT64

```
#define HAL_HAS_INT64
```

Denotes that this platform supports 64-bit data-types.

Definition at line 97 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_HAL_USE_COMMON_PGM_

```
#define _HAL_USE_COMMON_PGM_
```

Use the Master Program Memory Declarations from [platform-common.h](#).

Definition at line 102 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

Miscellaneous Macros Documentation

halInternalAssertFailed

```
void halInternalAssertFailed (const char *filename, int linenumber)
```

A prototype definition for use by the assert macro. (see [hal/micro/micro.h](#))

Parameters

N/A	filename	
N/A	linenumber	

Definition at line 152 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

halInternalResetWatchDog

```
void halInternalResetWatchDog (void)
```

Macro to reset the watchdog timer. Note: be very very careful when using this as you can easily get into an infinite loop if you are not careful.

Parameters

N/A		
-----	--	--

Definition at line 184 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

BIGENDIAN_CPU

```
#define BIGENDIAN_CPU
```

Value:

```
false
```

A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

Definition at line 115 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

NTOHS

```
#define NTOHS
```

Value:

```
(val)
```

Define intrinsics for NTOHL and NTOHS to save code space by making endian.c compile to nothing.

Definition at line 121 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

NTOHL

```
#define NTOHL
```

Value:

```
(val)
```

A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

Definition at line 122 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

NO_STRIPPING

```
#define NO_STRIPPING
```

Value:

```
__root
```

A friendlier name for the compiler's intrinsic for not stripping.

Definition at line 128 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

EEPROM

```
#define EEPROM
```

Value:

```
errorerror
```

A friendlier name for the compiler's intrinsic for eeprom reference.

Definition at line 134 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__SOURCEFILE__

```
#define __SOURCEFILE__
```

Value:

```
__FILE__
```

The **SOURCEFILE** macro is used by asserts to list the filename if it isn't otherwise defined, set it to the compiler intrinsic which specifies the whole filename and path of the sourcefile.

Definition at line 143 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

assert

```
#define assert
```

A custom implementation of the C language assert macro. This macro implements the conditional evaluation and calls the function `halInternalAssertFailed()`. (see [hal/micro/micro.h](#))

Definition at line 160 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

halResetWatchdog

```
#define halResetWatchdog
```

Value:

```
0
```

A convenient method for code to know what endiannes processor it is running on. For the Cortex-M3, we are little endian.

Definition at line 191 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

UNUSED

```
#define UNUSED
```

Declare a variable as unused to avoid a warning. Has no effect in IAR builds.

Definition at line 198 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

SIGNED_ENUM

```
#define SIGNED_ENUM
```

Some platforms need to cast enum values that have the high bit set.

Definition at line 203 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

STACK_FILL_VALUE

```
#define STACK_FILL_VALUE
```

Value:

```
0xCDCCDCDU
```

Define the magic value that is interpreted by IAR C-SPY's Stack View.

Definition at line 208 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

RAMFUNC

```
#define RAMFUNC
```

Value:

```
_ramfunc
```

Define a generic RAM function identifier to a compiler specific one.

Definition at line 218 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

NO_OPERATION

```
#define NO_OPERATION
```

Value:

```
0
```

Define a generic no operation identifier to a compiler specific one.

Definition at line 224 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

SET_REG_FIELD

```
#define SET_REG_FIELD
```

Value:

```
0 | do {
0 |     reg = ((reg & (~field##_MASK))
0 |           | (((uint32_t) value) << field##_BIT) \
0 |             & (field##_MASK));
0 | } while (0)
```

A convenience macro that makes it easy to change the field of a register to any unsigned value.

Definition at line 230 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

SET_CMSIS_REG

```
#define SET_CMSIS_REG
```

Value:

```
0 | do {
0 |     reg = (((reg) & (~mask)) | (value)); \
0 | } while (0)
```

A convenience macro that makes it easy to change a register using the provided mask(s) and value(s). Example:
 SET_CMSIS_REG(GPIO->P[1].CFGH, (_GPIO_P_CFGH_Px5_MASK | _GPIO_P_CFGH_Px6_MASK), (GPIO_P_CFGH_Px5_OUT |
 GPIO_P_CFGH_Px6_OUT));

Definition at line 247 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

SET_CMSIS_REG_FIELD

```
#define SET_CMSIS_REG_FIELD
```

Value:

```
0 | do {
0 |     reg = ((reg & (~_##field##_MASK)) \
0 |           | ((value << _##field##_SHIFT) \
0 |             & (_##field##_MASK))); \
0 | } while (0)
```

A convenience macro that makes it easy to change the field of a register, as defined in CMSIS Device headers, to any unsigned value. Example using EM35xx: SET_CMSIS_REG_FIELD(GPIO->P[0].CFGL, GPIO_P_CFGL_Px0, _GPIO_P_CFGL_Px0_OUT);

Definition at line 258 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

simulatedTimePasses

```
#define simulatedTimePasses
```

Stub for code not running in simulation.

Definition at line 268 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

simulatedTimePassesMs

```
#define simulatedTimePassesMs
```

Stub for code not running in simulation.

Definition at line 273 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

simulatedSerialTimePasses

```
#define simulatedSerialTimePasses
```

Stub for code not running in simulation.

Definition at line 278 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_HAL_USE_COMMON_DIVMOD_


```
#define _HAL_USE_COMMON_DIVMOD_
```

Use the Divide and Modulus Operations from [platform-common.h](#).

Definition at line 283 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

VAR_AT_SEGMENT

```
#define VAR_AT_SEGMENT
```

Value:

```
(__variableDeclaration, __segmentName)
```

Provide a portable way to specify the segment where a variable lives.

Definition at line 289 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

STRINGIZE

```
#define STRINGIZE
```

Value:

```
(x)
```

Convenience macro for turning a token into a string.

Definition at line 295 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

ALIGNMENT

```
#define ALIGNMENT
```

Value:

```
(x)
```

Provide a portable way to align data.

Definition at line 300 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

WEAK

```
#define WEAK
```

Value:

```
(__symbol)
```

Provide a portable way to specify a symbol as weak.

Definition at line 306 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

NO_INIT

```
#define NO_INIT
```

Value:

```
(_symbol)
```

Provide a portable way to specify a non initialized symbol.

Definition at line 312 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

STATIC_ASSERT

```
#define STATIC_ASSERT
```

Value:

```
(_condition, __errorstr)
```

Provide a portable way to specify a compile time assert.

Definition at line 318 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

External Declarations Documentation

abs

```
int abs (int l)
```

Returns the absolute value of `l` (also called the magnitude of `l`). That is, if `l` is negative, the result is the opposite of `l`, but if `l` is nonnegative the result is `l`.

Parameters

N/A	<code>l</code>	An integer.
-----	----------------	-------------

Returns

- A nonnegative integer.

Definition at line 527 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

PLATCOMMONOKTOINCLUDE

```
#define PLATCOMMONOKTOINCLUDE
```

Include [platform-common.h](#) last to pick up defaults and common definitions.

Definition at line 536 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

MAIN_FUNCTION_PARAMETERS

```
#define MAIN_FUNCTION_PARAMETERS
```

Value:

```
void
```

The kind of arguments the main function takes.

Definition at line 543 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

MAIN_FUNCTION_ARGUMENTS

```
#define MAIN_FUNCTION_ARGUMENTS
```

Include [platform-common.h](#) last to pick up defaults and common definitions.

Definition at line 544 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

Portable segment names Documentation

__NO_INIT__

```
#define __NO_INIT__
```

Value:

```
".noinitlegacy"
```

Portable segment names.

Definition at line 341 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

__DEBUG_CHANNEL__

```
#define __DEBUG_CHANNEL__
```

Value:

```
"DEBUG_CHANNEL"
```

Portable segment names.

Definition at line 344 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

__INTVEC__

```
#define __INTVEC__
```

Value:

```
".intvec"
```

Portable segment names.

Definition at line 345 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h`

__CSTACK__

```
#define __CSTACK__
```

Value:

```
"CSTACK"
```

Portable segment names.

Definition at line 346 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__RESETINFO__

```
#define __RESETINFO__
```

Value:

```
"RESETINFO"
```

Portable segment names.

Definition at line 347 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DATA_INIT__

```
#define __DATA_INIT__
```

Value:

```
".data_init"
```

Portable segment names.

Definition at line 348 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DATA__

```
#define __DATA__
```

Value:

```
".data"
```

Portable segment names.

Definition at line 349 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__BSS__

```
#define __BSS__
```

Value:

```
"bss"
```

Portable segment names.

Definition at line 350 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__CONST__

```
#define __CONST__
```

Value:

```
".rodata"
```

Portable segment names.

Definition at line 351 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__TEXT__

```
#define __TEXT__
```

Value:

```
".text"
```

Portable segment names.

Definition at line 352 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__TEXTRW_INIT__

```
#define __TEXTRW_INIT__
```

Value:

```
".textrw_init"
```

Portable segment names.

Definition at line 353 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__TEXTRW__

```
#define __TEXTRW__
```

Value:

```
".textrw"
```

Portable segment names.

Definition at line 354 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__AAT__

```
#define __AAT__
```

Value:

```
"AAT"
```

Portable segment names.

Definition at line 355 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__BAT__

```
#define __BAT__
```

Value:

```
"BAT"
```

Portable segment names.

Definition at line 356 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__BAT_INIT__

```
#define __BAT_INIT__
```

Value:

```
"BAT"
```

Portable segment names.

Definition at line 357 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__FAT__

```
#define __FAT__
```

Value:

```
"FAT"
```

Portable segment names.

Definition at line 358 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__RAT__

```
#define __RAT__
```

Value:

```
"RAT"
```

Portable segment names.

Definition at line 359 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__SIMEE__

```
#define __SIMEE__
```

Value:

```
"SIMEE"
```

Portable segment names.

Definition at line 360 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__PSSTORE__

```
#define __PSSTORE__
```

Value:

```
"PSSTORE"
```

Portable segment names.

Definition at line 361 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__LONGTOKEN__

```
#define __LONGTOKEN__
```

Value:

```
"LONGTOKEN"
```

Portable segment names.

Definition at line 362 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__EMHEAP__

```
#define __EMHEAP__
```

Value:

```
"EMHEAP"
```

Portable segment names.

Definition at line 363 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__GUARD_REGION__

```
#define __GUARD_REGION__
```

Value:

```
"GUARD_REGION"
```

Portable segment names.

Definition at line 364 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DLIB_PERTHREAD_INIT__

```
#define __DLIB_PERTHREAD_INIT__
```

Value:

```
"__DLIB_PERTHREAD_init"
```

Portable segment names.

Definition at line 365 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DLIB_PERTHREAD_INITIALIZED_DATA__

```
#define __DLIB_PERTHREAD_INITIALIZED_DATA__
```

Value:

```
"DLIB_PERTHREAD_INITIALIZED_DATA"
```

Portable segment names.

Definition at line 366 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DLIB_PERTHREAD_ZERO_DATA__

```
#define __DLIB_PERTHREAD_ZERO_DATA__
```

Value:

```
"DLIB_PERTHREAD_ZERO_DATA"
```

Portable segment names.

Definition at line 367 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__INTERNAL_STORAGE__

```
#define __INTERNAL_STORAGE__
```

Value:


```
"INTERNAL_STORAGE"
```

Portable segment names.

Definition at line 368 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__LOCKBITS_IN_MAINFLASH__

```
#define __LOCKBITS_IN_MAINFLASH__
```

Value:

```
"LOCKBITS_IN_MAINFLASH"
```

Portable segment names.

Definition at line 369 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__UNRETAINED_RAM__

```
#define __UNRETAINED_RAM__
```

Value:

```
"UNRETAINED_RAM"
```

Portable segment names.

Definition at line 370 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_NO_INIT_SEGMENT_BEGIN

```
#define _NO_INIT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_NO_INIT_)
```

Portable segment names.

Definition at line 408 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DEBUG_CHANNEL_SEGMENT_BEGIN

```
#define _DEBUG_CHANNEL_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_DEBUG_CHANNEL_)
```

Portable segment names.

Definition at line 409 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_INTVEC_SEGMENT_BEGIN

```
#define _INTVEC_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_INTVEC_)
```

Portable segment names.

Definition at line 410 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_CSTACK_SEGMENT_BEGIN

```
#define _CSTACK_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_CSTACK_)
```

Portable segment names.

Definition at line 411 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RESETINFO_SEGMENT_BEGIN

```
#define _RESETINFO_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_RESETINFO_)
```

Portable segment names.

Definition at line 412 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DATA_INIT_SEGMENT_BEGIN

```
#define _DATA_INIT_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_DATA_INIT_)
```

Portable segment names.

Definition at line 413 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DATA_SEGMENT_BEGIN

```
#define _DATA_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__DATA__)
```

Portable segment names.

Definition at line 414 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BSS_SEGMENT_BEGIN

```
#define _BSS_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__BSS__)
```

Portable segment names.

Definition at line 415 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_CONST_SEGMENT_BEGIN

```
#define _CONST_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__CONST__)
```

Portable segment names.

Definition at line 416 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXT_SEGMENT_BEGIN

```
#define _TEXT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__TEXT__)
```

Portable segment names.

Definition at line 417 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_INIT_SEGMENT_BEGIN

```
#define _TEXTRW_INIT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__TEXTRW_INIT__)
```

Portable segment names.

Definition at line 418 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_SEGMENT_BEGIN

```
#define _TEXTRW_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_TEXTRW_)
```

Portable segment names.

Definition at line 419 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_AAT_SEGMENT_BEGIN

```
#define _AAT_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_AAT_)
```

Portable segment names.

Definition at line 420 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_SEGMENT_BEGIN

```
#define _BAT_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_BAT_)
```

Portable segment names.

Definition at line 421 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_INIT_SEGMENT_BEGIN

```
#define _BAT_INIT_SEGMENT_BEGIN
```

Value:

```
_segment_begin(_BAT_INIT_)
```

Portable segment names.

Definition at line 422 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_FAT_SEGMENT_BEGIN

```
#define _FAT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_FAT_)
```

Portable segment names.

Definition at line 423 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RAT_SEGMENT_BEGIN

```
#define _RAT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_RAT_)
```

Portable segment names.

Definition at line 424 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_SIMEE_SEGMENT_BEGIN

```
#define _SIMEE_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_SIMEE_)
```

Portable segment names.

Definition at line 425 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_PSSTORE_SEGMENT_BEGIN

```
#define _PSSTORE_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_PSSTORE_)
```

Portable segment names.

Definition at line 426 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_LONGTOKEN_SEGMENT_BEGIN

```
#define _LONGTOKEN_SEGMENT_BEGIN
```

Value:

```
__segment_begin(_LONGTOKEN_)
```

Portable segment names.

Definition at line 427 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_EMHEAP_SEGMENT_BEGIN

```
#define _EMHEAP_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__EMHEAP__)
```

Portable segment names.

Definition at line 428 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_GUARD_REGION_SEGMENT_BEGIN

```
#define _GUARD_REGION_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__GUARD_REGION__)
```

Portable segment names.

Definition at line 429 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_INIT_SEGMENT_BEGIN

```
#define _DLIB_PERTHREAD_INIT_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__DLIB_PERTHREAD_INIT__)
```

Portable segment names.

Definition at line 430 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_BEGIN

```
#define _DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__DLIB_PERTHREAD_INITIALIZED_DATA__)
```

Portable segment names.

Definition at line 431 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_ZERO_DATA_SEGMENT_BEGIN

```
#define _DLIB_PERTHREAD_ZERO_DATA_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__DLIB_PERTHREAD_ZERO_DATA__)
```

Portable segment names.

Definition at line 432 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

INTERNAL_STORAGE_SEGMENT_BEGIN

```
#define _INTERNAL_STORAGE_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__INTERNAL_STORAGE__)
```

Portable segment names.

Definition at line 433 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

LOCKBITS_IN_MAINFLASH_SEGMENT_BEGIN

```
#define _LOCKBITS_IN_MAINFLASH_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__LOCKBITS_IN_MAINFLASH__)
```

Portable segment names.

Definition at line 434 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

UNRETAINED_RAM_SEGMENT_BEGIN

```
#define _UNRETAINED_RAM_SEGMENT_BEGIN
```

Value:

```
__segment_begin(__UNRETAINED_RAM__)
```

Portable segment names.

Definition at line 435 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

NO_INIT_SEGMENT_END

```
#define _NO_INIT_SEGMENT_END
```

Value:

```
__segment_end(__NO_INIT__)
```

Portable segment names.

Definition at line 437 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DEBUG_CHANNEL_SEGMENT_END

```
#define _DEBUG_CHANNEL_SEGMENT_END
```

Value:

```
_segment_end(__DEBUG_CHANNEL__)
```

Portable segment names.

Definition at line 438 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_INTVEC_SEGMENT_END

```
#define _INTVEC_SEGMENT_END
```

Value:

```
_segment_end(__INTVEC__)
```

Portable segment names.

Definition at line 439 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_CSTACK_SEGMENT_END

```
#define _CSTACK_SEGMENT_END
```

Value:

```
_segment_end(__CSTACK__)
```

Portable segment names.

Definition at line 440 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RESETINFO_SEGMENT_END

```
#define _RESETINFO_SEGMENT_END
```

Value:

```
_segment_end(__RESETINFO__)
```

Portable segment names.

Definition at line 441 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DATA_INIT_SEGMENT_END

```
#define _DATA_INIT_SEGMENT_END
```

Value:


```
__segment_end(__DATA_INIT__)
```

Portable segment names.

Definition at line 442 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DATA_SEGMENT_END

```
#define __DATA_SEGMENT_END
```

Value:

```
__segment_end(__DATA__)
```

Portable segment names.

Definition at line 443 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__BSS_SEGMENT_END

```
#define __BSS_SEGMENT_END
```

Value:

```
__segment_end(__BSS__)
```

Portable segment names.

Definition at line 444 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__CONST_SEGMENT_END

```
#define __CONST_SEGMENT_END
```

Value:

```
__segment_end(__CONST__)
```

Portable segment names.

Definition at line 445 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__TEXT_SEGMENT_END

```
#define __TEXT_SEGMENT_END
```

Value:

```
__segment_end(__TEXT__)
```

Portable segment names.

Definition at line 446 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_INIT_SEGMENT_END

```
#define _TEXTRW_INIT_SEGMENT_END
```

Value:

```
_segment_end(_TEXTRW_INIT_)
```

Portable segment names.

Definition at line 447 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_SEGMENT_END

```
#define _TEXTRW_SEGMENT_END
```

Value:

```
_segment_end(_TEXTRW_)
```

Portable segment names.

Definition at line 448 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_AAT_SEGMENT_END

```
#define _AAT_SEGMENT_END
```

Value:

```
_segment_end(_AAT_)
```

Portable segment names.

Definition at line 449 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_SEGMENT_END

```
#define _BAT_SEGMENT_END
```

Value:

```
_segment_end(_BAT_)
```

Portable segment names.

Definition at line 450 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_INIT_SEGMENT_END

```
#define _BAT_INIT_SEGMENT_END
```

Value:

```
__segment_end(__BAT_INIT__)
```

Portable segment names.

Definition at line 451 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_FAT_SEGMENT_END

```
#define _FAT_SEGMENT_END
```

Value:

```
__segment_end(__FAT__)
```

Portable segment names.

Definition at line 452 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RAT_SEGMENT_END

```
#define _RAT_SEGMENT_END
```

Value:

```
__segment_end(__RAT__)
```

Portable segment names.

Definition at line 453 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_SIMEE_SEGMENT_END

```
#define _SIMEE_SEGMENT_END
```

Value:

```
__segment_end(__SIMEE__)
```

Portable segment names.

Definition at line 454 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_PSSTORE_SEGMENT_END

```
#define _PSSTORE_SEGMENT_END
```

Value:

```
__segment_end(__PSSTORE__)
```

Portable segment names.

Definition at line 455 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_LONGTOKEN_SEGMENT_END

```
#define _LONGTOKEN_SEGMENT_END
```

Value:

```
_segment_end(_LONGTOKEN_)
```

Portable segment names.

Definition at line 456 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_EMHEAP_SEGMENT_END

```
#define _EMHEAP_SEGMENT_END
```

Value:

```
_segment_end(_EMHEAP_)
```

Portable segment names.

Definition at line 457 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_GUARD_REGION_SEGMENT_END

```
#define _GUARD_REGION_SEGMENT_END
```

Value:

```
_segment_end(_GUARD_REGION_)
```

Portable segment names.

Definition at line 458 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_INIT_SEGMENT_END

```
#define _DLIB_PERTHREAD_INIT_SEGMENT_END
```

Value:

```
_segment_end(_DLIB_PERTHREAD_INIT_)
```

Portable segment names.

Definition at line 459 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_END

```
#define _DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_END
```

Value:

```
__segment_end(__DLIB_PERTHREAD_INITIALIZED_DATA__)
```

Portable segment names.

Definition at line 460 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_ZERO_DATA_SEGMENT_END

```
#define _DLIB_PERTHREAD_ZERO_DATA_SEGMENT_END
```

Value:

```
__segment_end(__DLIB_PERTHREAD_ZERO_DATA__)
```

Portable segment names.

Definition at line 461 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_INTERNAL_STORAGE_SEGMENT_END

```
#define _INTERNAL_STORAGE_SEGMENT_END
```

Value:

```
__segment_end(__INTERNAL_STORAGE__)
```

Portable segment names.

Definition at line 462 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_LOCKBITS_IN_MAINFLASH_SEGMENT_END

```
#define _LOCKBITS_IN_MAINFLASH_SEGMENT_END
```

Value:

```
__segment_end(__LOCKBITS_IN_MAINFLASH__)
```

Portable segment names.

Definition at line 463 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_UNRETAINED_RAM_SEGMENT_END

```
#define _UNRETAINED_RAM_SEGMENT_END
```

Value:

```
__segment_end(__UNRETAINED_RAM__)
```

Portable segment names.

Definition at line 464 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_NO_INIT_SEGMENT_SIZE

```
#define _NO_INIT_SEGMENT_SIZE
```

Value:

```
__segment_size(_NO_INIT_)
```

Portable segment names.

Definition at line 466 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DEBUG_CHANNEL_SEGMENT_SIZE

```
#define _DEBUG_CHANNEL_SEGMENT_SIZE
```

Value:

```
__segment_size(_DEBUG_CHANNEL_)
```

Portable segment names.

Definition at line 467 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_INTVEC_SEGMENT_SIZE

```
#define _INTVEC_SEGMENT_SIZE
```

Value:

```
__segment_size(_INTVEC_)
```

Portable segment names.

Definition at line 468 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_CSTACK_SEGMENT_SIZE

```
#define _CSTACK_SEGMENT_SIZE
```

Value:

```
__segment_size(_CSTACK_)
```

Portable segment names.

Definition at line 469 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RESETINFO_SEGMENT_SIZE

```
#define _RESETINFO_SEGMENT_SIZE
```

Value:

```
__segment_size(__RESETINFO__)
```

Portable segment names.

Definition at line 470 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DATA_INIT_SEGMENT_SIZE

```
#define __DATA_INIT_SEGMENT_SIZE
```

Value:

```
__segment_size(__DATA_INIT__)
```

Portable segment names.

Definition at line 471 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DATA_SEGMENT_SIZE

```
#define __DATA_SEGMENT_SIZE
```

Value:

```
__segment_size(__DATA__)
```

Portable segment names.

Definition at line 472 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__BSS_SEGMENT_SIZE

```
#define __BSS_SEGMENT_SIZE
```

Value:

```
__segment_size(__BSS__)
```

Portable segment names.

Definition at line 473 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__CONST_SEGMENT_SIZE

```
#define __CONST_SEGMENT_SIZE
```

Value:

```
__segment_size(__CONST__)
```

Portable segment names.

Definition at line 474 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXT_SEGMENT_SIZE

```
#define _TEXT_SEGMENT_SIZE
```

Value:

```
_segment_size(_TEXT_)
```

Portable segment names.

Definition at line 475 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_INIT_SEGMENT_SIZE

```
#define _TEXTRW_INIT_SEGMENT_SIZE
```

Value:

```
_segment_size(_TEXTRW_INIT_)
```

Portable segment names.

Definition at line 476 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_TEXTRW_SEGMENT_SIZE

```
#define _TEXTRW_SEGMENT_SIZE
```

Value:

```
_segment_size(_TEXTRW_)
```

Portable segment names.

Definition at line 477 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_AAT_SEGMENT_SIZE

```
#define _AAT_SEGMENT_SIZE
```

Value:

```
_segment_size(_AAT_)
```

Portable segment names.

Definition at line 478 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_SEGMENT_SIZE

```
#define _BAT_SEGMENT_SIZE
```

Value:


```
__segment_size(_BAT_)
```

Portable segment names.

Definition at line 479 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_BAT_INIT_SEGMENT_SIZE

```
#define _BAT_INIT_SEGMENT_SIZE
```

Value:

```
__segment_size(_BAT_INIT_)
```

Portable segment names.

Definition at line 480 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_FAT_SEGMENT_SIZE

```
#define _FAT_SEGMENT_SIZE
```

Value:

```
__segment_size(_FAT_)
```

Portable segment names.

Definition at line 481 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_RAT_SEGMENT_SIZE

```
#define _RAT_SEGMENT_SIZE
```

Value:

```
__segment_size(_RAT_)
```

Portable segment names.

Definition at line 482 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_SIMEE_SEGMENT_SIZE

```
#define _SIMEE_SEGMENT_SIZE
```

Value:

```
__segment_size(_SIMEE_)
```

Portable segment names.

Definition at line 483 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_PSSTORE_SEGMENT_SIZE

```
#define _PSSTORE_SEGMENT_SIZE
```

Value:

```
_segment_size(_PSSTORE_)
```

Portable segment names.

Definition at line 484 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_LONGTOKEN_SEGMENT_SIZE

```
#define _LONGTOKEN_SEGMENT_SIZE
```

Value:

```
_segment_size(_LONGTOKEN_)
```

Portable segment names.

Definition at line 485 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_EMHEAP_SEGMENT_SIZE

```
#define _EMHEAP_SEGMENT_SIZE
```

Value:

```
_segment_size(_EMHEAP_)
```

Portable segment names.

Definition at line 486 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_GUARD_REGION_SEGMENT_SIZE

```
#define _GUARD_REGION_SEGMENT_SIZE
```

Value:

```
_segment_size(_GUARD_REGION_)
```

Portable segment names.

Definition at line 487 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_DLIB_PERTHREAD_INIT_SEGMENT_SIZE

```
#define _DLIB_PERTHREAD_INIT_SEGMENT_SIZE
```

Value:

```
__segment_size(__DLIB_PERTHREAD_INIT__)
```

Portable segment names.

Definition at line 488 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_SIZE

```
#define __DLIB_PERTHREAD_INITIALIZED_DATA_SEGMENT_SIZE
```

Value:

```
__segment_size(__DLIB_PERTHREAD_INITIALIZED_DATA__)
```

Portable segment names.

Definition at line 489 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__DLIB_PERTHREAD_ZERO_DATA_SEGMENT_SIZE

```
#define __DLIB_PERTHREAD_ZERO_DATA_SEGMENT_SIZE
```

Value:

```
__segment_size(__DLIB_PERTHREAD_ZERO_DATA__)
```

Portable segment names.

Definition at line 490 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__INTERNAL_STORAGE_SEGMENT_SIZE

```
#define __INTERNAL_STORAGE_SEGMENT_SIZE
```

Value:

```
__segment_size(__INTERNAL_STORAGE__)
```

Portable segment names.

Definition at line 491 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

__LOCKBITS_IN_MAINFLASH_SEGMENT_SIZE

```
#define __LOCKBITS_IN_MAINFLASH_SEGMENT_SIZE
```

Value:

```
__segment_size(__LOCKBITS_IN_MAINFLASH__)
```

Portable segment names.

Definition at line 492 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

_UNRETAINED_RAM_SEGMENT_SIZE

```
#define _UNRETAINED_RAM_SEGMENT_SIZE
```

Value:

```
_segment_size(_UNRETAINED_RAM_)
```

Portable segment names.

Definition at line 493 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

Function Documentation

_executeBarrierInstructions

```
void _executeBarrierInstructions (void)
```

Parameters

N/A		
-----	--	--

Definition at line 501 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/cortexm3/compiler/iar.h

Common PLATFORM_HEADER Configuration

Common PLATFORM_HEADER Configuration

Compiler and Platform specific definitions and typedefs common to all platforms.

[platform-common.h](#) provides PLATFORM_HEADER defaults and common definitions. This head should never be included directly, it should only be included by the specific PLATFORM_HEADER used by your platform.

See [platform-common.h](#) for source code.

Generic Types

```
#define TRUE 1
    An alias for one, used for clarity.

#define FALSE 0
    An alias for zero, used for clarity.

#define NULL ((void *)0)
    The null pointer.
```

Bit Manipulation Macros

```
#define BIT (x)
    Useful to reference a single bit of a byte.

#define BIT32 (x)
    Useful to reference a single bit of an uint32_t type.

#define SETBIT (reg, bit)
    Sets bit in the reg register or byte.

#define SETBITS (reg, bits)
    Sets the bits in the reg register or the byte as specified in the bitmask bits.

#define CLEARBIT (reg, bit)
    Clears a bit in the reg register or byte.

#define CLEARBITS (reg, bits)
    Clears the bits in the reg register or byte as specified in the bitmask bits.

#define READBIT (reg, bit)
    Returns the value of bit within the register or byte reg.

#define READBITS (reg, bits)
    Returns the value of the bitmask bits within the register or byte reg.
```

Byte Manipulation Macros

```
#define LOW_BYTE (n)
    Returns the low byte of the 16-bit value n as an uint8_t.
```

```

#define HIGH_BYTE (n)
Returns the high byte of the 16-bit value n as an uint8_t.

#define HIGH_LOW_TO_INT (high, low)
Returns the value built from the two uint8_t values high and low.

#define INT8U_TO_INT32U (byte3, byte2, byte1, byte0)
Returns the value built from the four uint8_t as an uint32_t.

#define BYTE_0 (n)
Returns the low byte of the 32-bit value n as an uint8_t.

#define BYTE_1 (n)
Returns the second byte of the 32-bit value n as an uint8_t.

#define BYTE_2 (n)
Returns the third byte of the 32-bit value n as an uint8_t.

#define BYTE_3 (n)
Returns the high byte of the 32-bit value n as an uint8_t.

#define BYTE_4 (n)
Returns the fifth byte of the 64-bit value n as an uint8_t.

#define BYTE_5 (n)
Returns the sixth byte of the 64-bit value n as an uint8_t.

#define BYTE_6 (n)
Returns the seventh byte of the 64-bit value n as an uint8_t.

#define BYTE_7 (n)
Returns the high byte of the 64-bit value n as an uint8_t.

#define COUNTOF (a)
Returns the number of entries in an array.

```

Time Manipulation Macros

```

#define elapsedTimeInt8u (oldTime, newTime)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define elapsedTimeInt16u (oldTime, newTime)
Returns the elapsed time between two 16 bit values. Result may not be valid if the time samples differ by more than 32767.

#define elapsedTimeInt32u (oldTime, newTime)
Returns the elapsed time between two 32 bit values. Result may not be valid if the time samples differ by more than 2147483647.

#define MAX_INT8U_VALUE (0xFF)
Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

#define HALF_MAX_INT8U_VALUE (0x80)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define timeGTorEqualInt8u (t1, t2)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

#define MAX_INT16U_VALUE (0xFFFF)
Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

```

- #define [HALF_MAX_INT16U_VALUE](#) (0×8000)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
- #define [timeGTorEqualInt16u](#) (t1, t2)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
- #define [MAX_INT32U_VALUE](#) (0xFFFFFFFFUL)
Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.
- #define [HALF_MAX_INT32U_VALUE](#) (0×80000000UL)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.
- #define [timeGTorEqualInt32u](#) (t1, t2)
Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Miscellaneous Macros

- #define [UNUSED_VAR](#) (x)
- #define [DEBUG_LEVEL](#) BASIC_DEBUG
Set debug level based on whether DEBUG or DEBUG_STRIPPED are defined.
- #define [STATIC_ASSERT](#) (__condition, __errorstr)
Disable static assertions on compilers that don't support them.

Macros

- #define [MEMSET](#) (d, v, l)
Friendly convenience macro pointing to the C Stdlib functions.
- #define [MEMCOPY](#) (d, s, l)
- #define [MEMMOVE](#) (d, s, l)
- #define [MEMPGMCOPY](#) (d, s, l)
- #define [MEMCOMPARE](#) (s0, s1, l)
- #define [MEMPGMCOMPARE](#) (s0, s1, l)

Generic Types Documentation

TRUE

```
#define TRUE
```

Value:

```
1
```

An alias for one, used for clarity.

Definition at line 210 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

FALSE

```
#define FALSE
```

Value:

```
0
```

An alias for zero, used for clarity.

Definition at line 215 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

NULL

```
#define NULL
```

Value:

```
((void *)0)
```

The null pointer.

Definition at line 222 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

Bit Manipulation Macros Documentation

BIT

```
#define BIT
```

Value:

```
(x)
```

Useful to reference a single bit of a byte.

Definition at line 235 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BIT32

```
#define BIT32
```

Value:

```
(x)
```

Useful to reference a single bit of an uint32_t type.

Definition at line 240 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

SETBIT

```
#define SETBIT
```

Value:


```
(reg, bit)
```

Sets `bit` in the `reg` register or byte.

Note

- Assuming `reg` is an IO register, some platforms (such as the AVR) can implement this in a single atomic operation.

Definition at line 247 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

SETBITS

```
#define SETBITS
```

Value:

```
(reg, bits)
```

Sets the bits in the `reg` register or the byte as specified in the bitmask `bits`.

Note

- This is never a single atomic operation.

Definition at line 254 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

CLEARBIT

```
#define CLEARBIT
```

Value:

```
(reg, bit)
```

Clears a bit in the `reg` register or byte.

Note

- Assuming `reg` is an IO register, some platforms (such as the AVR) can implement this in a single atomic operation.

Definition at line 261 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

CLEARBITS

```
#define CLEARBITS
```

Value:

```
(reg, bits)
```

Clears the bits in the `reg` register or byte as specified in the bitmask `bits`.

Note

- This is never a single atomic operation.

Definition at line 268 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

READBIT

```
#define READBIT
```

Value:

(reg, bit)

Returns the value of `bit` within the register or byte `reg`.

Definition at line 273 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

READBITS

```
#define READBITS
```

Value:

(reg, bits)

Returns the value of the bitmask `bits` within the register or byte `reg`.

Definition at line 279 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

Byte Manipulation Macros Documentation

LOW_BYTE

```
#define LOW_BYTE
```

Value:

(n)

Returns the low byte of the 16-bit value `n` as an `uint8_t`.

Definition at line 293 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

HIGH_BYTE

```
#define HIGH_BYTE
```

Value:

(n)

Returns the high byte of the 16-bit value `n` as an `uint8_t`.

Definition at line 298 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

HIGH_LOW_TO_INT

```
#define HIGH_LOW_TO_INT
```

Value:

```
0 | ( \
0 | (((uint16_t) (((uint16_t) (high)) << 8)) \
0 | + ((uint16_t) ((low) & 0xFFu)) \
0 | )
```

Returns the value built from the two `uint8_t` values `high` and `low`.

Definition at line 304 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

INT8U_TO_INT32U

```
#define INT8U_TO_INT32U
```

Value:

```
0 | ( \
0 | (((uint32_t) (byte3)) << 24) \
0 | + (((uint32_t) (byte2)) << 16) \
0 | + (((uint32_t) (byte1)) << 8) \
0 | + ((uint32_t) ((byte0) & 0xFFu)) \
0 | )
```

Returns the value built from the four `uint8_t` as an `uint32_t`.

Definition at line 312 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_0

```
#define BYTE_0
```

Value:

```
(n)
```

Returns the low byte of the 32-bit value `n` as an `uint8_t`.

Definition at line 322 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_1

```
#define BYTE_1
```

Value:

```
(n)
```

Returns the second byte of the 32-bit value `n` as an `uint8_t`.

Definition at line 327 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_2

```
#define BYTE_2
```

Value:

```
(n)
```

Returns the third byte of the 32-bit value `n` as an `uint8_t`.

Definition at line 332 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_3

```
#define BYTE_3
```

Value:

```
(n)
```

Returns the high byte of the 32-bit value `n` as an `uint8_t`.

Definition at line 337 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_4

```
#define BYTE_4
```

Value:

```
(n)
```

Returns the fifth byte of the 64-bit value `n` as an `uint8_t`.

Definition at line 342 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_5

```
#define BYTE_5
```

Value:

```
(n)
```

Returns the sixth byte of the 64-bit value `n` as an `uint8_t`.

Definition at line 347 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_6

```
#define BYTE_6
```

Value:

```
(n)
```

Returns the seventh byte of the 64-bit value `n` as an `uint8_t`.

Definition at line 352 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

BYTE_7

```
#define BYTE_7
```

Value:

(n)

Returns the high byte of the 64-bit value `n` as an `uint8_t`.

Definition at line 357 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

COUNTOF

```
#define COUNTOF
```

Value:

(a)

Returns the number of entries in an array.

Definition at line 362 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

Time Manipulation Macros Documentation

elapsedTimeInt8u

```
#define elapsedTimeInt8u
```

Value:

(oldTime, newTime)

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 377 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

elapsedTimeInt16u

```
#define elapsedTimeInt16u
```

Value:

(oldTime, newTime)

Returns the elapsed time between two 16 bit values. Result may not be valid if the time samples differ by more than 32767.

Definition at line 384 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

elapsedTimeInt32u

```
#define elapsedTimeInt32u
```

Value:

```
(oldTime, newTime)
```

Returns the elapsed time between two 32 bit values. Result may not be valid if the time samples differ by more than 2147483647.

Definition at line 391 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MAX_INT8U_VALUE

```
#define MAX_INT8U_VALUE
```

Value:

```
(0xFF)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 398 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

HALF_MAX_INT8U_VALUE

```
#define HALF_MAX_INT8U_VALUE
```

Value:

```
(0x80)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 399 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

timeGTorEqualInt8u

```
#define timeGTorEqualInt8u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 400 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MAX_INT16U_VALUE

```
#define MAX_INT16U_VALUE
```

Value:

```
(0xFFFF)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 407 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

HALF_MAX_INT16U_VALUE

```
#define HALF_MAX_INT16U_VALUE
```

Value:

```
(0x8000)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 408 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

timeGTorEqualInt16u

```
#define timeGTorEqualInt16u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 409 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MAX_INT32U_VALUE

```
#define MAX_INT32U_VALUE
```

Value:

```
(0xFFFFFFFFUL)
```

Returns true if t1 is greater than t2. Can only account for 1 wrap around of the variable before it is wrong.

Definition at line 416 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

HALF_MAX_INT32U_VALUE

```
#define HALF_MAX_INT32U_VALUE
```

Value:

```
(0x80000000UL)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 417 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

timeGTorEqualInt32u

```
#define timeGTorEqualInt32u
```

Value:

```
(t1, t2)
```

Returns the elapsed time between two 8 bit values. Result may not be valid if the time samples differ by more than 127.

Definition at line 418 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

Miscellaneous Macros Documentation

UNUSED_VAR

```
#define UNUSED_VAR
```

Value:

```
(x)
```

Description:
Useful macro for avoiding compiler warnings related to unused

function arguments or unused variables.

Definition at line 436 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

DEBUG_LEVEL

```
#define DEBUG_LEVEL
```

Value:

```
BASIC_DEBUG
```

Set debug level based on whether DEBUG or DEBUG_STRIPPED are defined.

Definition at line 458 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

STATIC_ASSERT

```
#define STATIC_ASSERT
```

Disable static assertions on compilers that don't support them.

Definition at line 466 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h`

Macro Definition Documentation

MEMSET


```
#define MEMSET
```

Value:

```
(d, v, l)
```

Friendly convenience macro pointing to the C Stdlib functions.

Definition at line 188 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MEMCOPY

```
#define MEMCOPY
```

Value:

```
(d, s, l)
```

Definition at line 189 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MEMMOVE

```
#define MEMMOVE
```

Value:

```
(d, s, l)
```

Definition at line 190 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MEMPGMCOPY

```
#define MEMPGMCOPY
```

Value:

```
(d, s, l)
```

Definition at line 191 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MEMCOMPARE

```
#define MEMCOMPARE
```

Value:

```
(s0, s1, l)
```

Definition at line 192 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

MEMPGMCOMPARE

```
#define MEMPGMCOMPARE
```

Value:

(s0, s1, l)

Definition at line 193 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/generic/compiler/platform-common.h

NVIC Configuration

NVIC Configuration

Reset Cause Type Definitions

Reset Cause Type Definitions

HAL Utilities

HAL Utilities

Modules

[Crash and Watchdog Diagnostics](#)

[Cyclic Redundancy Code \(CRC\)](#)

[Random Number Generation](#)

[Network to Host Byte Order Conversion](#)

Crash and Watchdog Diagnostics

Crash and Watchdog Diagnostics

Cyclic Redundancy Code (CRC)

Cyclic Redundancy Code (CRC)

Functions that provide access to cyclic redundancy code (CRC) calculation. See [crc.h](#) for source code.

Functions

- `uint16_t` [halCommonCrc16](#)(`uint8_t` newByte, `uint16_t` prevResult)
Calculates 16-bit cyclic redundancy code (CITT CRC 16).
- `uint32_t` [halCommonCrc32](#)(`uint8_t` newByte, `uint32_t` prevResult)
Calculates 32-bit cyclic redundancy code.

Macros

- ```
#define INITIAL_CRC 0xFFFFFFFFL

#define CRC32_START INITIAL_CRC

#define CRC32_END 0xDEBB20E3L
```

## Function Documentation

### halCommonCrc16

```
uint16_t halCommonCrc16 (uint8_t newByte, uint16_t prevResult)
```

Calculates 16-bit cyclic redundancy code (CITT CRC 16).

#### Parameters

|     |            |                                     |
|-----|------------|-------------------------------------|
| N/A | newByte    | The new byte to be run through CRC. |
| N/A | prevResult | The previous CRC result.            |

Applies the standard CITT CRC 16 polynomial to a single byte. It should support being called first with an initial value, then repeatedly until all data is processed.

#### Returns

- The new CRC result.

Definition at line 38 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/crc.h`

### halCommonCrc32

```
uint32_t halCommonCrc32 (uint8_t newByte, uint32_t prevResult)
```

Calculates 32-bit cyclic redundancy code.

#### Parameters

|     |            |                                     |
|-----|------------|-------------------------------------|
| N/A | newByte    | The new byte to be run through CRC. |
| N/A | prevResult | The previous CRC result.            |

**Note**

- On some radios or micros, the CRC for error detection on packet data is calculated in hardware.

Applies a CRC32 polynomial to a single byte. It should support being called first with an initial value, then repeatedly until all data is processed.

**Returns**

- The new CRC result.

Definition at line 55 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/crc.h

## Macro Definition Documentation

### INITIAL\_CRC

```
#define INITIAL_CRC
```

**Value:**

```
0xFFFFFFFFL
```

Definition at line 58 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/crc.h

### CRC32\_START

```
#define CRC32_START
```

**Value:**

```
INITIAL_CRC
```

Definition at line 59 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/crc.h

### CRC32\_END

```
#define CRC32_END
```

**Value:**

```
0xDEBB20E3L
```

Definition at line 60 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/crc.h



## Random Number Generation

# Random Number Generation

Functions that provide access to random numbers.

These functions may be hardware accelerated, though often are not.

See [random.h](#) for source code.

## Functions

void [halStackSeedRandom](#)(uint32\_t seed)  
Seeds the [halCommonGetRandom\(\)](#) pseudorandom number generator.

uint16\_t [halCommonGetRandom](#)(void)  
Runs a standard LFSR to generate pseudorandom numbers.

## Function Documentation

### halStackSeedRandom

```
void halStackSeedRandom (uint32_t seed)
```

Seeds the [halCommonGetRandom\(\)](#) pseudorandom number generator.

#### Parameters

|     |      |                                               |
|-----|------|-----------------------------------------------|
| N/A | seed | A seed for the pseudorandom number generator. |
|-----|------|-----------------------------------------------|

Called by the stack during initialization with a seed from the radio.

Definition at line 36 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/random.h`

### halCommonGetRandom

```
uint16_t halCommonGetRandom (void)
```

Runs a standard LFSR to generate pseudorandom numbers.

#### Parameters

|     |  |  |
|-----|--|--|
| N/A |  |  |
|-----|--|--|

Called by the MAC in the stack to choose random backoff slots.

Complicated implementations may improve the MAC's ability to avoid collisions in large networks, but it is **critical** to implement this function to return quickly.

Definition at line 51 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/random.h`

## Network to Host Byte Order Conversion

# Network to Host Byte Order Conversion

Functions that provide conversions from network to host byte order. Network byte order is big endian, so these APIs are only necessary on platforms which have a natural little endian byte order. On big-endian platforms, the APIs are macro'd away to nothing. See [endian.h](#) for source code.

## Functions

- uint16\_t [NTOHS](#)(uint16\_t val)  
Converts a short (16-bit) value from network to host byte order.
- uint32\_t [NTOHL](#)(uint32\_t val)  
Converts a long (32-bit) value from network to host byte order.
- uint32\_t [SwapEndiannessInt32u](#)(uint32\_t val)

## Macros

- ```
#define HTONL NTOHL
#define HTONS NTOHS
```

Function Documentation

NTOHS

```
uint16_t NTOHS (uint16_t val)
```

Converts a short (16-bit) value from network to host byte order.

Parameters

N/A	val	
-----	-----	--

Definition at line 45 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/endian.h`

NTOHL

```
uint32_t NTOHL (uint32_t val)
```

Converts a long (32-bit) value from network to host byte order.

Parameters

N/A	val	
-----	-----	--

Definition at line 53 of file `/mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/endian.h`

SwapEndiannessInt32u

```
uint32_t SwapEndiannessInt32u (uint32_t val)
```

Parameters

N/A	val	
-----	-----	--

Definition at line 79 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/endian.h

Macro Definition Documentation

HTONL

```
#define HTONL
```

Value:

```
NTOHL
```

Definition at line 71 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/endian.h

HTONS

```
#define HTONS
```

Value:

```
NTOHS
```

Definition at line 74 of file /mnt/raid/workspaces/ws.Q8qnkBLX2/overlay/gsdk/platform/base/hal/micro/endian.h

Deprecated List

Deprecated List

- Global [EMBER_MAX_SECURED_APPLICATION_PAYLOAD_LENGTH](#)
The maximum length in bytes of the application payload for a secured message. This define has been deprecated, you should use the [emberGetMaximumPayloadLength](#) API instead.
- Global [EMBER_MAX_UNSECURED_APPLICATION_PAYLOAD_LENGTH](#)
The maximum length in bytes of the application payload for an unsecured message. This define has been deprecated, you should use the [emberGetMaximumPayloadLength](#) API instead.

Training

Training

This series of tutorials demonstrates "the essentials" of building applications based on Silicon Labs Connect. The collection presents an incremental review of key techniques and features that help developers access the powerful convenience available thru Connect. These tutorials supplement the [Developer's Guide](#) and the API reference. Note: The API reference is the authoritative Connect resource, and represents the most current documentation at all times. Grant it a priority in any conflicts you may encounter in the following (or any other) Connect guidance.

Prerequisites

We strongly recommend familiarity with the resources above (especially the Developer's Guide) before beginning Connect-based application development, as they provide insight on crucial decisions that impact the design phase of your project.

That said, each tutorial in this series walks you through important Connect concepts using accessible demonstrations and discussions that illuminate how you can make Connect work for you. To extract the most value from this tutorial series, programming experience in embedded C and (at least) a baseline understanding of wireless networking theory is recommended. See [Fundamentals](#).

The Tutorials

This group of tutorials leads you from "square one" (tutorial 1) to performing packet analysis on traffic captured from the firmware you've developed along the way (tutorial 7). A Direct mode Connect-based application serves as the demonstration vehicle. Though the coverage spans a broad range of topics, the tutorials are designed to be completed sequentially. However, Tutorial 6 is largely independent, and is immediately accessible as a strong subject matter reference.

1. [Getting Started with Application Development](#)
2. [Communication Basics: Send and Receive](#)
3. [Command Line Interface](#)
4. [Communication Features: Acknowledge and Message Queue](#)
5. [Communication Features: Security](#)
6. [IEEE 802.15.4 Addressing](#)
7. [Traffic Analysis: Addressing, Acknowledgement, and Security](#)
8. [Network Management](#)

